

Nike DX7616-404

Nike Star Runner 4 Baby/Toddler Shoes (DX7616-404) Instruction Manual

1. PRODUCT OVERVIEW

The Nike Star Runner 4 is designed for baby and toddler feet, offering comfort and support for active young children. This manual provides essential information for the proper use and care of your Star Runner 4 shoes.



Image 1.1: Side view of the Nike Star Runner 4 shoe, highlighting its design and sole structure.

Key Features:

- **Easy On/Off:** Loops on the tongue and heel facilitate wide opening for easy foot insertion.
- **Durable Construction:** Synthetic material covers the front for enhanced durability.
- **Enhanced Grip:** Tread pattern on the sole provides traction on various surfaces.
- **Comfortable Cushioning:** Soft midsole cushioning supports active movement.
- **Breathable Upper:** Vertical mesh upper helps maintain foot comfort.

2. SETUP AND WEARING INSTRUCTIONS

Follow these steps to ensure a comfortable and secure fit for your child.

1. **Prepare the Shoe:** Grasp the loops located on the tongue and heel of the shoe. Pull them gently to open the shoe's collar as wide as possible.
2. **Insert Foot:** Guide your child's foot into the shoe. Ensure the heel is seated correctly at the back of the shoe.
3. **Adjust Laces:** The Star Runner 4 features a lace-up closure. Adjust the laces to achieve a snug, yet comfortable fit. Avoid overtightening, which can restrict circulation, or leaving them too loose, which can cause tripping.
4. **Check Fit:** Ensure there is approximately a thumb's width of space between your child's longest toe and the front of the shoe. The shoe should feel secure around the midfoot without pinching.



Image 2.1: Top view illustrating the tongue and heel loops for easy access.

3. OPERATING (USAGE)

The Nike Star Runner 4 shoes are designed for everyday wear and various activities suitable for babies and toddlers.

- **Walking and Running:** The soft midsole provides cushioning for comfortable movement, while the durable rubber sole offers reliable grip.
- **Playtime:** The robust construction, including the rubber-wrapped toe, is built to withstand typical play activities on different surfaces like pavement, grass, and gravel.
- **Ventilation:** The vertical mesh upper promotes airflow, helping to keep your child's feet cool during activity.



Image 3.1: The sole's tread pattern, designed for multi-surface grip.

4. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your Nike Star Runner 4 shoes.

- **Cleaning the Upper:** For the vertical mesh upper and synthetic overlays, gently wipe with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners. Allow to air dry completely away from direct heat.
- **Cleaning the Sole:** The rubber sole can be cleaned with a brush and mild soap and water to remove dirt and debris.
- **Drying:** Do not machine wash or tumble dry. Always air dry shoes at room temperature. Stuffing with paper towels can help absorb moisture and maintain shape.
- **Storage:** Store shoes in a cool, dry place away from direct sunlight to prevent material degradation.



Image 4.1: Close-up of the mesh upper and synthetic material for cleaning reference.

5. TROUBLESHOOTING

If you encounter any issues with your Star Runner 4 shoes, consider the following:

- **Poor Fit:** If shoes feel too tight or too loose, re-check the sizing against your child's foot measurements. Ensure laces are adjusted correctly. Children's feet grow quickly, so regular size checks are recommended.
- **Excessive Wear:** While designed for durability, extreme use or specific activities can accelerate wear. Inspect shoes regularly for signs of damage and replace them when necessary to ensure proper support and safety.
- **Slipping:** If the shoes are slipping on certain surfaces, ensure the soles are clean and free of mud or debris that might reduce traction.

6. SPECIFICATIONS

Feature	Detail
---------	--------

Model Number	DX7616-404
Department	Unisex-Child
Sole Material	Rubber
Outer Material	Vertical mesh upper with synthetic overlays
Closure Type	Lace-Up
Approx. Package Dimensions	13.15 x 5.08 x 4.61 inches
Approx. Item Weight	7.05 ounces

7. WARRANTY INFORMATION

Specific warranty details for Nike products, including the Star Runner 4 shoes, are typically provided at the point of purchase or on the official Nike website. Please retain your proof of purchase for any warranty claims. For detailed information, refer to the official Nike warranty policy or contact your retailer.

8. SUPPORT AND CONTACT

For further assistance, product inquiries, or support, please contact:

- **Retailer:** The store or online platform where the shoes were purchased.
- **Nike Customer Service:** Visit the official Nike website (www.nike.com) for contact information, FAQs, and support resources.

© 2024 Nike. All rights reserved. This manual is for informational purposes only.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question