

Toshiba CL2-C

Instruction Manual for Toshiba Torneo V Cordless Cleaner AC Adapter

MODEL CL2-C (FOR VC-CL1200 SERIES)

1. Important Safety Information

Please read all safety instructions carefully before using this product. Failure to follow these instructions may result in electric shock, fire, or other hazards.

- **Indoor Use Only:** This AC adapter is designed exclusively for indoor use. Do not expose it to rain, moisture, or use it in damp environments.
- **Dedicated Use:** This adapter is specifically designed for Toshiba Torneo V Cordless Cleaner Model VC-CL1200. Do not use it with any other devices or for purposes other than its intended use. Using an incompatible adapter may damage the device or cause a fire.
- **Voltage Compatibility:** Ensure your power outlet voltage matches the adapter's input specifications (100V~ 50/60Hz).
- **Handle with Care:** Do not drop, disassemble, or attempt to repair the adapter. If the adapter or its cable is damaged, discontinue use immediately and contact a qualified service professional.
- **Ventilation:** Do not cover the adapter during use, as this may lead to overheating.

2. Product Overview

The CL2-C AC adapter is a genuine Toshiba power supply unit designed to provide power and charge the battery of your Toshiba Torneo V Cordless Cleaner (Model VC-CL1200).



Image 1: Front view of the Toshiba AC Adapter CL2-C. The label clearly indicates "ACアダプター" (AC Adapter), "入力：100V～50/60Hz 0.23A" (Input: 100V~ 50/60Hz 0.23A), "出力：21V ≒ 0.45A" (Output: 21V ≒ 0.45A), "MODEL NO. CL2-C", "室内用" (For indoor use), and warnings about reading the manual and using it only for Toshiba cleaners. It also states "MADE IN CHINA" and "三菱ライフスタイル株式会社" (Toshiba Lifestyle Corporation).



Image 2: A closer view of the AC adapter's label, highlighting the model number CL2-C and the electrical specifications. This image provides a clear view of the text on the adapter.

3. Setup and Connection

Follow these steps to properly connect your AC adapter to the cleaner and a power source.

1. **Connect to Cleaner:** Insert the DC output plug of the AC adapter firmly into the charging port of your Toshiba Torneo V Cordless Cleaner (VC-CL1200). Ensure a secure connection.
2. **Connect to Power Outlet:** Plug the AC input cable of the adapter into a standard 100V~ 50/60Hz

wall power outlet.

3. **Verify Connection:** Once connected, the cleaner's charging indicator (if available) should illuminate, indicating that the battery is charging.



Image 3: The Toshiba AC Adapter CL2-C shown with its output cable coiled. This illustrates the physical form factor of the adapter and its attached cable, ready for connection.

4. Operating Instructions

The AC adapter operates automatically once connected. It converts the household AC power to the DC power required by your cleaner for operation and battery charging.

- **Charging:** When connected, the adapter will begin charging the cleaner's battery. Refer to your cleaner's manual for specific charging times and battery indicators.
- **Power Supply:** The adapter also supplies power to the cleaner when it is in use while plugged in, if supported by the cleaner model.

5. Maintenance and Care

Proper maintenance ensures the longevity and safe operation of your AC adapter.

- **Cleaning:** Disconnect the adapter from the power outlet before cleaning. Wipe the exterior with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Regularly inspect the adapter and its cable for any signs of damage, such as cuts, fraying, or bent pins. If damage is found, discontinue use.

6. Troubleshooting

If you encounter issues with your AC adapter, try the following steps:

- **No Power/Not Charging:**
 - Ensure the adapter is securely plugged into both the wall outlet and the cleaner.
 - Check if the wall outlet is functional by plugging in another device.
 - Verify that the adapter model (CL2-C) is correct for your Toshiba Torneo V Cordless Cleaner (VC-CL1200).
- **Overheating:**

- Ensure the adapter is in a well-ventilated area and not covered.
- If overheating persists, discontinue use and contact customer support.

If these steps do not resolve the issue, please refer to your cleaner's main instruction manual or contact Toshiba customer support.

7. Specifications

Model Number	CL2-C
Input	100V~ 50/60Hz 0.23A
Output	21V === 0.45A
Compatibility	Toshiba Torneo V Cordless Cleaner VC-CL1200
Brand	Toshiba (Manufacturer's Genuine Part)
Manufacturer	Toshiba Lifestyle Corporation
Dimensions (approx.)	13.5 x 8.7 x 3.2 cm
Weight (approx.)	170 g
Country of Origin	Made in China

8. Warranty and Support

Specific warranty information for this AC adapter is not provided within this manual. Please refer to the warranty documentation included with your Toshiba Torneo V Cordless Cleaner or visit the official Toshiba Lifestyle Corporation website for details on warranty coverage and customer support.

For technical assistance or inquiries, please contact Toshiba customer service through their official channels.