

Smoko 4101

Smoko Astro Tayto UFO Speaker Instruction Manual

INTRODUCTION

Welcome to the instruction manual for your Smoko Astro Tayto UFO Speaker. This quirky and compact speaker is shaped like a UFO and is designed to deliver out-of-this-world sound quality to any room. Featuring easy Bluetooth connectivity and a rechargeable battery, it provides hours of music and fun with its playful light-up functionality. Please read this manual carefully to ensure proper use and maintenance of your speaker.

PRODUCT OVERVIEW

Features

- Tayto Potato UFO Bluetooth Speaker with fun lights
- Compact Size: 4.7" x 5.5" x 3.5"
- Durable Material: ABS construction
- Rechargeable Battery for portable use
- Easy Bluetooth Connectivity

What's in the Box

- 1 x Smoko Astro Tayto UFO Speaker

Product Visual



Image: The Smoko Astro Tayto UFO Speaker. This image displays the speaker's unique design, featuring a blue UFO body, a clear top dome, and a charming yellow potato character (Tayto) inside. The character is illuminated by a warm light, highlighting the speaker's fun and playful aesthetic. Small yellow accents are visible on the side and as feet.

SETUP

Charging the Speaker

Before first use, fully charge your Smoko Astro Tayto UFO Speaker. Locate the charging port, typically on the underside or side of the speaker. Connect the provided charging cable to the speaker and plug the other end into a USB power source (e.g., computer USB port, USB wall adapter). The indicator light will show charging status and turn off or change color when fully charged.

Bluetooth Pairing

1. **Power On:** Press and hold the power button (usually located on the speaker's body) for a few seconds until you hear an audible prompt or see an indicator light flash, indicating it's in pairing mode.
2. **Activate Bluetooth:** On your device (smartphone, tablet, laptop), go to your Bluetooth settings and ensure Bluetooth is turned on.
3. **Select Speaker:** In the list of available Bluetooth devices, look for "Smoko Astro Tayto Speaker" or a

similar name. Tap on it to connect.

4. **Confirmation:** Once successfully paired, you will hear a confirmation sound from the speaker, and the indicator light will typically become solid.
5. **Reconnect:** The speaker will automatically attempt to reconnect to the last paired device when powered on, if that device's Bluetooth is active and within range.

OPERATING INSTRUCTIONS

Power On/Off

- **To Power On:** Press and hold the power button for approximately 3 seconds.
- **To Power Off:** Press and hold the power button again for approximately 3 seconds.

Playing Audio

Once paired, simply start playing audio from your connected device. The sound will be routed through your Smoko Astro Tayto UFO Speaker. Use your device's volume controls to adjust the playback volume.

Light Features

The speaker features fun lights. Refer to the specific controls on your speaker for light mode adjustments. This may involve a dedicated light button or a combination of existing buttons. The product description mentions "Control Method: App", so it's possible light features are controlled via a dedicated app. Please check the manufacturer's website or app store for the official Smoko app if available.

MAINTENANCE

To ensure the longevity and optimal performance of your Smoko Astro Tayto UFO Speaker, follow these maintenance guidelines:

- **Cleaning:** Spot clean only. Use a soft, dry cloth to wipe down the exterior of the speaker. For stubborn marks, lightly dampen the cloth with water. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Water Exposure:** This speaker is not waterproof. Avoid exposing it to water or excessive moisture.
- **Handling:** Handle the speaker with care to prevent drops or impacts that could damage internal components.

TROUBLESHOOTING

If you encounter any issues with your Smoko Astro Tayto UFO Speaker, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is depleted.	Charge the speaker fully using the provided cable.
Cannot pair with Bluetooth device.	Speaker is not in pairing mode; device Bluetooth is off; speaker is too far from device.	Ensure speaker is in pairing mode (flashing light). Turn Bluetooth on your device. Move speaker closer to device (within 33 feet/10 meters). Forget the device on your phone and try pairing again.
No sound from speaker.	Volume is too low; speaker is not connected; incorrect audio output selected on device.	Increase volume on both the speaker and your connected device. Ensure the speaker is successfully paired. Check your device's audio output settings.
Sound quality is poor or distorted.	Device is too far from speaker; interference; low battery.	Move device closer to speaker. Avoid obstacles between speaker and device. Charge the speaker.
Lights are not working.	Light feature is off; app control issue.	Check if there's a dedicated light button. If controlled by app, ensure the app is functioning correctly and updated.

SPECIFICATIONS

Attribute	Detail
Model Name	Tayto Potato UFO Speaker
Model Number	4101
Brand	Smoko
Speaker Type	3D
Compatible Devices	Laptop, MP3 Player, Smartphone, Tablet, Television
Product Dimensions	4.5"D x 5.5"W x 3.5"H
Item Weight	0.66 Pounds (10.6 ounces)
Material	ABS
Is Waterproof	False
Control Method	App
Wireless Communication Technology	Bluetooth
Speaker Size	4.7 Inches
Power Source	Battery Powered
Audio Driver Type	Dynamic Driver
Speaker Maximum Output Power	2.5 Watts
Audio Output Mode	3D Spatial Audio
Mounting Type	Desktop
UPC	810134233164

WARRANTY AND SUPPORT

Your Smoko Astro Tayto UFO Speaker is covered by a manufacturer's warranty against defects in materials and workmanship. The specific duration and terms of the warranty may vary. Please retain your proof of purchase for warranty claims.

For technical support, warranty inquiries, or further assistance, please visit the official Smoko website or contact their customer service department. Contact information can typically be found on the product packaging or the manufacturer's official website.

Manufacturer: Smoko

Website: Visit the Smoko Store on Amazon (for general brand information)