Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Tamagotchi 43408

Tamagotchi Connection - Sweet Charms Instruction Manual

Model: 43408

Introduction

Welcome to the world of Tamagotchi Connection! This virtual pet device brings back the nostalgic experience of raising a digital companion. Your Tamagotchi character will grow and evolve based on the care you provide. This manual will guide you through the setup, operation, and maintenance of your Tamagotchi Connection Sweet Charms device.

Safety Information

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.
Please ensure that the battery compartment is securely closed to prevent access to small parts. Adult supervision is recommended for young users.

Setup

1. Battery Installation

Your Tamagotchi Connection device requires one CR2032 battery, which is included. To install or replace the battery:

1. Locate the battery compartment on the back of the device.
2. Using a small screwdriver, carefully open the battery compartment cover.
3. Insert the CR2032 battery with the positive (+) side facing up.
4. Replace the cover and secure it with the screw.

2. Initial Activation and Settings

After battery installation, your Tamagotchi will hatch. Follow the on-screen prompts to set the time and date. You will also be able to name your new virtual pet.



Image: Tamagotchi Connection Sweet Charms device with a hatched character on its screen.

Operating Your Tamagotchi

The Tamagotchi Connection device features three buttons (A, B, C) for interaction:

- **Button A:** Selects menu options.
- **Button B:** Confirms selections.
- **Button C:** Cancels actions or returns to the previous screen.

Caring for Your Pet

Your Tamagotchi requires daily care to grow into a healthy and happy companion. Monitor its needs using the status icons.

- **Feeding:** Provide meals and snacks when your Tamagotchi is hungry.
- **Playing:** Engage in mini-games to keep your pet happy and earn Gotchi Points. There are over 10 mini-games available.

- **Cleaning:** Clean up after your pet when it makes a mess.
- **Medicine:** Administer medicine if your Tamagotchi becomes sick.
- **Discipline:** Discipline your pet if it misbehaves.
- **Lights:** Turn the lights off when your Tamagotchi goes to sleep.

Growth and Evolution

Your Tamagotchi character will evolve through different stages (egg, baby, child, teenager, adult) based on the care you provide. There are over 50 unique characters to discover.

Connection Play

The Tamagotchi Connection allows you to interact with other Tamagotchi Connection devices. You can:

- Make friends with other Tamagotchi characters.
- Play games together.
- Exchange gifts.
- Even get married and raise new generations of Tamagotchi characters.



Image: Multiple Tamagotchi devices showcasing various characters and the concept of connection play.

Items and Gotchi Points

Collect over 150 items for your Tamagotchi. Earn Gotchi Points by playing games, which can be used to purchase new food and other items. Some special items can be unlocked using passwords found in various sources.

Maintenance

Battery Replacement

When the battery runs low, the screen may dim or the device may stop responding. Replace the CR2032 battery as described in the Setup section.

Cleaning

To clean your Tamagotchi device, gently wipe it with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the device or screen.

Troubleshooting

- **Dim Screen/Low Contrast:** The Tamagotchi Connection screen does not have a backlight. For optimal visibility, use the device in a well-lit area or adjust the viewing angle.
- **Short Battery Life:** While a CR2032 battery is included, its lifespan can vary. Keep spare batteries on hand for uninterrupted play. Turning off sound during games may help conserve battery.
- **Pet Not Responding:** If your pet is unresponsive, check the battery. If the issue persists, try resetting the device (refer to the manufacturer's website for specific reset instructions, as this may erase progress).
- **No Pause Function:** The device does not have a dedicated pause function. To temporarily stop gameplay, you can remove the battery or enter the clock setting menu, which effectively pauses the game.

Specifications

Feature	Detail
Model Number	43408
Dimensions (L x W x H)	1.9" x 2.13" x 0.75"
Weight	0.11 Kilograms
Screen Size	2.15 inches
Display Type	LCD
Power Source	1 x CR2032 Battery (included)
Material Type	ABS, Metal
Age Range	6+ years
UPC	045557434083

Official Product Videos

No official seller videos were found for this product. Please refer to the manufacturer's website or product page for any available video content.

Warranty and Support

For warranty information, technical support, or further assistance, please visit the official Tamagotchi website or contact Bandai Namco Toys & Collectibles America directly. Keep your purchase receipt as proof of purchase.

Packaging Information



Image: Front of the Tamagotchi Connection Sweet Charms product packaging.

TAMAGOTCHI ©BANDAI


Tamagotchi®

® & © 2024 BANDAI

Tamagotchi Connection™

MORE FRIENDS, MORE FUN!
PLUS D'AMIS, PLUS DE FUN !









Find a password for the item on the side flap inside the box!

Le mot de passe pour l'article se trouve sur le rabat latéral à l'intérieur de la boîte !

CONNECT WITH FRIENDS!
CONNECTE-TOI AVEC TES AMIS !



(A)B2L-080724

97132804

Proof of Purchase
Preuve d'anchat

0 45557 43408 3

CR2032(3V) X 1 battery included. / Pile CR2032(3V) X 1 incluse.

Software in 2 languages ENGLISH/JAPANESE / Software en 2 langues ENGLISH/JAPANESE

MADE IN CHINA

Bandai Namco Toys & Collectibles America Inc.
23 Odyssey, Irvine, CA 92618

Actual size, color, style and decoration may vary. Retain packaging and instruction as it contains important information. Bandai logo: ® & © 2024 Bandai. All Rights Reserved. Package: ® & © 2024 BANDAI.

FABRIQUÉ EN CHINE

Bandai Namco Toys & Collectibles America Inc.
23 Odyssey, Irvine, CA 92618

Taille, couleur, style et décoration réels pouvant varier. Conservez l'emballage et les instructions car ils contiennent des informations importantes. Logo Bandai : MD et © 2024 Bandai. Tous droits réservés. Emballage : ® & © 2024 BANDAI.

Image: Back of the Tamagotchi Connection product packaging, illustrating features.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DJHFG9PN

More documents and user manuals: **https://manuals.plus/**