

JOINICE FU8429

JOINICE 47-inch Tall Accent Cabinet with Doors

Model: FU8429 | Brand: JOINICE

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your JOINICE 47-inch Tall Accent Cabinet. Please read all instructions carefully before assembly and use to ensure safe and proper functionality.

IMPORTANT SAFETY INFORMATION

- Always secure the cabinet to the wall using appropriate hardware to prevent tipping.
- Be cautious when moving the cabinet, as it can be heavy when fully loaded.
- Never exceed the maximum weight capacity of 100 pounds for the top surface and 22 pounds per laminate shelf.
- Keep small parts away from children during assembly.
- Ensure all screws and fasteners are tightened securely before use.

PARTS LIST

Before beginning assembly, verify that all parts and hardware are present. Refer to the diagram below for identification.



Image: All components and hardware for the JOINICE Accent Cabinet, laid out for identification.

Panels:

- Panel No. (1) - Top Panel
- Panel No. (2) - Bottom Panel
- Panel No. (3) - Back Panel (bottom section)
- Panel No. (4) - Shelf
- Panel No. (5) - Side Panel (x2)
- Panel No. (6) - Back Support (top section)
- Panel No. (7) - Vertical Side Frame (x2)
- Panel No. (8) - Internal Shelf (x2)

- Panel No. (9) - Left Door
- Panel No. (10) - Right Door
- Panel No. (11) - Legs (x4)

Hardware:

- A - Cam Bolt (x20)
- B - Cam Lock (x20)
- C - Wood Dowel (x16)
- D - Screw (x6)
- E - Screw (x42)
- F - Backplane Buckle (x12)
- G - Wall Anchor (x2)
- H - Anti-Tipping Bracket (x2)
- I - Anti-Tipping Strap (x2)
- J - Hinge (x4)
- K - Bolt and Handle (x2)
- L - Foot Pad (x4)
- M - Magnetic Catch (x2)
- N - Metal Plate (x2)

ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. It is recommended to have a second person assist with certain steps, especially when attaching doors.

Step 1: Prepare Panel No. (3)

1. Insert 8 Cam Bolts (A) into the designated holes on Panel No. (3).
2. Insert 2 Wood Dowels (C) into the designated holes on Panel No. (3).



Image: Insertion of Cam Bolts (A) and Wood Dowels (C) into Panel No. (3).

Step 2: Attach Side Panels (5)

1. Align Side Panels (5) (x2) with Panel No. (3), ensuring the cam bolts align with the cam lock holes.
2. Insert 4 Cam Locks (B) and 4 Wood Dowels (C) into the corresponding holes on Side Panels (5) and tighten the cam locks.



Image: Securing Side Panel (5) to Panel No. (3) using Cam Locks (B).

Step 3: Attach Vertical Side Frames (7)

1. Attach Vertical Side Frames (7) (x2) to the assembly from Step 2 using 4 Cam Locks (B).



Image: Installation of Vertical Side Frame (7) using Cam Locks (B).

Step 4: Insert Internal Shelves (8)

1. Insert the two Internal Shelves (8) into the designated slots within the cabinet frame.



Image: Placement of Internal Shelf (8) within the cabinet frame.

Step 5: Prepare Bottom Panel (2)

1. Insert 8 Cam Bolts (A) into the designated holes on Panel No. (2).
2. Insert 2 Wood Dowels (C) into the designated holes on Panel No. (2).



Image: Insertion of Cam Bolts (A) and Wood Dowels (C) into Panel No. (2).

Step 6: Attach Back Support (6)

1. Attach Back Support (6) to the top of the cabinet frame using 4 Wood Dowels (C).



Image: Securing Back Support (6) to the cabinet using Wood Dowels (C).

Step 7: Attach Top Panel (1)

1. Insert 4 Cam Bolts (A) into the designated holes on Panel No. (1).
2. Attach Top Panel (1) to the assembled frame using 4 Cam Locks (B).
3. Attach 2 Magnetic Catches (M) to the underside of the top panel using 4 Screws (E).



Image: Installation of Top Panel (1) and attachment of Magnetic Catches (M) with Screws (E).

Step 8: Attach Legs (11) and Foot Pads (L)

1. Screw the 4 Legs (11) into the bottom of the cabinet.
2. Attach the 4 Foot Pads (L) to the bottom of each leg.



Image: Installation of the four Legs (11) and attachment of Foot Pads (L).

Step 9: Attach Metal Plates (N) and Hinges (J) to Doors (9) and (10)

1. Attach 2 Metal Plates (N) to each Door (9) and (10) using 2 Screws (E) per plate.
2. Attach 2 Hinges (J) to each Door (9) and (10) using 3 Screws (E) per hinge.



Image: Securing Metal Plates (N) and Hinges (J) to Doors (9) and (10) with Screws (E).

Step 10: Attach Bolt and Handles (K) to Doors (9) and (10)

1. Attach 1 Bolt and Handle (K) to each Door (9) and (10) using 1 Screw (E) per handle.



Image: Installation of Bolt and Handle (K) onto Doors (9) and (10).

Step 11: Attach Doors to Cabinet

1. Align the hinges on Doors (9) and (10) with the pre-drilled holes on the cabinet frame.
2. Secure the doors using the remaining Screws (E). (Assistance recommended for this step).



Image: Securing the doors to the cabinet frame using Screws (E).

Step 12: Install Backplane Buckles (F)

1. Attach the 12 Backplane Buckles (F) to the back of the cabinet using 12 Screws (E) to secure the back panel.



Image: Attaching Backplane Buckles (F) to the rear of the cabinet with Screws (E).

Step 13: Install Anti-Tipping Device

1. Attach the Anti-Tipping Brackets (H) to the top rear edge of the cabinet using Screws (D).
2. Mark the wall where the cabinet will be placed, aligning with the brackets.
3. Drill pilot holes into the wall at the marked locations. Insert Wall Anchors (G) if necessary.
4. Secure the Anti-Tipping Straps (I) to the wall using Screws (D) through the brackets.
5. Ensure the cabinet is securely fastened to the wall to prevent accidental tipping.



Image: Illustration demonstrating the correct method for installing the anti-tipping device, securing the cabinet to the wall for stability.

OPERATING INSTRUCTIONS

Your JOINICE Accent Cabinet is designed for versatile storage and display. The two carved doors open to reveal three internal compartments, providing ample space for various items.

- To open the doors, gently pull the knob handles.
- To close the doors, push them until the magnetic catches engage, ensuring they remain securely shut.
- The internal shelves are fixed and provide organized storage.




Image: The distressed blue accent cabinet with its doors open, revealing the three internal storage compartments and key dimensions.

MAINTENANCE

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the distressed finish.
- **Dusting:** Regularly dust with a dry, soft cloth to prevent buildup.
- **Spills:** Clean spills immediately to prevent staining.
- **Inspection:** Periodically check all fasteners and connections to ensure they remain tight. Re-tighten if necessary.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the wood finish.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Cabinet feels wobbly or unstable.	Loose fasteners; uneven floor; anti-tipping device not installed.	Tighten all screws and cam locks. Ensure the cabinet is on a level surface. Install the anti-tipping device as per instructions.
Doors do not close properly or are misaligned.	Hinges are loose or incorrectly installed; magnetic catches are misaligned.	Check and tighten hinge screws. Adjust hinge position if needed. Ensure magnetic catches are aligned with the metal plates on the doors.
Difficulty during assembly.	Incorrect part orientation; missing hardware.	Review the assembly diagrams and ensure parts are oriented correctly. Verify all hardware is present against the parts list. Contact customer service for missing parts.

SPECIFICATIONS

Feature	Detail
Brand	JOINICE
Model Number	FU8429
Color	Distressed Blue
Product Dimensions	13.8"D x 31.5"W x 47.2"H
Item Weight	56 Pounds
Material	Solid Fir Wood Frame, MDF with Fir Wood Veneers
Weight Limit (Top)	100 Pounds
Weight Limit (Shelves)	22 Pounds per shelf
Number of Shelves	2 (creating 3 compartments)
Special Feature	Anti-Tipping Device Included
Assembly Required	Yes

WARRANTY AND SUPPORT

For any quality problems, assembly issues, or missing parts, please contact JOINICE customer service. Our dedicated team is available to assist you.

Refer to your purchase documentation for specific warranty details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DJJVZCM5>

More documents and user manuals: **<https://manuals.plus/>**