Dyson HS08

Dyson Airwrap i.d. Multi-Styler and Dryer Straight+Wavy HS08 User Manual

Model: HS08

Important Safety Information

Please read all safety instructions carefully before using your Dyson Airwrap i.d. Multi-Styler and Dryer. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Water and Flammable Materials:** Keep the appliance away from water and flammable materials. Do not use near bathtubs, showers, basins, or other vessels containing water.
- **Skin Contact:** Avoid direct contact with hot surfaces of the appliance to prevent burns. Allow attachments to cool before handling or changing.
- **Power Supply:** Ensure the voltage specified on the appliance corresponds to your local mains voltage before connecting.
- **Children and Persons with Reduced Capabilities:** This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- **Maintenance:** Do not attempt to repair or disassemble the appliance yourself. Refer all servicing to qualified service personnel.
- **Cord Care:** Do not pull, twist, or wrap the power cord around the appliance. Inspect the cord regularly for damage.

What's in the Box

Your Dyson Airwrap i.d. Multi-Styler and Dryer package includes the following components:

- Dyson Airwrap i.d. Multi-Styler and Dryer (Main Unit)
- 40mm Airwrap Long Barrel

- Conical Airwrap Barrel
- Soft Smoothing Brush
- Large Round Volumising Brush
- Filter Cleaning Brush
- Dryer + Flyaway Smoother
- Fast Dryer
- Storage Case (Strawberry Bronze/Blush Pink)

Image: The Dyson Airwrap i.d. Multi-Styler and Dryer packaging, displaying the main unit and various styling attachments neatly arranged within the box.

Product Overview

The Dyson Airwrap i.d. Multi-Styler and Dryer is engineered for various hair types and styles, offering drying, curling, shaping, and smoothing functions without extreme heat. It features intelligent heat control, measuring air temperature over 40 times a second to prevent heat damage. This model is Bluetooth-enabled, allowing for enhanced control and personalized styling sequences via the MyDyson app.

Image: The Dyson Airwrap i.d. Multi-Styler and Dryer, presented in its retail packaging, showcasing the device and its core functionalities like "Dry. Curl. Shape. Smooths and hide flyaways."

Setup

Initial Setup

1. Unpack all components from the storage case.
2. Ensure the filter is clean and properly seated at the base of the main unit.
3. Plug the power cord into a suitable electrical outlet (220-240V).

Attaching Accessories

To attach any accessory, align the attachment with the main unit's top and push it firmly until it clicks into place. To remove, pull the attachment away from the main unit while holding the main unit securely.

Operating Instructions

Powering On/Off

Slide the power switch located on the handle to turn the device ON or OFF.

Temperature and Speed Settings

The device features 3 heat settings and 3 speed settings. Use the dedicated buttons on the handle to adjust these settings according to your hair type and desired style.

Using the Attachments

Each attachment is designed for specific styling needs:

- **40mm Airwrap Long Barrel:** Ideal for creating voluminous curls and waves, especially on longer hair.
- **Conical Airwrap Barrel:** Designed for creating looser, more relaxed curls and waves.
- **Soft Smoothing Brush:** Used to smooth and control frizzy hair, creating a sleek finish.
- **Large Round Volumising Brush:** Adds body and shape to hair, creating volume from the roots.
- **Dryer + Flyaway Smoother:** Dries hair quickly and then can be used to smooth down flyaways for a polished look.
- **Fast Dryer:** Provides rapid drying for damp hair before styling.

Bluetooth Connectivity and MyDyson App

The Dyson Airwrap i.d. is Bluetooth-enabled. Download the MyDyson app on your smartphone to connect your device. The app allows you to:

- Access the one-touch i.d. curl technology for programmed curl sequences.
- Receive personalized styling tips and tutorials.
- Monitor device usage and maintenance reminders.

Follow the in-app instructions for pairing your device and utilizing its smart features.

Maintenance and Care

Cleaning the Filter

Regular cleaning of the filter is essential for optimal performance. Use the provided filter cleaning brush to gently remove any hair or dust buildup from the filter cage at the base of the main unit. Clean the filter regularly, especially if you notice reduced airflow.

General Cleaning

- Ensure the device is unplugged and cool before cleaning.
- Wipe the main unit and attachments with a soft, damp cloth. Do not use abrasive cleaners or immerse the device in water.
- Remove any hair tangled in the brushes or barrels.

Storage

Store your Dyson Airwrap i.d. Multi-Styler and Dryer and its attachments in the provided storage case to protect them from dust and damage when not in use.

Troubleshooting

If you encounter any issues with your Dyson Airwrap i.d., refer to the table below for common problems and their solutions.

Problem	Possible Cause / Solution
Device not turning on.	Ensure the power cord is securely plugged into a working electrical outlet. Check for power outages.
Reduced airflow or device overheating.	The filter may be blocked. Clean the filter thoroughly using the provided brush.
Styling attachments not working effectively (e.g., curls not holding).	Ensure hair is damp, not soaking wet or completely dry, for optimal styling with Airwrap barrels. Use the correct attachment for your desired style and hair type. Ensure the attachment is securely clicked into place.
Bluetooth connection issues.	Ensure Bluetooth is enabled on your smartphone. Make sure the device is within range of your phone. Try restarting both the device and your phone. Re-pair the device through the MyDyson app.

Technical Specifications

Feature	Value
Model Number	HS08
Power	1300 Watts
Voltage	220-240V
Air Flow	13.5 l/s
Dimensions (L x W x H)	4.1 x 4.8 x 27.2 cm
Weight	0.595 kg
Heat Settings	3
Speed Settings	3
Special Features	Bluetooth Enabled, Intelligent Heat Control, Replaceable Brush Head
Material	Plastic
Color	Strawberry Bronze/Blush Pink

Warranty and Support

For information regarding your product's warranty, please refer to the warranty card included in your product packaging or visit the official Dyson website. For technical support, troubleshooting assistance beyond this manual, or to purchase replacement parts, please contact Dyson Customer Service or visit their online support portal.
Note: Warranty terms and conditions may vary by region. Please retain your proof of purchase for warranty claims.