

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Audiocrazy](#) /
- › [Audiocrazy Portable Radio User Manual](#)

Audiocrazy 42062bcb-2c81-41f9-abbd-3beac60ee015

Audiocrazy Portable AM/FM Radio with Bluetooth User Manual

Model: 42062bcb-2c81-41f9-abbd-3beac60ee015

1. INTRODUCTION

Thank you for choosing the Audiocrazy Portable AM/FM Radio with Bluetooth. This device offers versatile listening options, including traditional AM/FM radio, Bluetooth streaming, and multiple power supply methods. It features a clear digital LCD display, alarm clock, and sleep timer functions, making it suitable for various indoor and outdoor environments.



Figure 1: Front view of the Audiocrazy Portable AM/FM Radio.

2. SAFETY INFORMATION

- Do not expose the device to rain, moisture, or extreme temperatures.
- Avoid dropping or subjecting the device to strong impacts.
- Do not disassemble or attempt to repair the device yourself. Refer to qualified service personnel.
- Keep out of reach of children.
- Use only the specified power adapter and battery types.

3. PRODUCT OVERVIEW

The Audiocrazy Portable Radio combines multiple functionalities in one compact unit.

5-in-1 Digital AM FM Radio

One item meets all your indoor and outdoor essentials.

-  **AM/FM Radio**
-  **Alarm Clock**
-  **Bluetooth V5.0**
-  **Sleep Timer**
-  **3 Mode Power**



Figure 2: Key features of the radio including AM/FM, Alarm Clock, Bluetooth, Sleep Timer, and multiple power options.

Controls and Display:

- **LCD Display:** Shows time, frequency, mode, and battery status. Features a backlight for low-light visibility.
- **Volume Knob:** Adjusts audio output level.
- **Tuning Knob:** Used for manual station tuning.
- **Mode Switch (FM/BT/AM/CLOCK):** Selects the operating mode.
- **ALL/SET/TIME/SET Button:** For setting time and alarm.
- **BT //PP Button:** Bluetooth pairing, Play/Pause.
- **SNOOZE Button:** Snooze alarm.
- **HOUR / MIN Buttons:** Adjust hour and minute settings.
- **Telescopic Antenna:** For FM and AM reception.

Portable And Simple Operation



Large LCD Display



Big Tuning Knob



AM/FM/BT/Clock Switch



Figure 3: Detailed view of the radio's user-friendly controls and large LCD display.

4. SETUP

4.1 Power Supply Options

Your Audiocrazy radio offers three convenient ways to power the device:

- **Built-in Rechargeable Battery:** The radio comes with an 1800mAh built-in lithium-ion battery. Connect the included AC adapter to charge the battery. A full charge provides up to 10 hours of use.
- **AC Power:** For continuous use indoors, connect the included AC adapter directly to a wall outlet.
- **4*D Cell Batteries (Not Included):** For extended portable use, insert four (4) D-cell batteries into the battery compartment on the back of the unit. Ensure correct polarity.

3 Ways of Power Supply

No need to worry about running out of battery



Figure 4: Illustration of the three power supply methods for the radio.

4.2 Antenna Setup

For optimal FM and AM reception, extend the telescopic antenna fully. Adjust its direction for the best signal clarity.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off and Volume Control

Rotate the **VOLUME** knob clockwise to turn the radio on and increase the volume. Rotate counter-clockwise to decrease volume and turn the radio off.

5.2 AM/FM Radio Tuning

Slide the mode switch to **FM** or **AM**. Extend the telescopic antenna. Rotate the **TUNING** knob to find your desired station. The digital display will show the frequency.



Figure 5: The radio's telescopic antenna helps achieve strong and clear reception.

The radio features updated DSP technology for strong and stable reception across AM (520-1710kHz) and FM (87-108MHz) bands.

Your browser does not support the video tag.

Video 1: Demonstrates the automatic search function and strong reception capabilities of the radio.

5.3 Bluetooth Pairing

Slide the mode switch to **BT**. The display will show "bt" and the radio will enter pairing mode. On your Bluetooth-enabled device (e.g., smartphone), search for "Audiocrazy Radio" and select it to connect. Once connected, you can stream audio wirelessly.



Wireless Bluetooth 5.0 Fast Connection



Figure 6: The radio in Bluetooth mode, ready for pairing with a mobile device.

5.4 Setting Time and Alarm

Slide the mode switch to **CLOCK**.

- **To Set Time:** Press and hold the **ALL/SET/TIME/SET** button until the hour digits flash. Use the **HOUR** and **MIN** buttons to adjust. Press **ALL/SET/TIME/SET** again to confirm. You can switch between 12H/24H format by pressing the **ALL/SET/TIME/SET** button briefly when the time is displayed.
- **To Set Alarm:** Press the **ALL/SET/TIME/SET** button once (short press) to enter alarm setting mode. The alarm icon will flash. Use the **HOUR** and **MIN** buttons to set the alarm time. Press **ALL/SET/TIME/SET** again to confirm. To activate/deactivate the alarm, press the **ALL/SET/TIME/SET** button briefly when the alarm time is displayed.
- **Snooze Function:** When the alarm sounds, press the **SNOOZE** button to temporarily silence it. The alarm will sound again after a few minutes.



Figure 7: The radio supports both alarm clock and sleep timer functions.

5.5 Sleep Timer

The radio features an auto-off timer (0-90 minutes). To set the sleep timer, press the **SLEEP** button repeatedly to cycle through the available timer durations. The radio will automatically turn off after the selected time.

Large Number Backlit Display

Show Time/Station Information



12 Hours Format



24 Hours Format



Station Information

Figure 8: The clear LCD display shows time in 12H/24H format and radio station information.

6. MAINTENANCE

- **Cleaning:** Wipe the radio with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Care:** If using D-cell batteries, remove them if the radio will not be used for an extended period to prevent leakage. For the built-in rechargeable battery, charge it regularly to maintain its lifespan.
- **Storage:** Store the radio in a cool, dry place away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Batteries are dead or incorrectly inserted; AC adapter not connected or faulty.	Replace D-cell batteries, check polarity. Ensure AC adapter is securely plugged in. Charge built-in battery.

Problem	Possible Cause	Solution
Poor radio reception	Antenna not extended; weak signal area; interference.	Fully extend and adjust the telescopic antenna. Move the radio to a location with better signal. Move away from other electronic devices.
Bluetooth not connecting	Radio not in BT mode; device too far; previously paired device connected.	Ensure radio is in BT mode. Move Bluetooth device closer to the radio. Disconnect from other Bluetooth devices.
No sound	Volume too low; mute activated (if applicable); faulty speaker.	Increase volume. Check if any mute function is active. If problem persists, contact support.

8. SPECIFICATIONS

- **Brand:** Audiocrazy
- **Model Number:** 42062bcb-2c81-41f9-abbd-3beac60ee015
- **Product Dimensions:** 9.4 x 2.95 x 6.93 inches
- **Item Weight:** 2.29 pounds
- **Power Source:** AC Power / DC Battery (4*D Cell) / Built-in 1800mAh Rechargeable Battery
- **Tuner Technology:** AM/FM
- **Radio Bands Supported:** AM (520-1710kHz), FM (87-108MHz)
- **Connectivity Technology:** Bluetooth 5.0
- **Included Components:** Radio, Owner's Manual, Power Adapter

9. WARRANTY AND SUPPORT

Audiocrazy products typically come with a **12-month warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use.

For technical support, warranty claims, or any questions regarding your Audiocrazy Portable Radio, please contact our customer service team. Refer to the contact information provided on the product packaging or the official Audiocrazy website.

Please have your model number (42062bcb-2c81-41f9-abbd-3beac60ee015) and purchase date ready when contacting support.



© 2024 Audiocrazy. All rights reserved.

Related Documents - 42062bcb-2c81-41f9-abbd-3beac60ee015



[AC-RC87BT BT/AM/FM 2-Band Radio Instruction Manual](#)

Instruction manual for the AC-RC87BT BT/AM/FM 2-Band Radio, covering safety precautions, operation, troubleshooting, and specifications.