



[Manuals.plus](#) /

> [ODK](#) /

> ODK 80x40cm Small Computer Desk User Manual

## ODK RE-B03

# ODK 80x40cm Small Computer Desk User Manual

Model: RE-B03

## INTRODUCTION

---

Thank you for choosing the ODK 80x40cm Small Computer Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read it thoroughly before beginning assembly and keep it for future reference.



Image: The ODK 80x40cm Small Computer Desk, showcasing its compact design and integrated headphone hook.

## SAFETY INFORMATION

---

Please observe the following safety precautions to prevent injury or damage to the product:

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the desk on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly, as this may damage the threads.
- Keep small parts away from children to avoid choking hazards.
- Do not exceed the maximum weight capacity of the desk (refer to Specifications section).
- Place the desk on a level surface to ensure stability.

## PACKAGE CONTENTS

---

Verify that all components listed below are included in your package:

- Desktop Panel (1)
- Left Leg Frame (1)
- Right Leg Frame (1)
- Crossbars (2)
- Headphone Hook (1)
- Adjustable Feet (4)
- Assembly Hardware (Screws, Allen Wrench)
- Instruction Manual (This document)

## SETUP & ASSEMBLY

Assembly is straightforward and typically takes about 25 minutes. Follow these steps carefully:

# Snelle en Eenvoudige Montage



Image: Visual guide for quick and easy assembly of the desk.

### 1. Step 1: Assemble Leg Frames

Attach the two crossbars to the leg frames. Ensure they are securely fastened but do not fully tighten the screws yet.

### 2. Step 2: Attach Desktop

Carefully align the assembled leg frame structure with the pre-drilled holes on the underside of the desktop panel. Insert and partially tighten the screws.

### 3. Step 3: Secure All Connections

Once all screws are in place, gradually tighten all screws using the provided Allen wrench until the desk is stable. Avoid overtightening.

#### 4. Step 4: Install Headphone Hook & Adjustable Feet

Screw the headphone hook into the designated hole on the side of the desk. Attach the adjustable feet to the bottom of each leg.




Image: Detail of the adjustable feet, allowing for stability on uneven floors.

Use the adjustable feet to level the desk on uneven floors, ensuring maximum stability.

## OPERATING INSTRUCTIONS

The ODK computer desk is designed for versatile use in various settings. Here are some key operational aspects:

- **Weight Capacity:** The desk is built with a sturdy metal frame and can support up to 50 kg (approximately 110 lbs) evenly distributed on the desktop. Do not exceed this limit.
- **Headphone Hook:** Utilize the integrated headphone hook to keep your headphones conveniently stored and your workspace tidy.
- **Versatile Placement:** Its compact size makes it ideal for small apartments, dorm rooms, bedrooms, living rooms, or dedicated home office spaces.



Image: Desk dimensions and maximum weight capacity of 50 KG.



Image: The desk integrated into a modern gaming or work setup.



Image: The desk fitting perfectly in a bedroom, highlighting its suitability for small spaces.

## MAINTENANCE

To ensure the longevity and appearance of your ODK desk, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. For stubborn marks, use a mild soap solution and dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** Clean up spills immediately to prevent staining or damage to the surface.
- **Heat Protection:** Use coasters or protective pads under hot items to prevent heat damage to the desktop.
- **Regular Checks:** Periodically check and retighten all screws to maintain stability.

## TROUBLESHOOTING

If you encounter any issues with your ODK desk, refer to the table below for common problems and solutions:

Problem	Possible Cause	Solution
Desk is wobbly	Screws are loose; uneven floor.	Tighten all assembly screws. Adjust the leveling feet on the bottom of the legs.

Problem	Possible Cause	Solution
Parts do not align during assembly	Incorrect orientation of parts; screws overtightened prematurely.	Review the assembly instructions and ensure parts are oriented correctly. Loosen screws slightly, align parts, then retighten.
Scratches on surface	Sharp objects; abrasive cleaning.	Use protective mats for sharp objects. Clean with soft cloth and mild solutions only. Minor scratches may be buffed with appropriate furniture polish.

## SPECIFICATIONS

Feature	Detail
Brand	ODK
Model Number	RE-B03
Dimensions (L x W x H)	80 cm x 40 cm x 74 cm (31.5 in x 15.7 in x 29.1 in)
Item Weight	5.7 kg (12.5 lbs)
Color	Black
Shape	Rectangular
Material Type	Alloy Steel (Frame), Engineered Wood (Desktop)
Finish Type	Powder Coated
Special Feature	Integrated Headphone Hook, Adjustable Feet
Maximum Weight Capacity	50 kg (110 lbs)

## WARRANTY INFORMATION

ODK products are manufactured to high-quality standards. This product comes with a limited warranty against defects in materials and workmanship from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by improper assembly, misuse, neglect, accidents, or normal wear and tear.

## CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing or damaged parts, please contact ODK customer support. For the most up-to-date contact information, please visit the official ODK website or refer to your purchase documentation.

*Thank you for choosing ODK.*