

[Manuals.plus](#) /

› [CHOEZON](#) /

› CHOEZON Bathroom Wall Cabinet MBBL Instruction Manual

CHOEZON MBBL

CHOEZON Bathroom Wall Cabinet MBBL Instruction Manual

Model: MBBL

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your CHOEZON Bathroom Wall Cabinet, Model MBBL. Please read all instructions carefully before beginning assembly and retain this manual for future reference.





Image: The CHOEZON Bathroom Wall Cabinet (Model MBBL) in Black and Walnut finish, featuring dual doors, an open partition, and a towel bar. Dimensions are 39 x 18 x 62 cm.

SAFETY INFORMATION

For safe use of your cabinet, please observe the following:

- **Wall Mount Securely:** Ensure the cabinet is firmly mounted to a suitable wall structure to prevent falling. Use appropriate hardware for your wall type.
- **Do Not Overload:** Avoid placing excessive weight on shelves or the towel bar to prevent structural damage or collapse.
- **Keep Away from Water:** While suitable for bathrooms, avoid direct and prolonged exposure to water to maintain material integrity.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Cabinet Panels (Engineered Wood)
- Hardware Set (Screws, dowels, hinges, handles, wall anchors)
- Adjustable Shelf
- Towel Bar (Iron)
- Assembly Instructions

SETUP AND ASSEMBLY

Follow the included assembly instructions carefully. It is recommended to have a second person assist with wall mounting for stability and safety.

1. **Unpack Components:** Lay out all parts on a clean, soft surface to prevent scratches.
2. **Assemble Cabinet Frame:** Connect the side panels, top, and bottom panels using the provided hardware. Ensure all connections are secure.
3. **Install Back Panel:** Attach the back panel to the assembled frame.
4. **Attach Doors:** Secure the doors to the cabinet frame using the hinges. Adjust hinges as needed for proper alignment.
5. **Install Handles:** Attach the decorative handles to the cabinet doors.
6. **Insert Adjustable Shelf:** Place the adjustable shelf supports at the desired height within the cabinet and insert the shelf.
7. **Attach Towel Bar:** Secure the towel bar to the designated area on the bottom of the cabinet.
8. **Wall Mounting:**
 - Choose a suitable location on a sturdy wall.
 - Mark the drilling points accurately using a level.
 - Drill pilot holes and insert wall anchors if necessary.
 - With assistance, lift the cabinet and secure it to the wall using the provided mounting hardware. Ensure it is level and stable.



Image: An interior view of the cabinet demonstrating the adjustable shelf feature, allowing customization of storage space.



Image: Diagram illustrating the dimensions of the CHOEZON Bathroom Wall Cabinet: 39 cm width, 18 cm depth, and 62 cm height.

OPERATING INSTRUCTIONS

The CHOEZON Bathroom Wall Cabinet is designed for convenient storage in various rooms.

- **Dual-Door Cabinet:** Use the two doors to access the enclosed storage space. The adjustable shelf inside allows for customized organization of toiletries, medicines, or other items.
- **Open Partition:** The open shelf below the main cabinet provides easy access to frequently used items or decorative displays.
- **Towel Bar:** Utilize the integrated towel bar for hanging hand towels or small cloths, promoting quick drying and organization.



Image: The wall cabinet installed above a sink in a bathroom, showcasing its use for storing various bathroom essentials.



Image: The wall cabinet mounted in a kitchen, demonstrating its versatility for storing spices or small kitchen items.

MAINTENANCE

Proper care will extend the life and appearance of your cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Spills:** Promptly wipe up any spills to prevent moisture damage to the engineered wood.
- **Hardware Check:** Periodically check all screws and connections to ensure they remain tight. Tighten if necessary.
- **Avoid Excessive Moisture:** While designed for bathrooms, ensure good ventilation to prevent prolonged exposure to high humidity.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Cabinet parts do not align during assembly.	Incorrect part orientation or manufacturing defect.	Double-check the assembly instructions for correct part orientation. If parts still do not align, contact CHOEZON customer support with details and photos of the issue.
Cabinet feels unstable after wall mounting.	Improper wall anchors, insufficient tightening of screws, or unsuitable wall material.	Ensure the cabinet is mounted into wall studs or appropriate heavy-duty anchors for your wall type. Tighten all mounting screws securely. If unsure, consult a professional.
Doors do not close properly or are misaligned.	Hinge adjustment needed or loose hinge screws.	Adjust the hinge screws to align the doors. Refer to the assembly instructions for hinge adjustment details. Tighten any loose hinge screws.

SPECIFICATIONS

Feature	Detail
Brand	CHOEZON
Model Number	MBBL
Color	Black and Walnut
Material	Engineered Wood, Iron
Product Dimensions (D x W x H)	18D x 39W x 62H centimeters
Item Weight	6.35 kg
Mounting Type	Wall Mount
Number of Doors	2
Number of Shelves	1 (Adjustable)
Special Features	Open storage, Adjustable shelves, Towel bar
Recommended Uses	Bathroom storage, Living Room, Kitchen

WARRANTY AND SUPPORT

For warranty information or product support, please contact CHOEZON customer service. Details regarding specific warranty periods and terms are typically provided with your purchase documentation or can be obtained directly from the manufacturer.

If you encounter any issues or have questions regarding your CHOEZON Bathroom Wall Cabinet, please reach out to the manufacturer for assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question