

[Manuals.plus](#) /

› [XIAOMI](#) /

› Xiaomi 65" S Mini TV (Model L65MA-SPLEU) User Manual

XIAOMI L65MA-SPLEU

Xiaomi 65" S Mini TV User Manual

Model: L65MA-SPLEU

1. SETUP AND INSTALLATION

This section guides you through the initial setup of your Xiaomi 65" S Mini TV, including unpacking, stand installation, and connecting essential components.

1.1 Unpacking the TV

Carefully remove the TV and all accessories from the packaging. Retain the packaging materials for future transport or service needs.



Image: Front view of the Xiaomi 65" S Mini TV. This image shows the television's sleek, borderless design and the display quality.

1.2 Stand Installation

If you are not wall-mounting the TV, attach the two included brackets to the bottom of the television using the provided screws. Ensure the stand is securely fastened before placing the TV on a stable, flat surface.

1.3 Wall Mounting

For wall mounting, use a VESA compatible bracket (not included) that supports a 300 x 300 mm pattern. Consult a professional for wall mounting to ensure safety and proper installation.

1.4 Connecting Peripherals

Connect your devices such as gaming consoles, sound systems, or set-top boxes to the available ports. The TV features multiple connectivity options including HDMI, USB, Ethernet, and wireless Bluetooth and Wi-Fi.



Image: Side view of the Xiaomi 65" S Mini TV, highlighting the various input and output ports for connecting external devices.

1.5 Remote Control Setup

Insert two AAA batteries into the 360° Bluetooth Remote Control. The remote will automatically pair with the TV upon initial power-on. If pairing issues occur, refer to the troubleshooting section.

1.6 Initial Power On and Google TV Setup

Connect the power cable to the TV and a power outlet. Press the power button on the remote control. Follow the on-screen instructions to complete the initial Google TV setup, including network connection, Google account login, and channel scanning.

2. OPERATING INSTRUCTIONS

This section details how to navigate and utilize the features of your Xiaomi 65" S Mini TV.

2.1 Google TV Interface Navigation

Use the directional pad and select button on your remote control to navigate the Google TV home screen. Access apps, settings, and content recommendations.

2.2 Smart Features

- **Built-in Google Assistant:** Use voice commands via the remote control for search, control, and information.
- **Chromecast built-in & AirPlay 2:** Cast content directly from your compatible smartphone, tablet, or computer to the TV.
- **Pre-installed Apps:** Access popular streaming services like Netflix, Prime Video, and YouTube directly from the home screen.
- **Smart Home Control:** Manage compatible smart home devices through the TV interface.

2.3 Picture Settings

Access the picture settings menu to customize your viewing experience. Key features include:

- **Display Technology:** QD-Mini LED for enhanced contrast and brightness.
- **Resolution:** Native 4K (3840 x 2160 pixels) for sharp images.
- **Refresh Rate:** Up to 144Hz for smooth motion, especially beneficial for gaming.
- **Brightness:** Maximum 1200 Nits for vivid highlights.
- **HDR Support:** Dolby Vision IQ for dynamic and accurate HDR content.
- **Local Dimming:** Advanced backlight control for deeper blacks and improved contrast.
- **Viewing Angle:** 178 degrees for consistent picture quality from various positions.

2.4 Sound Settings

Adjust audio output and sound modes through the sound settings menu.

- **Dolby Atmos:** Immersive surround sound experience.
- **5.1 Surround Sound:** Integrated audio system for rich sound.

2.5 Gaming Features

The TV is optimized for gaming with:

- **144Hz High Refresh Rate:** Reduces motion blur for fluid gameplay.
- **MEMC 4K at 120Hz:** Motion enhancement technology for smoother fast-paced scenes.



ENERGY



XIAOMI

L65MA-SPLEU




111 kWh/1000h

ABCDEF**G**



111 kWh/1000h



2019/2013

Image: A close-up of the A73 processor and memory (32GB storage, 3GB RAM) that powers the TV's smart features and performance.

3. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your TV.

3.1 Cleaning the TV

- **Screen:** Gently wipe the screen with a soft, dry, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a screen-specific cleaning solution. Do not spray liquid directly onto the screen.
- **Body:** Wipe the TV frame and stand with a soft, dry cloth. Avoid abrasive cleaners or solvents.

3.2 Software Updates

The Google TV operating system will periodically receive software updates. Ensure your TV is connected to the internet to receive these updates, which can improve performance and add new features. You can check for updates manually in the TV's settings menu.

4. TROUBLESHOOTING

This section addresses common issues you might encounter with your TV.

4.1 No Power / TV Does Not Turn On

- Check if the power cable is securely connected to both the TV and the power outlet.
- Ensure the power outlet is functioning by testing it with another device.
- Try pressing the power button on the TV itself, if available, or on the remote control.
- Verify that the remote control batteries are not depleted.

4.2 No Picture or Poor Picture Quality

- Ensure the correct input source is selected (e.g., HDMI 1, HDMI 2).
- Check all cable connections between the TV and external devices.
- Adjust picture settings such as brightness, contrast, and color.
- If using an antenna, check its connection and position.

4.3 No Sound or Poor Sound Quality

- Check the volume level and ensure the TV is not muted.
- Verify audio cable connections to external sound systems.
- Adjust sound settings in the TV menu.
- If using external speakers, ensure they are powered on and correctly configured.

4.4 Remote Control Not Responding

- Replace the batteries in the remote control.
- Ensure there are no obstructions between the remote and the TV.
- If the remote is Bluetooth, try re-pairing it through the TV's settings menu.

4.5 TV Takes Time to Initiate

Some users may experience a slight delay during TV startup. This is often normal as the Google TV operating system loads. Ensure the TV's software is up to date, as updates can sometimes optimize startup times.

5. SPECIFICATIONS

Detailed technical specifications for the Xiaomi 65" S Mini TV (Model L65MA-SPLEU).

Feature	Specification
Model Name	Xiaomi TV S Mini 65 2025
Model Number	L65MA-SPLEU
Screen Size	65 Inches (165 cm)
Display Technology	Mini LED, QLED
Resolution	4K (3840 x 2160 pixels)
Refresh Rate	144 Hz
Maximum Brightness	1200 Nits
HDR Format Supported	Dolby Vision IQ
Viewing Angle	178 Degrees
Operating System	Google TV
Memory Storage Capacity	32 GB
Integrated Surround Sound	Dolby Atmos, 5.1 surround sound
HDMI Ports	3
USB Ports	1 (Total USB 3.0 Ports: 1)
Connectivity Technology	Bluetooth 5.2, Ethernet, Wi-Fi
Screen Mirroring	AirPlay 2, Google Cast
Product Dimensions (D x W x H)	39.1D x 144.6W x 90.4H centimetres
Item Weight	18 Kilograms (18.3 Kilograms without stand)
Power Consumption	75 Watts
VESA Mount Standard	300 x 300 mm
Included Components	Television, 360° Bluetooth Remote Control, Power Cable, 2 brackets + bag of screws, User manual and warranty cards




Image: Energy efficiency label for the Xiaomi TV S Mini 65, indicating its energy class and consumption.
For more detailed product information, refer to the EPREL database: <https://eprel.ec.europa.eu/qr/2082807>



Image: Detailed product information sheet, providing a comprehensive list of technical parameters and specifications.
For more detailed product information, refer to the EPREL database: <https://eprel.ec.europa.eu/qr/2082807>

6. WARRANTY AND SUPPORT

Information regarding your product's warranty and how to obtain customer support.

6.1 Limited Warranty

Your Xiaomi 65" S Mini TV comes with a limited warranty. Please refer to the 'User manual and warranty cards' included in the box for specific terms, conditions, and duration of the warranty in your region.

6.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact Xiaomi's specialized customer support. Contact details can typically be found on the official Xiaomi website or within the warranty documentation provided with your TV.

You can also visit the official Xiaomi store on Amazon for additional resources and support:[Xiaomi Store](#)

© 2025 Xiaomi. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

