realme RMX3933

realme Note 60 Dual SIM 4G Smartphone User Manual

Model: RMX3933 | Brand: realme

1. Introduction

This manual provides detailed instructions for the realme Note 60 Dual SIM 4G Smartphone. Designed for optimal performance and durability, the realme Note 60 features a vibrant 6.74-inch 90Hz display, a powerful 32MP camera, and a long-lasting 5000mAh battery. It is also built with IP64 dust and splash resistance for enhanced protection. Please read this manual thoroughly to ensure proper use and maintenance of your device.



Image: Front and back view of the realme Note 60 smartphone, showcasing its sleek design and dual camera setup.

2. What's in the Box

Upon unboxing your realme Note 60, please verify that all the following items are included:

- realme Note 60 Smartphone
- USB Type-C Cable

- 10W Power Adapter
- SIM Ejector Tool
- Quick Start Guide
- Safety Information and Warranty Card

3. Setup Guide

3.1. Inserting SIM Cards and MicroSD Card

The realme Note 60 supports Dual SIM functionality and features a dedicated microSD card slot for expandable storage up to 1TB.

1. Locate the SIM tray on the side of the device.
2. Insert the SIM ejector tool into the small hole next to the tray and push gently until the tray pops out.
3. Place your Nano-SIM cards and/or microSD card into the designated slots on the tray, ensuring the gold contacts face downwards.
4. Carefully reinsert the tray into the phone until it clicks into place.

3.2. Initial Charging

Before first use, it is recommended to fully charge your realme Note 60. Use the provided 10W power adapter and USB Type-C cable.

- Connect the USB Type-C cable to the charging port at the bottom of the phone.
- Connect the other end of the cable to the power adapter, then plug the adapter into a power outlet.
- The charging indicator will appear on the screen.



Image: Illustration of the realme Note 60 being charged, highlighting its 5000mAh massive battery and long endurance.

3.3. Powering On/Off

- **To Power On:** Press and hold the Power button (located on the right side) until the realme logo appears.
- **To Power Off:** Press and hold the Power button until the power menu appears, then select 'Power off'.
- **To Restart:** Press and hold the Power button until the power menu appears, then select 'Restart'.

3.4. Initial Setup Wizard

Upon first power-on, the device will guide you through the initial setup process. This includes selecting your language, connecting to Wi-Fi, setting up your Google account, and configuring security features like the side-mounted fingerprint sensor.

4. Key Features

The realme Note 60 is equipped with a range of features designed to enhance your mobile experience:

- **Expansive 6.74" 90Hz Display:** Enjoy vibrant visuals and smooth scrolling with a 90Hz IPS LCD screen, offering 560 nits brightness for clear viewing in any lighting.
- **Ample Storage & Performance:** Features 128GB storage and 4GB RAM, powered by the efficient Unisoc Tiger T612 chipset for seamless multitasking and app performance.
- **Powerful 32MP Main Camera:** Capture detailed photos and videos with the 32MP wide-angle lens, enhanced by LED flash and panorama mode.
- **Durable Build with IP64 Rating:** Dust and splash-resistant design with a die-cast aluminum chassis and reinforced glass for enhanced durability.
- **Long-Lasting 5000mAh Battery:** Stay powered all day with the robust battery, complemented by 10W wired charging for reliable use.
- **Android 14 with Realme UI 5.0:** Experience a user-friendly interface with the latest Android features and Realme's optimized UI enhancements.
- **Dual SIM & Dedicated MicroSD Slot:** Effortlessly manage personal and work numbers, plus expand storage up to 1TB with a dedicated microSD card slot.
- **Enhanced Connectivity:** Equipped with Wi-Fi dual-band, Bluetooth 5.0, GPS, and USB Type-C for versatile and reliable connections.
- **Convenient Features:** Side-mounted fingerprint sensor for quick and secure access, plus a 3.5mm headphone jack and loudspeaker for audio flexibility.



Image: Overview of key features such as dynamic RAM, ROM, powerful octa-core chipset, 32MP camera, and 90Hz Eye-Comfort Display.



Image: The realme Note 60 shown with water splashing, illustrating its IP64 Dust & Water Resistant capabilities.

5. Operating Instructions

5.1. Basic Navigation

- **Touchscreen Gestures:** Swipe up, down, left, or right to navigate through menus and screens. Tap to select items. Pinch in/out to zoom.
- **Home Screen:** Swipe left or right to access different home screen panels.
- **App Drawer:** Swipe up from the bottom of the home screen to access all installed applications.
- **Notification Panel:** Swipe down from the top of the screen to view notifications and quick settings.

5.2. Making Calls and Sending Messages

- **Calls:** Open the 'Phone' app, enter the number or select a contact, then tap the call icon.
- **Messages:** Open the 'Messages' app, tap the 'Start chat' button, enter the recipient's number or select a contact, then type your message.

5.3. Using the Camera

The 32MP main camera allows for high-quality photos and videos.

- Open the 'Camera' app.
- Swipe left or right to switch between modes (Photo, Video, Portrait, Panorama, etc.).
- Tap the shutter button to take a photo or start/stop video recording.
- Tap the camera switch icon to toggle between front and rear cameras.

5.4. Connecting to Wi-Fi and Bluetooth

- **Wi-Fi:** Go to Settings > Network & internet > Wi-Fi. Turn on Wi-Fi, select your desired network, and enter the password if prompted.
- **Bluetooth:** Go to Settings > Connected devices > Bluetooth. Turn on Bluetooth, then select a device from the 'Pair new device' list to connect.

6. Maintenance

6.1. Cleaning Your Device

- Use a soft, lint-free cloth to wipe the screen and body.
- Avoid using harsh chemicals, abrasive materials, or aerosol sprays.
- For stubborn smudges, slightly dampen the cloth with water.

6.2. Software Updates

Regularly check for and install software updates to ensure optimal performance, security, and access to new features.

- Go to Settings > About device > realme UI version.
- Tap 'Check for updates' and follow the on-screen instructions.

6.3. Battery Care

- Avoid extreme temperatures, as they can degrade battery life.
- Use only realme-approved chargers and cables.
- For long-term storage, charge the battery to around 50%.

6.4. Storage Management

To maintain smooth performance, regularly manage your device's storage.

- Delete unnecessary apps and files.
- Clear cache data for apps in Settings > Apps.
- Utilize cloud storage services for photos and videos.

7. Troubleshooting

Here are solutions to some common issues you might encounter:

Problem	Solution
Phone not turning on	Ensure the battery is charged. Press and hold the Power button for at least 10 seconds to force restart.
Screen is unresponsive	Force restart the device. If the issue persists, consider a factory reset (backup data first).
Cannot connect to Wi-Fi/Bluetooth	Toggle Wi-Fi/Bluetooth off and on. Restart your router for Wi-Fi. Forget and re-pair Bluetooth devices.
Battery drains quickly	Reduce screen brightness, close background apps, disable unnecessary features (GPS, Bluetooth, Wi-Fi when not in use). Check battery usage in Settings to identify power-hungry apps.
Apps crashing or freezing	Clear the app's cache and data (Settings > Apps). Update the app to the latest version. Reinstall the app.

8. Specifications

Detailed technical specifications for the realme Note 60 (Model: RMX3933):

Feature	Detail
Brand	realme
Model Number	RMX3933
Operating System	Android 14, Realme UI 5.0
Installed RAM Memory Size	4 GB
Memory Storage Capacity	128 GB
CPU Model	Cortex (Unisoc Tiger T612 chipset)
Product Dimensions	16.73 x 7.67 x 0.78 cm; 187 g
Batteries	1 A batteries required. (included)
Display	6.74" 90Hz IPS LCD, 560 nits brightness

Feature	Detail
Camera	32MP Wide-angle (Main)
Battery Capacity	5000mAh
Charging	10W Wired Charging
Durability	IP64 Dust & Splash Resistant
Connectivity	Wi-Fi Dual-band, Bluetooth 5.0, GPS, USB Type-C

9. Warranty and Support

9.1. Warranty Information

The realme Note 60 Smartphone comes with a 12-month manufacturer's warranty from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. Please retain your proof of purchase for warranty claims.

9.2. Customer Support

For further assistance, technical support, or warranty inquiries, please visit the official realme support website or contact their customer service. You can find contact details and FAQs on the realme official website.

Official realme Website: www.realme.com

© 2025 realme. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question