

[Manuals.plus](#) /

› [HOFSTEIN](#) /

› HOFSTEIN Bamako Wall Light H3813287 Instruction Manual

HOFSTEIN H3813287

HOFSTEIN Bamako Wall Light H3813287 Instruction Manual

1. INTRODUCTION

Thank you for purchasing the HOFSTEIN Bamako Wall Light, Model H3813287. This modern Up&Down luminaire is designed to provide ambient lighting with a stylish aesthetic. This manual contains important information regarding the safe installation, operation, and maintenance of your new wall light. Please read these instructions carefully before installation and retain them for future reference.



Image 1.1: The HOFSTEIN Bamako Wall Light installed, demonstrating its upward and downward light projection.

2. SAFETY INSTRUCTIONS

To ensure safe operation and prevent damage, please observe the following safety precautions:

- **Electrical Safety:** Installation must be performed by a qualified electrician in accordance with local wiring regulations. Always disconnect the main power supply before installation, maintenance, or bulb replacement.
- **Indoor Use Only:** This luminaire has an IP20 rating, indicating it is protected against solid objects larger than 12.5mm but has no protection against water. It is suitable for indoor use only (e.g., dining room, hallway, bedroom, living room).
- **Bulb Type:** Use only G9 bulbs with a maximum wattage of 33W. Do not exceed the specified wattage.
- **Handling:** Handle the glass and metal components with care to avoid breakage or injury.
- **Cleaning:** Only clean the fixture when it is switched off and cool. Use a soft, dry cloth.

3. PACKAGE CONTENTS

Please check that all components are present and undamaged before proceeding with installation:

- HOFSTEIN Bamako Wall Light Fixture (main unit)
- Mounting Bracket
- Mounting Hardware (screws, wall plugs)

- Instruction Manual

Note: A G9 bulb is **not included** and must be purchased separately.



Image 3.1: View of the disassembled wall light, showing the main fixture, mounting bracket, and small hardware components.

4. SPECIFICATIONS

Model	H3813287
Type	Wall Light (Up & Down Luminaire)
Dimensions (Fixture)	Width: 10.5 cm, Height: 8.5 cm, Diameter: 8 cm
Dimensions (Canopy/Base)	Width: 3.5 cm, Height: 7.5 cm, Length: 4.5 cm
Material (Fixture)	Metal
Material (Shade)	Glass, Metal
Color (Fixture)	Black
Color (Shade)	Chrome, Smoked Grey, Black

Bulb Socket	G9
Number of Bulbs	1 (not included)
Max Wattage per Bulb	33 Watt
Voltage	230 Volt
Dimmable	No (non-dimmable)
Protection Class	IP20
Switch Type	Integrated Toggle Switch



Image 4.1: Dimensional diagram of the HOFSTEIN Bamako Wall Light, indicating width, height, and depth measurements.

5. SETUP AND INSTALLATION

Important: Ensure the main power supply is disconnected at the circuit breaker before beginning installation.

1. **Prepare the Mounting Location:** Choose a suitable wall location. Mark the drilling points for the mounting bracket.
2. **Install Mounting Bracket:** Drill holes at the marked points and insert wall plugs if necessary. Secure the mounting bracket to the wall using the provided screws.
3. **Electrical Connection:** Carefully connect the household electrical wires to the luminaire's terminals. Ensure correct

polarity (Live, Neutral, Earth) according to local electrical codes. If unsure, consult a qualified electrician.

4. **Attach Fixture:** Align the wall light fixture with the mounting bracket and secure it using the provided screws. Ensure it is firmly attached to the wall.
5. **Insert Bulb:** Gently insert a G9 bulb (max 33W) into the socket. Do not overtighten.
6. **Restore Power:** Once installation is complete and all connections are secure, restore power at the circuit breaker.



Image 5.1: The Bamako Wall Light mounted on a wall, showcasing its modern design and light distribution in a room.

6. OPERATING INSTRUCTIONS

The HOFSTEIN Bamako Wall Light features an integrated toggle switch for easy operation.

- **Turning On/Off:** Locate the toggle switch on the side of the fixture's base. Flip the switch to the 'ON' position to illuminate the light. Flip it to the 'OFF' position to turn the light off.



Image 6.1: A detailed view of the integrated toggle switch, located on the side of the wall light's base.

7. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your wall light.

- **Cleaning:** Always disconnect power before cleaning. Use a soft, dry, lint-free cloth to wipe the metal and glass surfaces. Do not use abrasive cleaners, solvents, or polishes, as these can damage the finish.
- **Bulb Replacement:** Ensure the light is switched off and completely cool before attempting to replace the bulb. Carefully remove the old G9 bulb and insert a new one, ensuring it is securely seated.

8. TROUBLESHOOTING

If you encounter issues with your wall light, refer to the following common problems and solutions:

- **Light does not turn on:**
 - Check if the main power supply is connected and the circuit breaker is on.
 - Ensure the integrated toggle switch is in the 'ON' position.
 - Verify that the G9 bulb is correctly inserted and not faulty. Replace the bulb if necessary.
 - Check electrical connections for looseness (only by a qualified electrician).
- **Light flickers:**
 - Ensure the bulb is fully seated in the socket.

- Replace the bulb to rule out a faulty bulb.

If the problem persists after attempting these solutions, please contact HOFSTEIN customer support or a qualified electrician.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the purchase documentation or contact HOFSTEIN customer service directly. Keep your proof of purchase for any warranty claims.