

[Manuals.plus](#) /

› [Sourcefy](#) /

› Sourcefy 76386GT Drive Control Board Instruction Manual for Genie Boom Lift TMZ-50/30

Sourcefy TMZ-50/30

Sourcefy 76386GT Drive Control Board Instruction Manual

For Genie Boom Lift TMZ-50/30

1. INTRODUCTION

This manual provides essential information for the proper installation, operation, and maintenance of the Sourcefy 76386GT Drive Control Board. This board is designed as a replacement part for Genie Boom Lift models, specifically the TMZ-50/30. Adherence to these instructions is crucial for safe and efficient performance of the equipment.

2. SAFETY INFORMATION

Warning: Installation and maintenance of this component should only be performed by qualified personnel with experience in industrial electrical systems and heavy machinery. Failure to follow safety procedures can result in serious injury, death, or equipment damage.

- Always disconnect power to the equipment before attempting any installation, removal, or maintenance.
- Wear appropriate personal protective equipment (PPE).
- Refer to the original equipment manufacturer's (OEM) service manual for specific safety guidelines related to the Genie Boom Lift TMZ-50/30.
- Ensure all connections are secure and correctly polarized before restoring power.

3. PRODUCT OVERVIEW

The Sourcefy 76386GT Drive Control Board is a critical electronic component responsible for managing the drive functions of compatible Genie Boom Lifts. It is designed to ensure precise control and reliable operation. This part replaces P/N 48273 and is backward compatible.




Figure 1: Sourcefy 76386GT Drive Control Board. This image displays the blue circuit board with various electronic components, connectors, and labels such as "JOYSTICK", "DRIVE V.1.4", "EXTEND", "AUTO", "RETRACT", "ALARM", and "PROGRAM J7".

4. SPECIFICATIONS

Feature	Detail
Product Dimensions	5.5 x 3 x 1.3 inches
Item Weight	2.08 ounces
Manufacturer	Sourcefy
Model Number	TMZ-50/30 (part number 76386GT)
Compatibility	Genie Boom Lift TMZ-50/30 (Replaces P/N 48273)

5. SETUP AND INSTALLATION

This section outlines the general procedure for installing the 76386GT Drive Control Board. Always refer to the specific service manual for your Genie Boom Lift TMZ-50/30 for detailed, model-specific instructions and diagrams.

1. **Preparation:** Ensure the boom lift is powered off and locked out according to safety protocols. Disconnect the battery to prevent accidental power-up.
2. **Access:** Locate the existing drive control board within the lift's control panel or designated compartment.
3. **Removal of Old Board:** Carefully disconnect all wiring harnesses and connectors from the old control board. Note the position and orientation of each connector for correct reinstallation. Unfasten any mounting screws or clips securing the old board.
4. **Installation of New Board:** Position the new Sourcefy 76386GT board in the same location as the old one. Secure it with the appropriate mounting hardware.
5. **Wiring:** Reconnect all wiring harnesses and connectors to the new board, ensuring they are firmly seated and correctly oriented. Double-check all connections against the lift's wiring diagram if available.
6. **Verification:** Before restoring full power, perform a continuity check on critical circuits if possible.
7. **Power Restoration:** Reconnect the battery and restore power to the lift.
8. **Functional Test:** Conduct a thorough functional test of all drive controls and related systems to confirm proper operation.

6. OPERATING INSTRUCTIONS

The 76386GT Drive Control Board operates as an integral part of the Genie Boom Lift's control system. Its function is to translate operator inputs from the joystick and other controls into commands for the lift's drive motors. No direct operator interaction with the board itself is required during normal operation.

Refer to the Genie Boom Lift TMZ-50/30 operator's manual for detailed instructions on how to operate the lift's drive system, including forward/reverse, steering, and speed control. The control board ensures that these operations are executed smoothly and safely.

7. MAINTENANCE

The Sourcefy 76386GT Drive Control Board is designed for durability and reliability. Regular maintenance of the overall boom lift system is essential for the longevity of all components, including the control board.

- **Inspection:** Periodically inspect the control board and its connections for signs of corrosion, loose wiring, or physical damage.
- **Cleaning:** Keep the control board area clean and free from dust, moisture, and debris. Use compressed air or a soft, dry brush for cleaning. Avoid using liquid cleaners directly on the board.
- **Environmental Protection:** Ensure the control panel or enclosure housing the board remains sealed and protected from environmental elements such as water, extreme temperatures, and excessive vibration.
- **Component Checks:** If accessible and safe, check for any signs of overheating on components (e.g., discoloration).

8. TROUBLESHOOTING

If the Genie Boom Lift exhibits issues related to its drive functions after installing or while using the 76386GT Drive Control Board, consider the following troubleshooting steps. Always consult the lift's OEM service manual for comprehensive diagnostic procedures.

- **No Drive Function:**

- Check power supply to the control board.
- Verify all wiring connections are secure and correct.
- Inspect fuses on the control board or within the lift's electrical system.
- Test the joystick or other input devices for proper function.

- **Intermittent Drive:**

- Check for loose or corroded connections.
- Inspect for signs of intermittent shorts or component failure on the board.

- **Incorrect Drive Response:**

- Ensure the correct control board model is installed.
- Verify proper calibration of input devices (if applicable and adjustable).

- **Error Codes:**

If the lift displays error codes, refer to the Genie Boom Lift's service manual to interpret these codes and identify the root cause. The control board may be part of the diagnostic chain.

If troubleshooting does not resolve the issue, professional diagnostic and repair services are recommended.

9. WARRANTY AND SUPPORT

The Sourcefy 76386GT Drive Control Board comes with a **6 Months Unlimited Warranty**. This warranty covers defects in materials and workmanship under normal use.

For technical support, warranty claims, or further assistance, please contact your authorized Sourcefy dealer or the point of purchase. When contacting support, please have your product model number (76386GT) and purchase information readily available.

