

surmen Cute Wireless Keyboard and Mouse Combo

surmen Cute Wireless Keyboard and Mouse Combo Instruction Manual

Brand: surmen | Model: Cute Wireless Keyboard and Mouse Combo

1. PRODUCT OVERVIEW

The surmen Cute Wireless Keyboard and Mouse Combo offers a full-size, slim, and low-noise input solution designed for comfort and efficiency. Featuring soft-touch round keys and a silent mouse, this combo is suitable for various environments including home and office use. Its wireless 2.4G technology ensures a stable connection.

Key Features:

- **Plug and Play:** Requires only one receiver for both keyboard and mouse, no additional drivers needed.
- **Silent Operation:** Designed for noise reduction, with quiet key presses and mouse clicks.
- **Ergonomic Design:** Ultra-thin keyboard with an optimum typing angle and a curved mouse for correct posture.
- **Power Saving:** Automatic sleep mode after 15 minutes of inactivity to conserve battery life.
- **Multi-functional Hotkeys:** 15 hotkeys and a numeric keypad for enhanced productivity.
- **Wide Compatibility:** Compatible with Windows XP/Vista/7/8/10/X, Mac, and other operating systems.



Image: The surmen wireless keyboard and mouse combo, showcasing its 2.4G wireless, 33ft transmission, low noise, power-saving, and USB connectivity features.

BEAUTIFULLY CRAFTED

Increased Key Stability for a Whopping 50 Million Presses



Round Key



Water-Drop
concave



Anti - Grease



Aesthetic



Image: Detailed view of the keyboard's round, water-drop concave, anti-grease, and aesthetic key design.

2. SETUP GUIDE

2.1 Battery Installation

1. **Mouse:** Open the battery compartment on the underside of the mouse. Insert one AAA battery (included), ensuring correct polarity. Close the compartment.
2. **Keyboard:** Open the battery compartment on the underside of the keyboard. Insert two AAA batteries (not included), ensuring correct polarity. Close the compartment.



Silent clicking & Ergonomic Design

Image: The underside of the mouse, illustrating the battery compartment and the slot for the USB receiver.

2.2 Connecting the Combo

1. Locate the USB receiver, which is conveniently stored inside the mouse's battery compartment.
2. Plug the USB receiver into an available USB port on your computer or laptop.
3. Turn on the mouse using the power switch located on its underside.
4. Turn on the keyboard using the power switch, usually located on the side or back.
5. Your computer should automatically detect and connect to both the keyboard and mouse. No additional drivers are required.

Your browser does not support the video tag.

Video: A demonstration of unboxing the Surmen Wireless Keyboard and Mouse, showing the USB receiver and initial setup steps.



Plug and play & Stable connection

Advanced 2.4GHz wireless technology provides a powerful and reliable connection up to 33 ft

Image: The wireless keyboard and mouse connected to a laptop, demonstrating the simple plug-and-play setup with a single USB receiver.

3. OPERATING INSTRUCTIONS

3.1 General Usage

- The keyboard features a full QWERTY layout with a numeric keypad for comprehensive input.
- The mouse is designed for silent clicking, reducing noise by 98% for a quiet working environment.




Image: The silent mouse in operation, highlighting its low-noise design suitable for quiet environments.

3.2 Multi-functional Hotkeys

The keyboard includes 15 hotkeys for quick access to common functions. These keys are typically located along the top row (F1-F12) and may require pressing the 'Fn' key simultaneously for certain functions.

- **Media Controls:** Play/Pause, Volume Up/Down, Mute.
- **Browser/Email:** Open browser, open email client.
- **System Functions:** Lock screen, search, calculator.



Image: The keyboard with arrows pointing to various hotkeys, illustrating their functions such as media control and system shortcuts.

3.3 Power Saving Mode

To extend battery life, both the keyboard and mouse will automatically enter sleep mode after 15 minutes of inactivity. To wake them up, simply press any key on the keyboard or click a mouse button.

Ultra-Slim Keyboard

Adjustable tilt legs keep you comfortable for long stretches at the desk

3.4 Indicator Lights

The keyboard features indicator lights for:

- **Number Lock:** Indicates when the numeric keypad is active.
- **Caps Lock:** Indicates when Caps Lock is active.
- **Low Power:** Illuminates when batteries are low and need replacement.



Image: A close-up of the keyboard's top right corner, showing the indicator lights for Number Lock, Caps Lock, and Low Power.

4. MAINTENANCE

To ensure the longevity and optimal performance of your keyboard and mouse combo, follow these maintenance tips:

- **Cleaning:** Use a soft, dry cloth to wipe down the surfaces of the keyboard and mouse. For deeper cleaning, the floating keycaps can be carefully removed to clean dust and debris underneath.
- **Battery Replacement:** Replace batteries promptly when the low power indicator light illuminates to avoid interruption in use.
- **Storage:** When not in use for extended periods, turn off both devices to conserve battery life. Store the USB receiver inside the mouse to prevent loss.

5. TROUBLESHOOTING

• **No Connection:**

- Ensure the USB receiver is securely plugged into a working USB port on your computer.
- Check if both the keyboard and mouse are powered on.
- Replace batteries in both devices if the low power indicator is on or if they haven't been replaced recently.
- Try plugging the USB receiver into a different USB port.

• **Mouse Lag/Unresponsive:**

- Ensure the mouse is on a clean, flat surface.
- Check battery levels and replace if necessary.
- Move the mouse closer to the USB receiver to rule out interference.

• **Keys Not Responding:**

- Check keyboard battery levels.
- Ensure the keyboard is powered on.
- Clean around and under the affected keys.

6. SPECIFICATIONS

Feature	Detail
Brand	surmen
Color	Colorful Pink
Connectivity Technology	Radio Frequency (2.4G Wireless)
Special Features	Ergonomic, Round Key, Silent Click, Power Saving
Compatible Devices	Personal Computer (Windows XP/Vista/7/8/10/X, Mac, etc.)
Keyboard Dimensions	17.52 x 5.42 x 1.11 inches (approximate)
Mouse Dimensions	4.12 x 2.72 x 1.41 inches (approximate)
Item Weight	1.76 pounds
Batteries Required	1 AAA for mouse (included), 2 AAA for keyboard (not included)

Full-Size Ultra Slim Design




Image: Visual representation of the keyboard and mouse with their respective dimensions, highlighting the full-size ultra-slim design.

7. WARRANTY AND SUPPORT

For any concerns regarding your surmen Cute Wireless Keyboard and Mouse Combo, please do not hesitate to contact our support team. We are committed to ensuring your satisfaction.

Contact Information:

Email: sumimall@163.com

Please refer to your purchase documentation for specific warranty details and terms.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question