

manuals.plus /

> [surmen](#) /

> [surmen Brown Quiet Wireless Keyboard and Mouse Combo User Manual](#)

surmen Brown Quiet Wireless Keyboard and Mouse Combo

surmen Brown Quiet Wireless Keyboard and Mouse Combo User Manual

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your surmen Brown Quiet Wireless Keyboard and Mouse Combo. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.

PACKAGE CONTENTS

Verify that all items are present in your package:

- Wireless Keyboard
- Wireless Mouse
- USB 2.4GHz Receiver (stored inside the mouse battery compartment)
- AAA Batteries (1 for keyboard, 1 for mouse)
- User Manual (this document)

SETUP INSTRUCTIONS

1. **Install Batteries:** Open the battery compartment on the underside of both the keyboard and the mouse. Insert the provided AAA batteries, ensuring correct polarity.
2. **Locate USB Receiver:** The USB 2.4GHz receiver is stored in the battery compartment of the mouse. Carefully remove it.
3. **Connect Receiver:** Plug the USB receiver into an available USB port on your computer.
4. **Power On:** Ensure both the keyboard and mouse are switched on (if they have an on/off switch). The devices are designed for plug-and-play functionality and should connect automatically.



Plug and play & Stable connection

Advanced 2.4GHz wireless technology provides a powerful and reliable connection up to 33 ft

Figure 1: Plug and Play setup with the 2.4GHz USB receiver.

The 2.4GHz wireless technology provides a stable connection up to 33 feet (approximately 10 meters).

OPERATING INSTRUCTIONS

Keyboard Usage

The full-size keyboard features a retro typewriter-style design with rounded keycaps. It offers a comfortable typing experience with low-noise keys. The keyboard is designed to maintain an optimum typing angle.

BEAUTIFULLY CRAFTED

Increased Key Stability for a Whopping 50 Million Presses



Round Key



Water-Drop
concave



Anti - Grease



Aesthetic



Figure 2: Key features of the keyboard design.

Mouse Usage

The wireless mouse features a curved surface designed for correct hand posture, promoting ergonomic comfort. It provides silent clicking, reducing noise by 98% compared to standard mice, making it suitable for quiet environments.



Figure 3: Ergonomic design and silent clicking feature of the mouse.

MULTIMEDIA HOTKEYS

The keyboard includes 15 multi-functional hotkeys for quick access to various functions. To activate multimedia functions, press the **Fn** key simultaneously with the desired function key (F1-F12).

- **Fn + Esc:** Switch multimedia functions
- **F1-F12:** Control media playback, volume, email, web browser, and other system functions. Refer to the key icons for specific functions.
- **Lock Screen Key:** Located above the numeric keypad, this key allows for quick screen locking.




Figure 4: Overview of multimedia hotkeys and their functions.

POWER MANAGEMENT

Both the keyboard and mouse are designed with low power consumption features to extend battery life.

Automatic Sleep Mode

To conserve power, both devices will automatically enter sleep mode after 15 minutes of inactivity. To wake them up, simply press any key on the keyboard or click any button on the mouse.



Figure 5: Energy-saving design with automatic sleep mode.



Plug and Play

One nano receiver connects both the wireless keyboard and mouse by 2.4G wireless connection

Figure 6: Automatic power saving states for the mouse.

Low Power Indicator

The keyboard features a low power indicator light, typically located near the Caps Lock and Num Lock indicators. When the battery level is low, this light will illuminate, signaling that the batteries need to be replaced.




Figure 7: Keyboard indicator lights, including the low power warning.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the keyboard and mouse. For stubborn dirt, a slightly damp cloth with mild soap can be used, ensuring no liquid enters the device.
- **Battery Replacement:** When the low power indicator illuminates or performance degrades, replace the AAA batteries in both devices. Ensure correct polarity during installation.
- **Storage:** When not in use for extended periods, remove the batteries to prevent leakage and store the devices in a cool, dry place.

TROUBLESHOOTING

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
Keyboard/Mouse not responding	<p>Ensure batteries are correctly installed and not depleted. Replace if necessary.</p> <p>Verify the USB receiver is securely plugged into a working USB port. Try a different USB port.</p> <p>Ensure the keyboard and mouse are switched on.</p> <p>Move the devices closer to the USB receiver to rule out range issues.</p> <p>Re-pair the devices by unplugging and re-plugging the USB receiver.</p>
Lag or delayed response	<p>Check for interference from other wireless devices.</p> <p>Ensure the devices are within the effective range (up to 33 feet) of the receiver.</p> <p>Replace batteries if they are low.</p>
Keys are sticky or unresponsive	<p>Clean around the affected keys with compressed air or a soft brush.</p> <p>Ensure no debris is lodged under the keycaps.</p>
Mouse cursor erratic or not moving	<p>Clean the optical sensor on the underside of the mouse.</p> <p>Ensure you are using the mouse on a suitable surface (not highly reflective or transparent).</p> <p>Replace batteries.</p>

SPECIFICATIONS

- **Brand:** surmen
- **Model:** Brown Quiet Wireless Keyboard and Mouse Combo
- **Connectivity:** 2.4GHz Wireless
- **Keyboard Type:** Full-Size, Retro Typewriter Style, Round Keycaps
- **Mouse Type:** Ergonomic, Silent Click
- **Power Source:** AAA Batteries (1 for keyboard, 1 for mouse)
- **Compatibility:** Windows XP/Vista/7/8/10/X, Mac, Chrome-book, PC, Laptop, Computer
- **Operating Range:** Up to 33 feet (10 meters)
- **Automatic Sleep:** After 15 minutes of inactivity
- **Keyboard Dimensions:** Approximately 17.52 x 5.42 x 1.11 inches
- **Mouse Dimensions:** Approximately 4.12 x 2.72 x 1.41 inches
- **Item Weight:** Approximately 1.94 pounds (combined)

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official surmen website. Keep your purchase receipt as proof of purchase.

