

FOWORE 42ex safe

FOWORE 2.5 Cuft Home Safe User Manual

Model: 42ex Safe

1. INTRODUCTION

Thank you for choosing the FOWORE 2.5 Cuft Home Safe. This manual provides essential information for the proper setup, operation, and maintenance of your new safe. Please read these instructions carefully before use and retain them for future reference. Proper use ensures the security and longevity of your product.

2. IMPORTANT SAFETY INFORMATION

- **DO NOT** store the emergency backup keys inside the safe. Keep them in a secure, separate location.
- **DO NOT** store your personal code or master code inside the safe. Memorize your codes or keep them in a secure, confidential place.
- Ensure the safe is securely mounted to a wall or floor to prevent unauthorized removal.
- Replace batteries promptly when the low battery warning is indicated to ensure continuous functionality.
- Keep children away from the safe and its contents.

3. PACKAGE CONTENTS

Please check the package to ensure all items are present:

- 1 x FOWORE 2.5 Cuft Home Safe
- 1 x User Manual (this document)
- 1 x Fireproof and Waterproof Bag
- 2 x Emergency Backup Keys
- 4 x Mounting Screws

4. PRODUCT OVERVIEW



Figure 4.1: FOWORE 2.5 Cuft Home Safe with door open, showcasing interior and included fireproof bag.

The FOWORE 2.5 Cuft Home Safe is designed to provide secure storage for your valuables. It features robust construction and advanced security mechanisms.

Key Features:

- **Durable Construction:** Made from solid cold-rolled steel with a recessed pry-resistant door and three enhanced steel locking bolts.
- **Digital Security Lock:** Electronic combination lock with a digital keypad for secure access.
- **Anti-Theft Alarm System:** Activates an audible alarm after three consecutive incorrect code entries.
- **Silent Mode:** Option to disable keypad sounds for discreet operation.
- **Removable Shelf:** Allows for customizable storage space to accommodate various item sizes.
- **Internal LED Light:** Provides visibility inside the safe, even in low-light conditions.
- **Mounting Capability:** Pre-drilled holes on the bottom and back for secure installation to a wall or floor.
- **Low Battery Warning:** Visual indicator on the keypad alerts you when batteries need replacement.
- **Fireproof and Waterproof Bag:** An additional layer of protection for important documents and small

valuables.

5. SETUP

5.1 Initial Opening

For the first use, the safe must be opened using one of the emergency backup keys.

1. Locate the keyhole cover on the digital keypad.
2. Remove the cover to expose the keyhole.
3. Insert one of the emergency backup keys into the keyhole and turn it clockwise.
4. While the key is turned, rotate the knob on the keypad clockwise to open the safe door.
5. Once open, remove the key and store it in a safe place outside the safe.




Figure 5.1: Initial opening and two access methods.

5.2 Battery Installation

The safe requires 4 AA batteries (not included) to power the digital keypad.

1. Open the safe door.

2. Locate the battery compartment on the inside of the safe door.
3. Open the battery compartment cover.
4. Insert 4 new AA batteries, ensuring correct polarity (+/-).
5. Close the battery compartment cover.

5.3 Setting Your Personal Code

You can set a personal code (3-8 digits) for daily access.

1. With the safe door open, locate the red setting button on the inside of the door, near the hinge.
2. Press the red setting button. The keypad will beep, and the indicator light will flash.
3. On the keypad, enter your desired 3 to 8 digit personal code.
4. Press the 'A' or 'B' key to confirm your new code. The keypad will beep again, indicating successful programming.
5. Test your new code with the door open before closing it.




Figure 5.2: Password setting instructions.

5.4 Setting the Master Code (Optional)

The safe also allows for a master code, which can be useful for multiple users or as a backup.

1. With the safe door open, press '00' on the keypad.
2. Then, press the red setting button on the inside of the door. The keypad will beep, and the indicator light will flash.
3. Enter your desired 3 to 8 digit master code.
4. Press the 'A' or 'B' key to confirm your new master code. The keypad will beep again.
5. Test your new master code with the door open before closing it.

5.5 Mounting the Safe

For enhanced security, it is recommended to anchor the safe to a wall or floor.

1. Choose a suitable location for mounting.
2. Open the safe door and remove the removable shelf if it obstructs access to the pre-drilled holes.
3. Mark the positions for drilling through the pre-drilled holes on the back or bottom of the safe.
4. Drill pilot holes in the wall or floor using an appropriate drill bit (not included).
5. Align the safe with the drilled holes and secure it using the provided mounting screws.

6. Ensure the safe is firmly attached and stable.

Removable Shelf to Customize Your Space



Figure 5.3: Removable shelf for customizable storage.

6. OPERATING INSTRUCTIONS

6.1 Opening the Safe with Your Code

1. Enter your personal code (3-8 digits) on the digital keypad.
2. Press the 'A' or 'B' key to confirm.
3. Within 5 seconds, rotate the knob clockwise to open the safe door.

6.2 Opening the Safe with Emergency Key

This method is used if you forget your code or if the batteries are depleted.

1. Remove the keyhole cover on the digital keypad.
2. Insert an emergency backup key into the keyhole and turn it clockwise.
3. While the key is turned, rotate the knob on the keypad clockwise to open the safe door.

6.3 Anti-Theft Alarm System

The safe is equipped with an alarm system to deter unauthorized access.

- If an incorrect code is entered three times consecutively, the alarm will activate.
- The safe will lock for approximately 5 minutes, and an audible alarm will sound.
- To silence the alarm, enter the correct code or use the emergency key.



Figure 6.1: Anti-theft alert and optional mute function.

6.4 Silent Mode

To operate the safe without keypad sounds:

- **Activate Silent Mode:** Press "00A" on the keypad.
- **Deactivate Silent Mode:** Press "66A" on the keypad.
- *Note:* Even in silent mode, the anti-theft alarm will still sound if incorrect codes are entered.

ANTI-THEFT ALERT SYSTEM

Any Unauthorized Access



3 Times Password
Error Alarm



Low Battery
Warning



Figure 6.2: Silent mode and LED light features.

6.5 Low Battery Warning

When the batteries are low, both the green and red indicator lights on the keypad will illuminate simultaneously. Replace the batteries immediately to ensure continued functionality.

7. MAINTENANCE

- **Cleaning:** Wipe the exterior of the safe with a soft, damp cloth. Avoid using abrasive cleaners or solvents that could damage the finish.
- **Battery Replacement:** Replace all 4 AA batteries annually or immediately when the low battery warning appears. Always use new, high-quality alkaline batteries.
- **Security Check:** Periodically check the mounting bolts to ensure they remain tight and secure.
- **Key Storage:** Regularly verify that your emergency keys are stored in a safe, accessible location outside the safe.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Safe does not open with code.	Incorrect code entered; low batteries.	Re-enter correct code carefully. Replace batteries. Use emergency key.
Keypad is unresponsive.	Dead or improperly installed batteries.	Replace all 4 AA batteries, ensuring correct polarity.
Alarm sounds unexpectedly.	Three incorrect code entries; tampering detected.	Enter correct code or use emergency key to disarm. Ensure safe is not being tampered with.
Forgotten personal or master code.	Code forgotten.	Use emergency key to open the safe. Reset your code following the instructions in Section 5.3 or 5.4.

9. SPECIFICATIONS

Feature	Detail
Brand	FOWORE
Model	42ex safe
Capacity	2.5 Cubic Feet
Product Dimensions (External)	11"D x 13"W x 16"H (approx. 31cm D x 35cm W x 42cm H)
Item Weight	25.5 Pounds
Lock Type	Electronic Combination Lock, Key
Material	Alloy Steel
Mounting Type	Wall and Floor Mount
Power Source	4 x AA Batteries (not included)

Smart Capacity & Perfect Size



Fireproof Bag



Spare Battery Box



Lifetime Support



Video Guide



Figure 9.1: External dimensions of the FOWORE Home Safe.

Solid Steel Plate & The Best Home Safety Protection



Enhanced Sturdy Steel Lock Bolt
3*20mm Solid Anti-Pry Latch



Multi-Layer Wear-Resistant
And Durable Steel



Micro Seam Design Anti-Drilling

Figure 9.2: Robust construction details of the FOWORE Home Safe.



10. WARRANTY AND SUPPORT

FOWORE is committed to providing high-quality products and excellent customer service.

- **Product Warranty:** Your FOWORE safe comes with a 5-year product warranty.
- **Technical Support:** Enjoy lifetime technical support for your product.
- **Returns:** We offer a 30-day free return policy.
- **Customer Service:** Our customer service team aims to reply to inquiries within 24 hours.

For any questions, concerns, or support needs, please contact FOWORE customer service through the platform where you purchased the product or visit the official FOWORE store online.


Related Documents - 42ex safe

 <p>TOUCHSCREEN SAFE BOX Instruction Manual</p> <p>COMPONENT DESCRIPTION</p> <p>① Circular Handle ② Digital Keypad ③ Indicator Light ④ Battery Box ⑤ Emergency Keyhole ⑥ Removable Shelf ⑦ Alarm Siren ⑧ Alarm Siren ⑨ Lock Bolt</p> <p>Extend 5 Years Warranty</p> <p>① Send your order number to following email: support@fowore.com</p> <p>② Register your product warranty to activate a free extra 5 years protection</p> <p>Parts list</p> <table border="1"> <thead> <tr> <th>Item</th> <th>Picture</th> <th>Qty</th> <th>Item</th> <th>Picture</th> <th>Qty</th> </tr> </thead> <tbody> <tr> <td>Emergency key</td> <td></td> <td>1</td> <td>Mounting screw</td> <td></td> <td>4</td> </tr> <tr> <td>Instruction book</td> <td></td> <td>1</td> <td>Emergency lock</td> <td></td> <td>1</td> </tr> <tr> <td>Mat</td> <td></td> <td>1</td> <td>Safe Box</td> <td></td> <td>1</td> </tr> </tbody> </table>	Item	Picture	Qty	Item	Picture	Qty	Emergency key		1	Mounting screw		4	Instruction book		1	Emergency lock		1	Mat		1	Safe Box		1	<p>Touchscreen Safe Box Instruction Manual</p> <p>Comprehensive instruction manual for the Touchscreen Safe Box, covering component descriptions, parts list, initial use, battery insertion, opening and closing the door, dual alarm system, setting user and administrator codes, mute mode, factory reset, and mounting instructions.</p>
Item	Picture	Qty	Item	Picture	Qty																				
Emergency key		1	Mounting screw		4																				
Instruction book		1	Emergency lock		1																				
Mat		1	Safe Box		1																				
 <p>SAFE BOX INSTRUCTION MANUAL</p> <p>⚠ Tip: Check the dimensions before installation.</p> <p>IMPORTANT INFORMATION FOR THE USER</p> <p>① Read the manual and pay attention to the safety instructions. ② Do not use the safe for storing flammable, explosive, or toxic substances. ③ Do not use the safe for storing food or other items that may be damaged by moisture. ④ Do not use the safe for storing cash or other valuables that are not protected by fire. ⑤ Do not use the safe for storing documents or other items that are not protected by fire.</p> <p>IMPORTANT INFORMATION FOR THE USER (continued)</p> <p>① The factory password is "9999". ② Do not use the safe for storing cash or other valuables that are not protected by fire. ③ Do not use the safe for storing documents or other items that are not protected by fire. ④ Do not use the safe for storing cash or other valuables that are not protected by fire.</p> <p>IMPORTANT INFORMATION FOR THE USER (continued)</p> <p>① Read the manual and pay attention to the safety instructions. ② Do not use the safe for storing flammable, explosive, or toxic substances. ③ Do not use the safe for storing food or other items that may be damaged by moisture. ④ Do not use the safe for storing cash or other valuables that are not protected by fire. ⑤ Do not use the safe for storing documents or other items that are not protected by fire.</p>	<p>Safe Box Instruction Manual - Operating and Mounting Guide</p> <p>Comprehensive guide for the Safe Box, covering first-time opening, user code setting, automatic lockout features, technical specifications, and mounting instructions. Learn how to secure your valuables with this home safe.</p>																								
 <p>SAFE BOX INSTRUCTION MANUAL</p> <p>⚠ Tip: Please do not lose the emergency key to the safe!</p> <p></p> <p>① Indicator light ② Emergency keyhole ③ Digital keypad ④ Handle ⑤ Lock bolt</p> <p>Dear valued customer:</p> <p>Thank you for choosing our products! You have taken an important step in safeguarding your valuables and ensuring your peace of mind. Our products are designed to provide safety, security, and protection for your valuables. Please take time to read and understand the proper operating procedures of your new safe presented on the following pages.</p>	<p>Safe Box Instruction Manual: Setup, Operation, and Mounting Guide</p> <p>Comprehensive instruction manual for operating and mounting your safe box. Covers first opening, setting user codes, alarm settings, and installation procedures. Includes troubleshooting tips and contact information.</p>																								
 <p>SECURITY LOCK BOX (EE) INSTRUCTIONS</p> <p></p> <p>Extend 4 Years Warranty</p> <p>① Send your order number to following email: support@fowore.com</p> <p>② Register your product warranty to activate a free extra 4 years protection</p>	<p>Security Lock Box (EE Series) Instructions and User Guide</p> <p>Comprehensive instructions for operating and securing the Security Lock Box (EE Series). This guide details first-time opening, setting master and personal codes, emergency access, troubleshooting notices, wall and floor fixation methods, and a list of packing accessories.</p>																								



[SentrySafe Fire-Safe® Owner's Manual - Operation, Warranty, and Support](#)

Comprehensive owner's manual for the SentrySafe Fire-Safe® safe, covering operation of mechanical and electronic locks, bolting down, troubleshooting, warranty information, and customer service. Learn how to set up, use, and maintain your SentrySafe safe.



[HMF 250442 Fireproof Document Safe: Instruction Manual](#)

Comprehensive instructions for the HMF 250442 fireproof and waterproof document safe, covering safe operation, storage, security, and warranty information.