

[Manuals.plus](#) /

› [HARPPA](#) /

› HARPPA 2 in 1 Toddler Swing Set Instruction Manual

HARPPA Toddler Swing Set

HARPPA 2 in 1 Toddler Swing Set Instruction Manual

Model: Toddler Swing Set | Brand: HARPPA

PRODUCT OVERVIEW

The HARPPA 2-in-1 Toddler Swing Set offers a versatile play solution for children aged 1 to 5 years, combining a swing and a jumper in one foldable unit. Designed for both indoor and outdoor use, this set promotes physical development, coordination, and balance while ensuring safety through durable materials and secure features.



Image: The complete HARPPA 2-in-1 Toddler Swing Set, showcasing both the swing seat and the baby jumper attachment, ready for use.

KEY FEATURES

- **Versatile 2-in-1 Design:** Easily converts between a swing and a jumper, offering diverse play options.
- **Enhanced Safety:** Constructed with high-quality, durable materials, secure harnesses, hook-locking design, and triangular stability for child's well-being.
- **Physical Development:** Encourages strength, coordination, and balance through active play.
- **Adjustable for Growth:** Both swing and jumper heights are adjustable, and the swing seat is customizable to accommodate children from 1 to 5 years.
- **Space-Saving Foldable Design:** Conveniently folds for easy storage, ideal for homes with limited space.



Image: Visual representation of the product's adaptability, showing how it accommodates children at different age stages from infant to toddler.

SETUP AND ASSEMBLY

Assembly is required for the HARPPA 2-in-1 Toddler Swing Set. Follow these general steps for safe and correct setup. Refer to the included physical manual for detailed, step-by-step instructions and diagrams.

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the parts list in your manual.
2. **Assemble Frame:** Connect the high carbon steel frame components, ensuring all connections are secure. The triangular stability design provides a sturdy base.
3. **Attach Anti-slip Caps:** Place the anti-slip caps on the bottom of the frame legs to ensure stability and protect floor surfaces.
4. **Install Hanging System:** Secure the double cable hanging system to the top bar of the frame using the reliable latching design.
5. **Attach Seat/Jumper:** Depending on your child's age and preference, attach either the swing seat or the jumper. Ensure secure screw connections and proper armrest and safety belt protection.
6. **Final Check:** Before first use, double-check all nuts, bolts, and connections to ensure they are tightened securely.




Image: Demonstrates the ease of assembly and the compact storage capability of the swing set.

SAFETY IS OUR PRIORITY!




Image: Detailed view of the secure connection points and safety mechanisms of the swing set.

OPERATING INSTRUCTIONS

Using the Jumper (6-18 Months)

The jumper attachment is designed for infants aged 6 to 18 months, supporting up to 35 lbs. It provides a safe and engaging way for babies to exercise their leg muscles and enjoy bouncing.

- **Secure Child:** Place your child in the jumper, ensuring the safety belt and Velcro straps are securely fastened for double protection.
- **Adjust Height:** Adjust the jumper's height so your child's feet can comfortably touch the floor, allowing for gentle bouncing.
- **Supervision:** Always supervise your child while they are in the jumper.

ENDLESS GIGGLES WITH EVERY BOUNCE!



6~18
Months



Adjustable
Height



Exercise Child's
Leg Muscles



Safety Belt & Velcro
for Double Protection



Jumper

Load Weight: Up to 35 lbs

Image: Illustrates the key features and age suitability for the jumper attachment.



Image: A baby enjoying the jumper feature indoors, demonstrating its use.

Using the Swing (1-5 Years)

The swing seat is designed to grow with your child, suitable for ages 1 to 5 years and supporting up to 88 lbs. It offers a classic swinging experience.

- **Seat Configuration:** The swing seat can be configured in three stages:
 - Full bucket seat (1-2 Years)
 - Seat with backrest (2-4 Years)
 - Flat seat (4-5 Years)
- **Secure Child:** Ensure your child is properly seated and the safety belt is fastened.
- **Swinging:** Gently push the swing. Avoid excessive force that could destabilize the frame.
- **Supervision:** Always supervise your child while they are using the swing.

A SWING THAT GROWS WITH YOU!



1~2 Years



2~4 Years



4~5 Years



Swing

Load Weight: Up to 88 lbs

Image: Details the three stages of the swing seat, illustrating its adaptability for growing children.

Image: Children enjoying both the jumper and swing features, suitable for both indoor and outdoor environments.

MAINTENANCE AND CARE

Regular maintenance ensures the longevity and safety of your HARPPA 2-in-1 Toddler Swing Set.

- **Cleaning:** Wipe down all plastic and metal parts with a damp cloth and mild soap. Avoid abrasive cleaners.
- **Inspection:** Periodically inspect all nuts, bolts, ropes, and straps for wear, damage, or looseness. Tighten any loose connections immediately.
- **Storage:** When not in use, especially during adverse weather conditions (if used outdoors), fold the swing set and store it in a dry, protected area to prevent rust and damage.
- **Material Care:** The frame is made of high carbon steel and plastic. The seat is made of thickened polypropylene material. Ensure these materials are not exposed to extreme temperatures or prolonged direct sunlight to prevent degradation.

TROUBLESHOOTING

If you encounter any issues with your swing set, please refer to the following common solutions:

- **Instability:** Ensure the swing set is placed on a flat, level surface. Check all frame connections and tighten any loose bolts. Verify anti-slip caps are properly installed.
- **Swing/Jumper Not Moving Smoothly:** Check for any obstructions around the swing/jumper. Ensure ropes/straps are not twisted or tangled.
- **Missing Parts:** If any parts are missing upon unboxing, contact customer support immediately with your order details.
- **General Wear and Tear:** Replace any worn or damaged components promptly to maintain safety. Do not use the product if any part is broken or compromised.

SPECIFICATIONS

Brand	HARPPA
Model Number	Toddler Swing Set
Color	Black
Product Dimensions	39.37"D x 57.09"W x 59.84"H
Frame Material	High carbon steel, plastic
Finish Type	Textured Plastic
Item Weight	25 pounds
Assembly Required	Yes
Jumper Load Weight	Up to 35 lbs
Swing Load Weight	Up to 88 lbs
Recommended Age (Jumper)	6-18 Months
Recommended Age (Swing)	1-5 Years

FOLDABLE FRAME FOR STORAGE




Image: Detailed dimensions of the swing set and its compact folded state for storage.

WARRANTY AND SUPPORT

For warranty information, product support, or to report any issues, please contact HARPPA customer service. Keep your purchase receipt and order ID handy for faster service.

Typically, you can find support contact information on the product packaging, the official HARPPA website, or through your purchase platform (e.g., Amazon order history).

General Contact Method (Amazon):

1. Login to your Amazon Account.
2. Go to "Your Orders".
3. Find the order ID for your HARPPA Swing Set.
4. Click "Contact Seller" to reach HARPPA customer support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question