

## Genérico J-60L

# Genérico J-60L Bone Conduction Bluetooth Earphones

## User Manual

### **1. INTRODUCTION**

---

Welcome to the user manual for your new Genérico J-60L Bone Conduction Bluetooth Earphones. These earphones are designed to provide a unique audio experience by transmitting sound through your cheekbones, allowing you to remain aware of your surroundings while enjoying your audio. Please read this manual carefully to ensure proper use and maintenance of your device.



Image: The Genérico J-60L Bone Conduction Bluetooth Earphones in white, shown inside their transparent-lidded charging case. The earphone on the right has a red indicator light visible.

## 2. PRODUCT FEATURES

---

- **Bone Conduction Technology:** Listen to music and calls without blocking your ears, maintaining awareness of your surroundings.
- **Stable Connection:** Equipped with Bluetooth V5.3 for a fast and stable connection up to 10 meters.
- **High Sound Quality:** 106dB SPL  $\pm 3$ dB sensitivity and a frequency range of 40Hz to 20KHz ensure clear and powerful sound.
- **True Wireless Design:** Provides complete freedom of movement without wires.
- **Wide Compatibility:** Supports multiple wireless protocols (HSP, HFP, A2DP, AVRCP, SPP) for connection with various devices.
- **Long-lasting Battery:** Rechargeable lithium polymer battery offers extended continuous use.
- **Water Resistant:** Designed to withstand splashes and sweat.

## 3. PACKAGE CONTENTS

---

Please check the box for the following items:

- 1x Genérico J-60L Bone Conduction Bluetooth Earphones
- 1x USB Charging Cable
- 1x User Manual (this document)
- 1x Carrying Case



Image: The product packaging for the J-60L earphones, displaying both white and black versions of the earphones and their respective charging cases.

## 4. SETUP GUIDE

---

### 4.1. Charging the Earphones

Before first use, fully charge your earphones. Connect the USB charging cable to the charging port on the earphones and plug the other end into a USB power source (e.g., computer, wall adapter).

- **Charging Time:** Approximately 1.2 hours for a full charge.
- The indicator light will show charging status (refer to specific light behavior in the quick start guide if available, or infer from common device behavior).

### 4.2. Powering On/Off

- **Power On:** Press and hold the multi-function button until the indicator light flashes (usually blue).
- **Power Off:** Press and hold the multi-function button until the indicator light flashes (usually red) and then turns off.

### 4.3. Bluetooth Pairing

To connect your earphones to a device:

1. Ensure the earphones are fully charged and powered off.
2. Press and hold the multi-function button until the indicator light flashes red and blue alternately, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "J-60L" from the list of found devices.
5. Once connected, the indicator light on the earphones will typically flash blue slowly or turn off.

**Compatible Devices:** Smartphones (Android, iOS), Tablets (Android, iPad), Computers/Laptops (with Bluetooth), Modern TVs (with Bluetooth), Some Gaming Consoles.

## 5. OPERATING INSTRUCTIONS

---

### 5.1. Music Playback

- **Play/Pause:** Single press the multi-function button.
- **Next Track:** Double press the multi-function button.
- **Previous Track:** Triple press the multi-function button.

### 5.2. Call Management

- **Answer/End Call:** Single press the multi-function button during an incoming call or active call.
- **Reject Call:** Press and hold the multi-function button for 2 seconds during an incoming call.

### 5.3. Volume Control

Use the dedicated volume buttons on the earphones or adjust the volume directly on your connected device.

## 6. MAINTENANCE AND CARE

---

To ensure the longevity and optimal performance of your J-60L earphones, follow these care guidelines:

- **Cleaning:** Wipe the earphones with a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the earphones in their carrying case to protect them from dust and damage.
- **Water Resistance:** The earphones are water-resistant, meaning they can withstand splashes and sweat. Do not submerge them in water or expose them to heavy rain. Dry them thoroughly if they get wet.
- **Temperature:** Avoid exposing the earphones to extreme temperatures (hot or cold) or high humidity.
- **Material:** The earphones are made of Acrylonitrile Butadiene Styrene (ABS).

## 7. TROUBLESHOOTING

---

If you encounter any issues with your earphones, please refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Earphones do not power on.	Low battery.	Charge the earphones fully.
Cannot pair with device.	Earphones not in pairing mode; Bluetooth off on device; device too far.	Ensure earphones are in pairing mode (flashing red/blue). Turn on Bluetooth on your device. Move earphones closer to the device (within 10m). Forget previous pairings on your device and try again.
No sound or low volume.	Volume too low; earphones not connected; incorrect audio output selected.	Increase volume on earphones and connected device. Reconnect earphones. Check audio output settings on your device.
Sound distortion.	Interference; device too far; low battery.	Move away from sources of interference. Move closer to the device. Charge the earphones.

## 8. SPECIFICATIONS

---

Feature	Detail
Model Name	J-60L
Brand	Genérico
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	V5.3
Maximum Operating Distance	10 meters
Frequency Response	40Hz - 20KHz
Sensitivity	106dB SPL ±3dB

Feature	Detail
Impedance	32 Ohm
Battery Type	Rechargeable Lithium Polymer
Average Battery Duration	Up to 5 hours (continuous playback)
Charging Time	Approximately 1.2 hours
Water Resistance Level	Water Resistant
Product Weight	200 Grams
Material	Acrylonitrile Butadiene Styrene (ABS)
Color	White

## 9. WARRANTY AND SUPPORT

### 9.1. Manufacturer's Warranty

This product comes with a **3-month manufacturer's warranty** against manufacturing defects. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

Please retain your proof of purchase for warranty claims.

### 9.2. Customer Support

For any questions, technical assistance, or warranty claims, please contact your retailer or the manufacturer's customer support. Refer to the product packaging or purchase documentation for specific contact details.