

Agrestem EZ06DG

Agrestem EZ06DG Espresso Coffee Maker User Manual

Model: EZ06DG

1. INTRODUCTION

Thank you for choosing the Agrestem EZ06DG Espresso Coffee Maker. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.

2. SAFETY INSTRUCTIONS

- Always ensure the appliance is unplugged before cleaning or maintenance.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Keep the appliance out of reach of children.
- Use only cold, fresh water in the water tank.
- Avoid contact with hot surfaces, such as the steam wand and portafilter, during and after operation.
- Do not operate the appliance if the power cord or plug is damaged.

3. PRODUCT OVERVIEW

The Agrestem EZ06DG is a semi-automatic espresso machine designed for home use, featuring a built-in bean grinder and a steam wand for milk frothing. Key features include:

- One-touch operation for espresso and cappuccino.
- Integrated conical burr grinder with 15 grind settings.
- Powerful 20-bar high-pressure pump for optimal extraction.
- Professional milk frother steam wand for smooth foam.
- Auto-cleaning function for brew group and milk system.
- Removable components for easy maintenance.



Figure 1: Agrestem EZ06DG Espresso Coffee Maker in Dark Gray, showcasing its sleek design and integrated components.

Included Components:

- Espresso coffee maker
- Milk jug
- Cleaning brush & needle
- Removable water tank
- Filter cups (single and double)
- Tamper



Figure 2: All accessories included with the Agrestem EZ06DG Espresso Coffee Maker, such as the milk jug, tamper, and cleaning tools.

4. SETUP

1. **Unpacking:** Carefully remove all packaging materials and ensure all components are present.
2. **Initial Cleaning:** Before first use, wash the water tank, portafilter, filter cups, milk jug, and drip tray with warm soapy water. Rinse thoroughly and dry. Wipe the exterior of the machine with a damp cloth.
3. **Water Tank:** Fill the removable water tank with fresh, cold water up to the MAX line. Place it securely back into the machine.
4. **Bean Hopper:** Fill the bean hopper with your preferred whole coffee beans. Ensure the lid is properly sealed.
5. **Power Connection:** Plug the power cord into a grounded electrical outlet.

5. OPERATING INSTRUCTIONS

5.1 Grinding Coffee Beans

The integrated conical burr grinder allows for precise grinding directly into the portafilter.

1. **Select Grind Setting:** Use the grind setting dial to choose your desired fineness. There are 15 settings available. A finer grind is generally preferred for espresso.
2. **Insert Portafilter:** Place the portafilter with the appropriate filter cup under the grinder outlet.
3. **Start Grinding:** Press the 'GRIND' button to start grinding. The machine will dispense a pre-set amount of coffee. Adjust the grind time if necessary for single or double shots.
4. **Tamp:** Once grinding is complete, remove the portafilter and use the tamper to press the ground coffee firmly and evenly.



Figure 3: Detail of the conical burr grinder, showing freshly ground coffee in the portafilter, ready for tamping.

5.2 Brewing Espresso

After grinding and tamping, you are ready to brew your espresso.

1. **Attach Portafilter:** Securely attach the portafilter to the brew group by twisting it to the right until it locks into place.

2. **Place Cup:** Position your espresso cup(s) on the drip tray directly under the portafilter spouts.
3. **Select Brew:** Press the 'SINGLE' or 'DOUBLE' button for a single or double shot of espresso. The machine will automatically dispense the correct volume.
4. **Enjoy:** Your espresso is now ready.

Guarantee Your Coffee Flavo



Figure 4: Espresso extraction in progress, demonstrating the 20-bar pump's ability to produce rich, flavorful coffee.

5.3 Frothing Milk

The steam wand allows you to create creamy milk foam for lattes and cappuccinos.

1. **Prepare Milk:** Fill the milk jug with cold milk (dairy or non-dairy) to just below the spout.
2. **Activate Steam:** Turn the control knob to the steam icon. Wait for the steam indicator light to illuminate, indicating the machine is ready.
3. **Position Wand:** Immerse the steam wand tip just below the surface of the milk.
4. **Start Frothing:** Turn the control knob to activate steam. Move the jug up and down to incorporate air and create foam. Once desired texture is achieved, immerse the wand deeper to heat the milk.

5. **Stop Steam:** Turn the control knob back to the standby position to stop steaming.
6. **Clean Wand:** Immediately wipe the steam wand with a damp cloth to prevent milk residue from drying. Briefly activate steam again to clear any internal blockages.

Powerful steam wand quickly turns milk into silky smooth microfoam



Figure 5: The professional steam wand in action, creating silky smooth microfoam for milk-based coffee beverages.

5.4 Video Demonstration

Your browser does not support the video tag.

Video 1: This video demonstrates the full process of making espresso and frothing milk using the Agrestem EZ06DG Espresso Coffee Maker, from grinding beans to pouring latte art.

6. CLEANING AND MAINTENANCE

Regular cleaning and maintenance are crucial for the longevity and optimal performance of your espresso machine. The machine features auto-cleaning functions and removable components for ease of use.

- **Daily Cleaning:** Empty and clean the drip tray and coffee waste bin daily. Rinse the portafilter and filter cups after each use. Wipe down the steam wand immediately after frothing.

- **Water Tank:** Clean the water tank weekly with warm soapy water and rinse thoroughly.
- **Brew Group:** The machine performs an auto-cleaning cycle for the brew group during start-up and shutdown. For deeper cleaning, refer to the specific instructions in the full manual for backflushing.
- **Descaling:** Depending on water hardness and usage, descaling will be required periodically. Follow the descaling instructions provided in the comprehensive manual or indicated by the machine's prompts.
- **Grinder Cleaning:** Periodically clean the burrs of the integrated grinder to ensure consistent grind quality. Refer to the full manual for detailed instructions on accessing and cleaning the burrs.

7. TROUBLESHOOTING

If you encounter issues with your Agrestem EZ06DG Espresso Coffee Maker, please consult the following common troubleshooting tips:

- **No Power:** Ensure the power cord is securely plugged into a working electrical outlet. Check the main power switch.
- **No Water Flow:** Check if the water tank is filled and correctly seated. Ensure there are no blockages in the water path or brew group.
- **Espresso Too Slow/Fast:** Adjust the grind setting. A finer grind slows extraction, a coarser grind speeds it up. Ensure proper tamping pressure.
- **No Steam/Weak Steam:** Ensure the steam wand is not clogged. Clean the wand thoroughly. Check if the machine has reached the correct temperature for steaming.
- **Leaking:** Check that the portafilter is correctly inserted and tightened. Inspect seals and gaskets for damage.

For more detailed troubleshooting, please refer to the complete product manual or contact customer support.

8. SPECIFICATIONS

Feature	Specification
Brand	Agrestem
Model Name	EZ06DG
Color	Dark Gray
Product Dimensions	16.61"D x 15.67"W x 18.86"H
Item Weight	25.4 pounds
Coffee Maker Type	Espresso Machine
Style	Semi Automatic
Special Feature	Integrated Coffee Grinder
Specific Uses For Product	Cappuccino
Included Components	Espresso coffee maker, milk jug, cleaning brush & needle, removable water tank, filter cups
Number of Items	1

Feature	Specification
Unit Count	1.0 Count
Coffee Input Type	whole_beans
Capacity	2.8 Liters
UPC	198723848389

9. WARRANTY AND SUPPORT

Your Agrestem EZ06DG Espresso Coffee Maker comes with a manufacturer's warranty. For specific details regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your product or visit the official Agrestem website.

For customer support, technical assistance, or to purchase replacement parts, please contact Agrestem customer service through their official channels. You can also visit the [Agrestem Store on Amazon](#) for more information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question