

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [XINJISHIMIN](#) /

› [XINJISHIMIN Replacement Remote Control User Manual for Nakamichi Car Audio Stereo Systems \(Models NA350iBTR, NA205, NA98, NA355IBT, NA300IR, NA788, NA101, NQ811B, NA85, NAM1710\)](#)

XINJISHIMIN C124100801D03

XINJISHIMIN Replacement Remote Control User Manual

For Nakamichi Car CD DVD Audio Stereo System Receivers

INTRODUCTION

This manual provides instructions for the XINJISHIMIN replacement remote control, designed for use with various Nakamichi car CD DVD audio stereo system receivers. This remote control is compatible with models such as NA350iBTR, NA205, NA98, NA355IBT, NA300IR, NA788, NA101, NQ811B, NA85, and NAM1710. No programming is required for operation; simply insert batteries and begin use.



Image: Overview of the XINJISHIMIN replacement remote control, highlighting its key features such as no programming requirement, oversized buttons, and use of AAA 1.5V batteries.

SETUP

Battery Installation

The remote control requires two (2) AAA 1.5V batteries. Batteries are not included with the remote control and must be purchased separately.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards and remove it.
3. Insert two AAA 1.5V batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Battery type:

AAA 1.5V



Image: The back of the remote control showing the battery compartment open, indicating the correct placement for two AAA 1.5V batteries.

Initial Use

This replacement remote control is designed for immediate use with compatible Nakamichi car audio stereo systems. No complex programming or pairing procedures are required. Once batteries are installed, the remote is ready to operate your device.

OPERATING INSTRUCTIONS

Familiarize yourself with the button layout and functions to effectively control your Nakamichi car audio stereo system.



Image: Detailed diagram of the remote control buttons with their corresponding functions labeled.

- Power Button (Orange, Top Right):**
 Press to turn the unit on or off. Under Radio mode, press and hold to enter Auto Seek mode; press again to enter Manual Seek mode.
- Volume Up/Down Buttons (Green, Top Left/Middle):**
 Press the up arrow to increase volume. Press the down arrow to decrease volume.
- Mute Button (White, Middle Left):**
 Press to mute or restore the audio volume.
- Skip/Fast Forward/Rewind Buttons (White, Middle Row):**
 Under Media playback mode (CD, DVD, USB, iPod/iPhone, SD, Aux-In), press the left arrow to skip to the previous track/file. Press and hold to rewind. Press the right arrow to skip to the next track/file. Press and hold to fast forward.
- SRC (Source) Button (White, Bottom Middle):**
 Press to select available audio sources such as Radio, Disc, USB (USB-iPod/iPhone), SD, or Aux-In.
- AUDIO Button (White, Bottom):**
 Press to access the Audio Menu mode for sound adjustments.

Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or solvents, as these can damage the remote's surface and internal components.

Battery Care

Replace batteries when the remote's performance diminishes or it stops responding. Always use fresh AAA 1.5V batteries. Remove batteries if the remote will not be used for an extended period to prevent leakage and potential damage.

An Industry Secret You Probably Don't Know
Two AAA batteries = 9 Coin Cell batteries.

NEW

***Good design
with AAA 1.5V
high-capacity battery***

Long life: 3-5 years.



OLD

***Bad design
with Coin Cell
low-capacity battery***

Short life: 0.5-1 year.



Image: Comparison illustrating the longer lifespan of AAA 1.5V batteries (3-5 years) compared to coin cell batteries (0.5-1 year), emphasizing the benefit of the remote's design.

TROUBLESHOOTING

- **Remote not responding:**

Check if the batteries are inserted correctly with the correct polarity. Replace old batteries with new AAA 1.5V batteries. Ensure there are no obstructions between the remote control and the car audio

system's infrared receiver.

- **Limited range:**

Ensure batteries are fresh. The remote control operates using infrared (IR) signals, which require a direct line of sight to the receiver.

- **Specific button not working:**

Clean the remote control, especially around the buttons, to ensure no debris is interfering with button presses. If the issue persists, the remote may be faulty.

SPECIFICATIONS

Feature	Detail
Model Number	C124100801D03
Compatible Devices	Nakamichi Car CD DVD Audio Stereo System Receivers (e.g., NA350iBTR, NA205, NA98, NA355IBT, NA300IR, NA788, NA101, NQ811B, NA85, NAM1710)
Battery Type	2 x AAA 1.5V (not included)
Special Features	Oversized buttons, no programming needed
Item Weight	1.06 ounces
Package Dimensions	5 x 2 x 1 inches

WARRANTY AND SUPPORT

For any questions, concerns, or support regarding this replacement remote control, please contact the seller directly through your purchase platform. Specific warranty details may vary and are typically provided by the seller at the time of purchase.