

[manuals.plus](#) /› [GlocalMe](#) /› [GlocalMe UniCord Charging Cable and G4 Pro Mobile Hotspot User Manual](#)

## GlocalMe UniCord & G4 Pro

# GlocalMe UniCord Charging Cable and G4 Pro Mobile Hotspot User Manual

Model: UniCord & G4 Pro

## 1. INTRODUCTION

This manual provides comprehensive instructions for the GlocalMe UniCord Charging Cable and the GlocalMe G4 Pro Mobile Hotspot. The UniCord is an innovative 3-in-1 device combining a 65W charging cable, a Type-C interface, and a global SIM-free roaming WiFi mobile hotspot. The G4 Pro is a 4G LTE mobile hotspot device featuring a 5-inch touch screen. This guide will assist you in setting up, operating, and maintaining both devices to ensure optimal performance and connectivity.

## 2. PRODUCT OVERVIEW

### 2.1 GlocalMe UniCord Charging Cable

The UniCord is designed for convenience, offering charging and internet access simultaneously. It supports 65W superfast charging and includes initial data for immediate use. Its multi-interface compatibility ensures it works with a wide range of USB-C devices.

Power On and Surfing at Once

# GlocalMe Unicord



Image: GlocalMe UniCord Charging Cable with key features such as 4G Cloud SIM technology, 65W power delivery, dual Type-C ports, and a USB-A adapter for broad compatibility.

## 2.2 GlocalMe G4 Pro Mobile Hotspot

The G4 Pro is a portable 4G LTE mobile hotspot that provides internet access in over 200 countries without needing a physical SIM card. It features a 5-inch touch screen for easy navigation and can connect up to 10 devices simultaneously.



Image: GlocalMe G4 Pro Mobile Hotspot showcasing its capabilities, including SIM-free operation, global coverage, multi-device connectivity, and a user-friendly 5-inch touch screen.

### 3. SETUP

#### 3.1 GlocalMe UniCord Initial Setup

- Connect for Power:** Plug the UniCord's USB-C connector into your device (phone, laptop, etc.) and the other end into a compatible power source. The cable will begin charging your device.
- Activate Hotspot:** The UniCord automatically activates its hotspot function when connected to a power source and a device. Look for the GlocalMe network on your device's Wi-Fi settings.
- Connect to Wi-Fi:** Select the UniCord's Wi-Fi network name (SSID) from your device's Wi-Fi list. Enter the password provided on the UniCord device or packaging.

#### 3.2 GlocalMe G4 Pro Initial Setup

- Power On:** Press and hold the power button on the side of the G4 Pro until the screen illuminates.
- Initial Configuration:** Follow the on-screen prompts to select your preferred language and accept the terms of service.
- Connect to Wi-Fi:** On the G4 Pro's touch screen, navigate to the Wi-Fi settings to view the network name

(SSID) and password. On your external device (phone, laptop), search for this SSID and enter the password to connect.

4. **Download GlocalMe App:** For full management of data plans and device settings, download the GlocalMe app from the App Store or Google Play Store.



Image: The GlocalMe mobile application interface, illustrating features for managing your hotspot, purchasing data plans, and accessing customer support.

## 4. OPERATING INSTRUCTIONS

### 4.1 Using the GlocalMe UniCord

- **Charging Function:** Connect the UniCord to your device and a power source. The 65W Power Delivery ensures fast charging for compatible devices.
- **Hotspot Function:** Once powered, the UniCord automatically provides a Wi-Fi hotspot. Connect up to 2 devices. The device intelligently selects the strongest local network.
- **Travel Companion:** The UniCord is designed for portability, offering both power and internet access for various scenarios, including in-car use or outdoor activities.

# Dual-Purpose Gadgets

Enjoy power charging and internet access at once



Image: A user demonstrating the UniCord's capability to charge both a smartphone and a laptop concurrently, highlighting its dual functionality for power and internet.

# Car Essential

Fast charging with mobile WiFi, stay connected on the go



Image: The UniCord in a car environment, charging a smartphone and providing mobile Wi-Fi, illustrating its utility for travel.

## 4.2 Using the GlocalMe G4 Pro

- **Touch Screen Navigation:** Use the 5-inch touch screen to navigate through menus, check data usage, view connected devices, and manage settings.
- **Connecting Devices:** Up to 10 devices can connect to the G4 Pro's Wi-Fi network simultaneously. The network name and password are displayed on the device screen.
- **Data Management:** Monitor your data usage directly on the G4 Pro screen or through the GlocalMe app. Purchase additional data plans as needed.
- **Cloud SIM Technology:** The G4 Pro utilizes Cloud SIM technology, eliminating the need for physical SIM cards and allowing seamless connectivity across various networks globally.

## 5. DATA PLANS AND CONNECTIVITY

Both the UniCord and G4 Pro operate on GlocalMe's global data network. The UniCord comes with 8GB of North American data and 1.1GB of global data. The G4 Pro also includes initial data. Additional data can be purchased through the GlocalMe app.

- **Global Coverage:** Access 4G LTE internet in over 200 countries and regions.

- **SIM-Free:** No physical SIM card or contract is required.
- **Flexible Plans:** Choose from pay-as-you-go, daily, monthly, or GB-based data plans via the GlocalMe app.




Image: A global map illustrating the extensive coverage of GlocalMe's Cloud-SIM 4G Hotspot service across more than 200 countries and regions.

# FLEXIBLE WIFI PLANS

- ★ Pay as you go and get wifi by the day, month or GB
- ★ Choose international or local data plans.
- ★ No contracts, cancel anytime



Image: The GlocalMe G4 Pro and a smartphone screen showing various flexible Wi-Fi data plans available for purchase through the GlocalMe application.

## 6. MAINTENANCE

- Cleaning:** Use a soft, dry cloth to clean the exterior of both devices. Avoid liquid cleaners or abrasive materials.
- Storage:** Store the devices in a cool, dry place away from direct sunlight and extreme temperatures.
- Cable Care:** Avoid sharp bends or excessive pulling on the UniCord cable to prevent damage.
- Software Updates:** Periodically check for firmware updates for the G4 Pro via the GlocalMe app to ensure optimal performance and security.

## 7. TROUBLESHOOTING

### • No Internet Connection:

- Ensure you have an active data plan. Check your data balance via the GlocalMe app or the G4 Pro screen.
- Restart the device (UniCord by unplugging/replugging, G4 Pro by holding the power button).
- Verify that the device is connected to the correct Wi-Fi network and the password is correct.
- Check network signal strength on the G4 Pro screen.

### • Charging Issues (UniCord):

- Ensure both ends of the cable are securely connected.
- Try a different power source or wall adapter.
- Inspect the cable for any visible damage.

- **Device Not Connecting to Hotspot:**

- Ensure the hotspot device (UniCord or G4 Pro) is powered on and broadcasting a Wi-Fi signal.
- Restart your connecting device (phone, laptop).
- Forget the network on your connecting device and try to reconnect.

## 8. SPECIFICATIONS

Feature	Specification
Brand	GlocalMe
Model Name (G4 Pro)	G4 Pro
Item Model Number	65f70e30-c253-4b31-9958-24b62b8e533f
UniCord Charging Power	65W Superfast Charging
Connectivity Technologies	LTE, USB, Wi-Fi
Wireless Communication Standard	802.11.be
Frequency Band Class	Dual-Band
Operating System (G4 Pro)	RouterOS
Security Protocol	WPA2
Antenna Type	Internal
Number of Ports (G4 Pro)	1
Compatible Devices	Laptop, Personal Computer, Smartphone, Tablet
G4 Pro Screen Size	5 inches
UniCord Data Included	8GB North American Data + 1.1GB Global Data

## 9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or visit the official GlocalMe website. For technical support, troubleshooting assistance, or inquiries regarding data plans, please utilize the GlocalMe app's live chat support feature or contact GlocalMe customer service directly. The GlocalMe app provides a convenient platform for managing your devices and accessing support resources.

### Related Documents - UniCord & G4 Pro

	<p><a href="#"><b>GlocalMe TriForce Quick Start Guide: Setup, Features, and Compliance</b></a></p> <p>Comprehensive quick start guide for the GlocalMe TriForce portable WiFi hotspot and power bank. Learn how to set up your device, connect to Wi-Fi, use the power bank feature, and understand safety and compliance information.</p>
	<p><a href="#"><b>GlocalMe K5 User Manual: Setup, Features, and Troubleshooting</b></a></p> <p>Comprehensive user manual for the GlocalMe K5 wireless data terminal, covering setup, technical specifications, quick start guide, FAQs, tariff information, troubleshooting, and safety warnings.</p>
	<p><a href="#"><b>GlocalMe UniCord Pro User Manual and Technical Specifications</b></a></p> <p>Comprehensive user manual for the GlocalMe UniCord Pro, detailing setup, usage, charging, technical specifications, and troubleshooting. Learn how to connect to Wi-Fi, manage data plans, and utilize its charging capabilities.</p>
	<p><a href="#"><b>GlocalMe Numen Air Quick Start Guide: Setup and Usage</b></a></p> <p>Your essential guide to setting up and using the GlocalMe Numen Air mobile WiFi hotspot. Learn to connect via Cloud SIM or physical SIM, manage data plans, and access global internet.</p>
	<p><a href="#"><b>GlocalMe GLMU20A01 User Manual and Quick Start Guide</b></a></p> <p>Comprehensive user manual for the GlocalMe GLMU20A01 portable WiFi hotspot, covering setup, features, technical specifications, and safety guidelines.</p>
	<p><a href="#"><b>GlocalMe G4 Pro/G4 Max User Manual: Setup, Features, and Troubleshooting</b></a></p> <p>Comprehensive user guide for the GlocalMe G4 Pro and G4 Max portable WiFi devices. Learn about setup, account management, data plans, troubleshooting, and technical specifications.</p>