#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- BEARBISU /
- > BEARBISU Digital Camera H15 User Manual

#### **BEARBISU H15**

# **BEARBISU Digital Camera H15 User Manual**

Model: H15

Setup

Operating Instructions

Maintenance Warranty & Support **Troubleshooting** 

**Specifications** 

## 1. SETUP

## 1.1 Package Contents

Verify that all items are present in the package:

- BEARBISU Digital Camera H15
- 64GB SD Card
- Wrist Strap
- Rechargeable Battery
- USB-C Charging Cable
- USB Adapter
- User Manual (this document)



Image 1.1: The BEARBISU Digital Camera H15 shown with its included accessories, including the 64GB SD card, USB adapter, and wrist strap.

#### 1.2 Battery Installation and Charging

- 1. Locate the battery compartment on the bottom of the camera.
- 2. Open the compartment cover.
- 3. Insert the rechargeable battery, ensuring the correct polarity as indicated inside the compartment.
- 4. Close the battery compartment cover securely.
- 5. Connect the camera to a power source using the provided USB-C charging cable and adapter. The charging indicator light will illuminate.
- 6. Charge the camera until the indicator light changes or turns off, signifying a full charge.

#### 1.3 Memory Card Installation

The camera supports SD cards up to 64GB. A 64GB card is included.

- 1. Locate the SD card slot, typically near the battery compartment or on the side of the camera.
- 2. Insert the 64GB SD card into the slot with the metal contacts facing the front of the camera, until it clicks into place.

3. To remove, gently press the card inward until it springs out.

## 1.4 Powering On/Off

- To power on: Press and hold the Power button (usually marked with a circle and a vertical line) until the screen illuminates.
- To power off: Press and hold the Power button again until the screen turns off.

# 2. OPERATING INSTRUCTIONS

## 2.1 Basic Photography (Photo Mode)

The camera captures 44MP photos and 1080p videos.




Image 2.1: The camera's display showing a captured image, illustrating its 1080P video and 44MP photo resolution capabilities.

#### 2.1.1 Taking a Photo

- 1. Ensure the camera is in Photo Mode (indicated by an icon on the screen, typically a camera symbol).
- 2. Frame your subject using the LCD screen.
- 3. Press the Shutter button (usually on top of the camera) halfway down to focus, then fully press to capture the image.

#### 2.1.2 Zoom Function

The camera features 16x digital zoom.

• Use the 'W' (Wide) and 'T' (Telephoto) buttons, typically located near the shutter, to zoom out and zoom in, respectively.



Image 2.2: Demonstrates the camera's 16x digital zoom capability and various creative filters like Normal, Black/White, Warm, and Cold.

The camera includes 20 unique filters to enhance your photos.

- Access the filter options through the camera's menu.
- Navigate using the directional buttons and select your desired filter.

#### 2.1.4 Self-Timer

Utilize the self-timer for group photos or stable shots.

- · Access the self-timer setting in the menu.
- Choose from 2-second, 5-second, or 10-second delays.

## 2.2 Video Recording (Video Mode)

The camera records in Full HD 1080p.

#### 2.2.1 Starting/Stopping Recording

- 1. Switch the camera to Video Mode (indicated by a video camera icon).
- 2. Press the Shutter button to start recording. A red dot or recording indicator will appear on the screen.
- 3. Press the Shutter button again to stop recording.

## 2.2.2 Built-in Microphone

The integrated microphone captures audio during video recording.

#### 2.3 Anti-Shake Function

The anti-shake feature helps reduce blur caused by camera movement.

• This function is typically enabled by default or can be toggled in the camera settings.



Image 2.3: Visual representation of the self-timer options (2s, 5s, 10s), continuous shooting, and the anti-shake function's effect on image clarity.

## 2.4 Webcam Functionality

The camera can function as a webcam when connected to a computer.

- 1. Connect the camera to your computer using the USB-C cable.
- 2. Select 'Webcam Mode' or 'PC Camera' from the options displayed on the camera screen (if prompted).
- 3. Your computer should recognize the camera as a webcam for video conferencing or streaming

applications.

## 3. MAINTENANCE

## 3.1 Cleaning the Camera

- Use a soft, lint-free cloth to clean the camera body.
- For the lens and screen, use a specialized lens cleaning cloth and solution, applying gently to avoid scratches.
- Do not use harsh chemicals or abrasive materials.

## 3.2 Battery Care

- Charge the battery fully before first use.
- Avoid completely draining the battery regularly to prolong its lifespan.
- If storing the camera for an extended period, remove the battery.

## 3.3 Storage

- Store the camera in a cool, dry place away from direct sunlight and extreme temperatures.
- Use a protective case or pouch to prevent dust and scratches.

# 4. TROUBLESHOOTING

Problem	Possible Cause	Solution
Camera does not power on.	Battery is drained or incorrectly inserted.	Ensure battery is fully charged and correctly inserted.
Cannot take photos/videos.	SD card is full, not inserted, or corrupted.	Check SD card storage. Reinsert or replace SD card. Format SD card (this will erase all data).
Images are blurry.	Anti-shake off, insufficient light, or camera movement.	Ensure Anti-Shake is enabled. Use fill light in low light conditions. Hold camera steady.
Poor battery life.	Frequent use of flash/screen, old battery.	Reduce screen brightness. Limit flash use. Consider a replacement battery if performance significantly degrades.
Camera freezes or becomes unresponsive.	Software glitch or memory card issue.	Remove and reinsert the battery. If using an SD card, try removing it and restarting the camera.

## 5. SPECIFICATIONS

Feature	Detail
Model Name	Digital Camera H15

Feature	Detail
Brand	BEARBISU
Photo Sensor Resolution	44 MP
Video Resolution	1080p Full HD
Digital Zoom	16x
Image Stabilization	Digital (Anti-Shake)
Screen Size	2.4 inches
Display Type	LCD Color Screen
Supported File Format	JPEG (Photos), MP4 (Videos)
Memory Storage Capacity	Supports up to 64GB SD Card (32GB listed in specs, but 64GB included)
Connectivity Technology	Micro USB
Battery Type	Lithium Ion
Special Features	Anti Shake, Self Timer, 20 Filters, Fill Light, Webcam Function
Material	Plastic
Color	Green

#### 6. WARRANTY & SUPPORT

## **6.1 Product Warranty**

The BEARBISU Digital Camera H15 comes with a**1-year limited warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product functions as intended under normal use. Please retain your proof of purchase for warranty claims.

#### **6.2 Customer Support**

For any questions, technical assistance, or warranty claims, please contact BEARBISU customer support. You can typically find contact information on the product packaging or through the seller's platform where the camera was purchased.

For more information about BEARBISU products, you may visit the official brand store:BEARBISU Store on Amazon.

© 2025 BEARBISU. All rights reserved.



#### Dreame H15 Mix Wet and Dry Vacuum User Manual

User manual for the Dreame H15 Mix Wet and Dry Vacuum Floor Washer, providing detailed instructions on safety, operation, maintenance, troubleshooting, and specifications for optimal cleaning performance.



#### RAB H15 Series Field-Adjustable LED High Bay Installation Guide

Comprehensive installation instructions for the RAB H15 and H15XL series field-adjustable LED high bay light fixtures. Covers hook, surface, and pendant mounting, field-adjustable CCT and wattage settings, wiring, maintenance, and troubleshooting.



#### Motorola MOTOPURE H15 Universal Flip Bluetooth Headset User Manual

User guide for the Motorola MOTOPURE H15 Universal Flip Bluetooth Headset. Learn how to charge, wear, pair, use multipoint technology, manage calls, understand indicator lights, audio tones, and troubleshoot common issues.



# H15 Bone Conduction Wireless Headset User Manual | Shenzhen Xingren Eucalyptus NetworkCo., Ltd.

Comprehensive user manual for the H15 bone conduction wireless headset, covering features, controls, specifications, charging, safety, and FCC compliance from Shenzhen Xingren Eucalyptus NetworkCo., Ltd.



Comprehensive user manual for the GADMEI H15 3-in-1 Fast Wireless Charger. Provides setup instructions, operation steps, device compatibility, specifications, and FCC compliance information for charging smartphones, Apple Watches, and AirPods.



## NovaStar H15 Video Wall Splicer Specifications

Detailed specifications for the NovaStar H15 Video Wall Splicer, covering its features, input/output cards, dimensions, electrical specifications, and application scenarios.

