FPD CG40-P3

FPD 40-inch 1080p Full HD Google Smart TV (Model CG40-P3) User Manual

Your Guide to Setup, Operation, and Maintenance

1. Introduction

This manual provides essential information for the safe and efficient use of your FPD 40-inch 1080p Full HD Google Smart TV, Model CG40-P3. Please read these instructions thoroughly before operating the device and retain them for future reference.

2. Safety Information

Always follow basic safety precautions when using this product to reduce the risk of fire, electric shock, and injury. Keep the TV away from water, moisture, and heat sources. Ensure proper ventilation and avoid blocking ventilation openings. Use only attachments/accessories specified by the manufacturer. Disconnect the power plug during lightning storms or when unused for long periods.

3. What's in the Box

Verify that all items are present upon unboxing:

- FPD Google TV (Model CG40-P3)
- Remote Control
- AAA Batteries (x2)
- Base Mounting Accessories (TV stands and screws)
- AV Adapter Cable
- User Manual (this document)




Image: FPD 40-inch Google TV dimensions, remote control, and included accessories. This visual guide shows the physical dimensions of the 40-inch FPD TV, its remote control, and other items found in the box like batteries and mounting accessories.

4. Setup

4.1 Physical Setup

1. **Attach the TV Stands:** Carefully place the TV screen-down on a soft, clean surface. Align the TV stands with the designated slots on the bottom of the TV. Secure them using the provided screws and a Phillips screwdriver.
2. **Connect Power:** Plug the power cord into the TV's power input and then into a wall outlet.
3. **Connect External Devices:** Use the available ports (HDMI, USB, AV-in, Optical-out, LAN) to connect your external devices such as gaming consoles, sound systems, or cable boxes.

4.2 Initial Power On & Configuration

1. **Insert Batteries into Remote:** Open the battery compartment on the back of the remote control and insert the

two AAA batteries, ensuring correct polarity.

2. **Power On:** Press the power button on the remote control or on the TV itself.
3. **Google TV Setup:** Follow the on-screen instructions to set up your Google TV. This typically involves:
    - Selecting your language.
    - Connecting to your Wi-Fi network.
    - Signing in with your Google Account to access personalized recommendations and Google Assistant.
    - Accepting terms and conditions.

Video: FPD FHD Google TV. This video demonstrates the initial setup and features of the FPD Full HD Google TV.

5. Operating Your FPD Smart TV

5.1 Google TV Smart OS

Your FPD Smart TV features the Google TV operating system, providing a centralized platform for all your entertainment. It offers a wide range of smart features and a vast library of content.




Image: Google TV home screen with various streaming app icons. The FPD Google TV interface displaying popular streaming applications and personalized content recommendations.

5.2 Google Assistant Voice Remote

Control your entertainment effortlessly using the Google Assistant Voice Remote. Press the dedicated Google Assistant button on your remote and speak your commands for hands-free navigation, content search, and smart home control.

5.3 Chromecast Built-in

Seamlessly stream and cast content from your compatible devices directly to your FPD Google TV. Use Chromecast built-in to wirelessly connect and enjoy your favorite content from your phone, tablet, or computer.




Image: Smartphone screen mirroring to FPD Google TV via Google Cast. A smartphone wirelessly casting content, including gaming and music, to the FPD Google TV using Google Cast.

5.4 Picture & Sound Quality

Experience crisp images and vibrant colors with Full HD 1080p resolution and HDR10 support. The TV also features

Dolby Audio for enhanced sound quality, delivering clear dialogue and dynamic audio.




Image: Comparison of 1080p Full HD and 720p HD picture quality on FPD TV. An image illustrating the enhanced clarity and detail of 1080p Full HD compared to 720p HD on the FPD TV.



Image: FPD TV displaying a snowy mountain scene with Dolby Audio sound waves. The FPD TV highlighting its Dolby Audio capabilities, enhancing the sound experience for movies and other content.

5.5 Connections

The FPD Smart TV offers a variety of connectivity options:

- HDMI 1.4 (x2)
- USB 2.0 (x2)
- AV-in (x1)
- Optical-out (x1)
- LAN (Ethernet) (x1)
- Earphone Jack
- Bluetooth 5
- WI-FI 5

6. Maintenance

To ensure the longevity and optimal performance of your FPD Smart TV, follow these maintenance guidelines:

- **Cleaning the Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, lightly dampen the cloth with water or a screen-specific cleaning solution. Avoid harsh chemicals or abrasive materials.
- **Cleaning the Body:** Use a soft, dry cloth to clean the TV's casing.
- **Ventilation:** Ensure that the ventilation openings on the TV are not blocked to prevent overheating.
- **Power Cord:** Regularly check the power cord for any damage. If damaged, contact customer support for replacement.

7. Troubleshooting

If you encounter issues with your FPD Smart TV, refer to the following common solutions:

Problem	Possible Solution
No Power	Check if the power cord is securely plugged into both the TV and the wall outlet. Ensure the outlet is functional.
No Picture/Sound	Verify that the correct input source is selected. Check all cable connections to external devices.
Remote Not Working	Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the TV.
Wi-Fi Connection Issues	Restart your router and modem. Re-enter your Wi-Fi password on the TV. Ensure the TV is within range of your Wi-Fi signal.
Apps Not Loading	Check your internet connection. Try restarting the TV. Clear the cache for the problematic app in the TV settings.

If the issue persists, please contact FPD customer support.

8. Specifications

Feature	Detail
Brand	FPD
Model Number	CG40-P3
Screen Size	40 Inches
Display Technology	LCD
Resolution	1080p Full HD
Refresh Rate	60 Hz
Special Features	Google TV Smart OS, Google Assistant Voice Remote, Chromecast Built-in, HDR 10, Dolby Audio
Connectivity Technology	Bluetooth 5, Ethernet, HDMI (x2), USB (x2), Wi-Fi 5

Feature	Detail
Product Dimensions	35.16"W x 20.98"H x 6.77"D (with stand)
Item Weight	15.75 pounds

9. Warranty and Support

Your FPD Smart TV comes with an industry-leading 1-year warranty. FPD is committed to providing excellent customer service.
For any product issues or technical assistance, please contact FPD directly via Amazon messages. Our customer service team aims to reply within 24 hours to help resolve your problem as soon as possible. We also provide regular software updates to ensure your FPD TV performs at its best.