Zlinke Geshini Ice Maker

Zlinke Countertop Ice Maker Machine

User Manual

Introduction

Thank you for choosing the Zlinke Countertop Ice Maker Machine. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and retain it for future reference.
This compact and efficient ice maker is designed to produce bullet-shaped ice quickly, providing a steady supply for your beverages and other needs. Its user-friendly design and self-cleaning function ensure convenience and ease of use.

Important Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using this appliance:

- Read all instructions before use.
- Do not touch the evaporator or ice blades when the unit is operating.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Supervise children closely when the appliance is in use.
- Unplug the ice maker from the outlet when not in use or before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only potable water for ice production.
- Ensure proper ventilation around the unit. Maintain at least 5 inches of space on all sides.
- Do not use outdoors.

Product Overview



Image: The Zlinke Countertop Ice Maker Machine in steel finish, showcasing its compact and modern design.

Components Included:

- Zlinke Countertop Ice Maker Machine
- Ice Basket
- Ice Scoop



Image: The ice maker with its removable ice basket and included ice scoop, highlighting its portable mini size.

Setup

1. **Unpacking:** Carefully remove the ice maker from its packaging. Remove all packing materials, including any tape or protective film.
2. **Placement:** Place the ice maker on a stable, level surface away from direct sunlight and heat sources (e.g., stoves, furnaces, radiators). Ensure there is at least 5 inches of clear space around the unit for proper ventilation.
3. **Initial Cleaning:** Before first use, clean the interior of the ice maker. Refer to the "Maintenance" section for detailed cleaning instructions.
4. **First Use Preparation:** After cleaning, fill the water reservoir with potable water up to the MAX fill line. Do not overfill.
5. **Power Connection:** Plug the power cord into a grounded electrical outlet.

Operating Instructions



Image: Close-up of the ice maker's simple operation panel with LED indicators.

1. **Power On:** Press the "ON/OFF" button to turn on the ice maker. The indicator light will illuminate.
2. **Ice Production:** The ice maker will automatically begin the ice-making cycle. The first batch of ice typically takes 6-8 minutes to produce.
3. **Monitoring:** The unit features LED indicators to show its status. The "ICE FULL" indicator will light up when the ice basket is full, and the machine will automatically pause. The "ADD WATER" indicator will light up when the water reservoir is low, and the machine will pause.
4. **Adding Water:** If the "ADD WATER" indicator is on, add more potable water to the reservoir. The machine will automatically resume operation after water is added.
5. **Removing Ice:** Use the provided ice scoop to remove ice from the basket.
6. **Automatic Shut-Off:** The ice maker will automatically shut off when the ice basket is full or when the water level is too low.
7. **Power Off:** Press the "ON/OFF" button again to turn off the ice maker.



Image: A view inside the ice maker showing the ice-making process, producing 9 bullet-shaped ice pieces in approximately 6 minutes.

Maintenance

Regular cleaning and maintenance will ensure the longevity and optimal performance of your ice maker.

Daily Cleaning:

- After each use, drain any remaining water from the reservoir.
- Wipe the interior and exterior surfaces with a soft, damp cloth.

Self-Cleaning Function:

The Zlinke ice maker is equipped with a convenient self-cleaning function:

1. Ensure the water reservoir is filled with clean water.
2. Press and hold the "CLEAN" button (if available, or refer to specific model instructions for self-clean activation). The

machine will run a cleaning cycle, circulating water through its system.

3. Once the cycle is complete, drain the water and wipe the interior dry.

Deep Cleaning (Monthly or as needed):

- Unplug the unit.
- Prepare a solution of water and a small amount of mild detergent or vinegar.
- Pour the solution into the water reservoir and run a self-cleaning cycle, or manually clean all accessible interior parts with a soft brush or cloth.
- Drain the solution completely.
- Rinse the interior thoroughly with clean water multiple times to remove any residue.
- Dry all parts before reassembling or storing.

Storage:

If storing the ice maker for an extended period, ensure it is completely dry to prevent mold or mildew growth. Store in a cool, dry place.

Troubleshooting

Before contacting customer support, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Ice maker not turning on	No power; loose plug	Check power outlet; ensure plug is securely inserted.
"ADD WATER" indicator is on	Water reservoir is empty or low	Add potable water to the reservoir up to the MAX fill line.
"ICE FULL" indicator is on	Ice basket is full	Remove ice from the basket. The machine will resume automatically.
No ice production or small ice	Insufficient water; ambient temperature too high; ventilation blocked	Ensure sufficient water; place in a cooler environment; clear ventilation openings.
Unusual noise during operation	Unit not level; internal component issue	Ensure the unit is on a level surface. If noise persists, contact customer support.

Specifications



Image: Visual representation of the ice maker's dimensions and key capacities.

Feature	Detail
Model Name	Geshini Ice Maker
Product Dimensions	12"D x 9"W x 13"H (approx. 11.42 x 12.6 x 9.45 inches)
Weight	14.85 Pounds
Ice Production Capacity	Up to 26.5 lbs per 24 hours
Ice Making Cycle	6-8 minutes per cycle (9 bullet ice cubes)
Water Reservoir Capacity	1.3 Liters (approx. 1.1L water tank capacity)
Voltage	115V
Manufacturer	Zlinke

Warranty and Support

Your Zlinke Countertop Ice Maker Machine is covered by a manufacturer's warranty. Please refer to the warranty card included with your product for specific terms and conditions, including the warranty period and coverage details.
For technical support, troubleshooting assistance beyond this manual, or warranty claims, please contact Zlinke customer service through the retailer where the product was purchased or visit the official Zlinke website for contact information.

© 2025 Zlinke. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question