

## HOOBRO EBF15KXG01G1

# HOOBRO 120 cm Narrow Console Table with Power Outlets and USB Ports, Model EBF15KXG01G1 Instruction Manual

### INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your HOOBRO 120 cm Narrow Console Table, Model EBF15KXG01G1. This console table is designed for use in various spaces such as entryways, hallways, or behind a sofa, offering a convenient surface and integrated charging capabilities.

### IMPORTANT SAFETY INFORMATION

- Do not use appliances with power greater than 1500W with the integrated power outlets. Exceeding this limit may cause electrical overload and damage.
- Follow all assembly instructions carefully to ensure the table's stability and prevent injury.
- Place the table on a flat, stable surface.
- Keep the power cord away from heat sources, water, and sharp edges.
- Do not allow children to climb on or play with the table.

### PACKAGE CONTENTS

Before assembly, ensure all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Tabletop (Engineered Wood)
- Metal Frame Components (Legs, Crossbars)
- Power Outlet Module (2 AC outlets, 2 USB ports, 150 cm power cord)
- Adjustable Feet
- Assembly Hardware (Screws, Allen Wrench)
- Instruction Manual

### SPECIFICATIONS

Feature	Detail
Brand	HOOBRO
Model Number	EBF15KXG01G1
Product Dimensions	120 cm (W) x 15 cm (D) x 79.5 cm (H) / 47.2 x 6 x 31.3 inches
Material	Thick Particleboard, Metal Frame
Item Weight	5 Kilograms
Power Outlets	2 AC Outlets, 2 USB Ports
Power Cord Length	150 cm (59 inches)
Special Features	Adjustable Feet, Integrated Charging Station

### ASSEMBLY INSTRUCTIONS

Assembly is designed to be straightforward. Please follow the numbered steps and refer to the diagrams for guidance. All necessary tools are included.

- Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface to prevent scratches. Refer to the included parts list to ensure all pieces are present.
- Assemble the Metal Frame:** Attach the vertical leg components to the horizontal crossbars using the provided screws and Allen wrench. Ensure all connections are secure but do not overtighten initially.

## Heavy-duty Metal Frame

Hardworking materials will bring years of enjoyment.



Image: Detail of the robust metal frame construction.

3. **Attach the Tabletop:** Carefully align the tabletop with the assembled metal frame. Secure the tabletop to the frame using the designated screws. Ensure the power outlet slot is correctly positioned.
4. **Install the Power Outlet Module:** Insert the power outlet module into the pre-cut slot on the tabletop. Secure it with the small screws provided.
5. **Attach and Adjust Leveling Feet:** Screw the adjustable feet into the bottom of each leg. Once the table is in its desired location, rotate the feet to level the table and prevent wobbling on uneven floors.



Image: Adjustable feet for stability on various surfaces.

6. **Final Tightening:** Once fully assembled and leveled, go back and securely tighten all screws. Do not overtighten to avoid damaging the materials.



Image: Overall dimensions of the console table.

## OPERATING INSTRUCTIONS

The HOOBRO console table features an integrated charging station for your convenience.


1. **Connect to Power:** Plug the table's 150 cm (59 inch) power cord into a standard wall outlet.
2. **Using AC Outlets:** Insert the power plug of your electronic device (e.g., lamp, laptop charger) into one of the two AC outlets on the module. Ensure the device's power consumption does not exceed 1500W.
3. **Using USB Ports:** Connect your USB charging cable to one of the two USB ports on the module, then connect the other end to your smartphone, tablet, or other USB-powered device.



**Power Cord**  
- 150cm -



**2 USB Ports**



**1 AC Outlet**

Image: Detail of the charging station with AC and USB ports.





Image: Example of the console table in use, charging devices.

## MAINTENANCE

To keep your HOOBRO console table in optimal condition:

- **Cleaning:** Wipe the surfaces with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Immediately wipe up any spills to prevent water damage to the engineered wood.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Power Module:** Keep the power outlets and USB ports free from dust and debris. Do not attempt to disassemble the power module.

## TROUBLESHOOTING

If you encounter any issues with your console table, refer to the following common solutions:

- **Table is Wobbly:** Ensure all assembly screws are fully tightened. Adjust the leveling feet on the bottom of the legs until the table is stable on the floor.
- **Power Outlets/USB Ports Not Working:**

- Verify that the table's main power cord is securely plugged into a functional wall outlet.
- Check if the wall outlet itself is working by plugging in another device.
- Ensure the total power draw of connected devices does not exceed 1500W.
- For USB charging, try a different USB cable or device to rule out a faulty cable/device.
- **Difficulty Assembling:** Review the assembly instructions and diagrams carefully. Ensure you are using the correct hardware for each step. Do not force parts together.

## WARRANTY AND SUPPORT

---

HOOBRO products are designed for quality and durability. For specific warranty information, please refer to the terms and conditions provided at the time of purchase or visit the official HOOBRO website. If you require technical assistance, have questions about assembly, or need to report a missing/damaged part, please contact HOOBRO customer service through your purchase platform or the contact information available on the official HOOBRO website.