pnochoo XGB0001

User Manual: 38.2" Rectangle Lift Top Coffee Table

Brand: pnochoo | Model: XGB0001

1. Introduction

Thank you for choosing the pnochoo 38.2" Rectangle Lift Top Coffee Table. This Mid-Century Modern fluted wood center table is designed to enhance your living space with both style and functionality. It features a unique lift-top mechanism that reveals hidden storage, making it convenient for dining, gaming, or working. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure you get the most out of your new furniture.



Figure 1.1: The pnochoo Lift Top Coffee Table with its top lifted, revealing ample storage space and providing a comfortable surface for various activities.

2. Setup and Assembly

The pnochoo Lift Top Coffee Table is designed for straightforward assembly. Please follow these steps carefully to ensure proper construction and stability. It is recommended to have a second person assist during certain steps, especially when attaching the lift-top mechanism.

2.1 Unpacking and Component Check

- Carefully unpack all components from the box.
- Verify that all parts listed in the assembly guide are present and undamaged. Refer to the included 'Assembly Guide' for a complete list of parts and hardware.
- Lay out all wooden panels and hardware on a clean, soft surface (e.g., a rug or blanket) to prevent scratches.

2.2 Assembly Steps

1. Begin by assembling the main body of the table, connecting the side panels to the base using the

provided screws and dowels. Ensure all connections are secure.

2. Attach the four sturdy legs to the bottom of the table body. Make sure they are firmly tightened to provide stable support.
3. Install the lift-top mechanism hardware inside the table body. Follow the diagrams in the assembly guide for correct orientation and screw placement.
4. Carefully align the lift-top with the installed mechanism and secure it. This step may require two people to hold the top steady while attaching.
5. Once assembled, gently test the lift-top mechanism to ensure smooth operation.

Tools Recommended For Assembly: Hammer (as per product specifications). Additional tools like a screwdriver may be helpful.

3. Operating Instructions

3.1 Lift-Top Functionality

The coffee table features a functional lift-top mechanism that allows you to adjust the tabletop height for various uses. To lift the top, gently pull it upwards from the front edge. The smooth gas mechanism will assist in raising the top to a comfortable height for dining, working on a laptop, or playing board games. The lift-top is designed to support up to 44 lbs when raised.



Figure 3.1: Demonstration of the lift-top design, showing the table in both closed and lifted positions.

To lower the top, gently push it downwards. The mechanism will smoothly guide it back into the closed position. When the top is lowered, the table can bear an impressive 88 lbs, providing ample support for decorative items or drinks.

3.2 Hidden Storage Compartment

Beneath the lift-top, the table offers a spacious hidden storage compartment. This area is perfect for discreetly stowing away items such as remote controls, magazines, blankets, gaming accessories, snacks, or books, helping to keep your living room organized and clutter-free.



Figure 3.2: The hidden storage compartment, ideal for organizing various living room essentials.

3.3 Weight Capacity

The table has the following weight capacities:

- **Table Surface (when not lifted):** 88 lbs
- **Lift-Top Surface (when lifted):** 44 lbs
- **Overall Maximum Weight Recommendation:** 110 lbs



Figure 3.3: Product dimensions and weight capacity details.

4. Maintenance

To ensure the longevity and appearance of your pnochoo coffee table, follow these maintenance guidelines:

- **Cleaning:** Wipe the surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as they can damage the walnut finish.
- **Spills:** Clean up spills immediately to prevent staining. The table is stain-resistant, but prompt cleaning is always recommended.
- **Protection:** Use coasters under drinks and placemats under hot items to protect the surface from heat and moisture rings.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration over time.
- **Stability:** Periodically check and tighten all screws and connections to maintain stability.

5. Troubleshooting

If you encounter any issues with your coffee table, please refer to the following common troubleshooting tips:

- **Table Wobbles:** Ensure all legs are securely attached and tightened. Check that the table is placed

on a flat, even surface. Adjust leg levelers if present.

- **Lift-Top Mechanism Sticking:** Ensure no objects are obstructing the mechanism. Check that all screws on the lift mechanism are properly tightened. Do not force the lift-top.
- **Scratches on Surface:** While the table is designed for durability, the top might be susceptible to scratches. Use dish mats or protective coverings for items placed on the surface.
- **Parts Missing/Damaged:** If any parts were missing or damaged upon arrival, please contact customer support immediately for assistance.

Important Safety Warnings:

- Ensure stable placement to prevent tipping.
- Be aware of pinch points during assembly and operation of the lift-top mechanism.
- Adhere strictly to the specified weight limits for the lift-top mechanism and overall table to prevent damage or injury.

6. Specifications

Feature	Detail
Brand	pnochoo
Model Name	XGB0001
Product Dimensions (D x W x H)	20.9"D x 38.2"W x 16.5"H
Item Weight	80 Pounds
Maximum Weight Recommendation	110 Pounds
Color	Walnut
Material Type	Wood (Engineered Wood frame, Walnut Wood top)
Shape	Rounded Rectangular
Style Name	Mid-Century Modern
Included Components	Assembly Guide, Installation Tool
Is Stain Resistant	Yes
Indoor Outdoor Usage	Indoor

7. Warranty and Support

For specific warranty information regarding your pnochoo Lift Top Coffee Table, please refer to the documentation included with your purchase or contact the manufacturer directly. Warranty terms typically cover manufacturing defects and material flaws under normal use.

If you require assistance with assembly, have questions about product functionality, or need to report a defect, please contact the seller, Nuoqi Home, or the manufacturer, SULIVES, through the platform where you purchased the product. They will be able to provide the most accurate and timely support.

Return Policy: This product typically has a 30-day easy return policy for refunds or replacements, as per the seller's terms.

© 2024 pnochoo. All rights reserved.