

## ULTECHNOVO K75PYE1NJ119E521568FLQFW

# ULTECHNOVO Wired Car Audio Navigation Multifunction Control Button User Manual

Model: K75PYE1NJ119E521568FLQFW

Brand: ULTECHNOVO

## 1. INTRODUCTION

This manual provides comprehensive instructions for the ULTECHNOVO Wired Car Audio Navigation Multifunction Control Button. This device is designed to offer convenient control over your car's audio and navigation systems, enhancing user experience with easy-to-access functions like volume adjustment, track selection, and mute.

Please read this manual thoroughly before installation and operation to ensure proper use and longevity of the product.

## 2. PRODUCT FEATURES

- **Multifunction Control:** Integrates mute, volume up/down, and next/previous track/station selection.
- **Wired Connection:** Ensures stable and reliable communication with your car's audio/navigation system.
- **Easy Installation:** Features a sticky design for secure mounting.
- **Durable Construction:** Made from nylon and plastic materials for long-lasting use.
- **Compact Design:** Ergonomic shape for comfortable handling and stable use.

## 3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x ULTECHNOVO Wired Car Audio Navigation Multifunction Control Button

## 4. SETUP AND INSTALLATION

The control button is designed for straightforward installation. Ensure your vehicle's power is off before beginning any wiring procedures.



**Figure 4.1:** Visual guide illustrating the installation process of the control button, including mounting and wiring steps.

- 1. Mounting:** Identify a suitable, easily accessible location on your steering wheel or dashboard. The control button features a sticky backing for secure attachment. Clean the surface thoroughly before applying.
- 2. Wiring Connection:**
  - Locate the audio/navigation system's control input wires in your vehicle. Consult your vehicle's service manual if unsure.
  - Connect the red wire from the control button to the positive (ACC) power supply.
  - Connect the black wire from the control button to the ground (GND) of your vehicle's electrical system.
  - Connect the remaining signal wire(s) from the control button to the corresponding input(s) on your car's audio/navigation unit. This connection may vary depending on your specific car model and head unit. Professional installation is recommended if you are unfamiliar with car electrical systems.
- 3. Test Functionality:** After installation, turn on your vehicle's power and test all functions (volume, mute, track selection) to ensure correct operation.



Figure 4.2: Top view of the control button, showing the wired connection for power and signal.

## 5. OPERATING INSTRUCTIONS

Once installed and connected, the control button provides intuitive access to common audio and navigation functions.



Figure 5.1: Close-up view of the control button's interface, highlighting the function labels.

- **Volume Up (VOL+):** Press the "VOL+" button to increase the audio volume.
- **Volume Down (VOL-):** Press the "VOL-" button to decrease the audio volume.
- **Mute ( ):** Press the mute button to silence the audio output. Press again to unmute.
- **Next Track/Station ( ):** Press this button to skip to the next track, station, or menu item.
- **Previous Track/Station ( ):** Press this button to go back to the previous track, station, or menu item.

The specific response of each button may depend on the compatibility and configuration of your car's audio and navigation system.

## 6. MAINTENANCE

To ensure the longevity and optimal performance of your control button, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the surface of the control button with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as these can damage the material and markings.
- **Environmental Conditions:** Avoid exposing the device to extreme temperatures, direct sunlight for prolonged periods, or excessive moisture.

- **Secure Mounting:** Periodically check that the control button remains securely attached to its mounting surface.

## 7. TROUBLESHOOTING

If you encounter issues with your ULTECHNOVO control button, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Button functions are unresponsive.	<ul style="list-style-type: none"> <li>Incorrect wiring.</li> <li>Loose connection.</li> <li>Incompatibility with car audio/navigation system.</li> </ul>	<ul style="list-style-type: none"> <li>Verify all wires are correctly connected according to the installation instructions.</li> <li>Check for any loose connections at the button or the head unit.</li> <li>Consult your car audio/navigation system's manual for compatibility requirements.</li> </ul>
Intermittent functionality.	<ul style="list-style-type: none"> <li>Poor wire contact.</li> <li>Power fluctuations.</li> </ul>	<ul style="list-style-type: none"> <li>Ensure all wire connections are firm and secure.</li> <li>Check vehicle's electrical system for stable power supply.</li> </ul>
Button does not stick to surface.	<ul style="list-style-type: none"> <li>Surface not clean.</li> <li>Adhesive worn out.</li> </ul>	<ul style="list-style-type: none"> <li>Clean the mounting surface thoroughly with an alcohol wipe and let it dry before applying.</li> <li>Use a new strong automotive-grade adhesive if the original is no longer effective.</li> </ul>

## 8. SPECIFICATIONS

<b>Brand</b>	ULTECHNOVO
<b>Model Number</b>	K75PYE1NJ119E521568FLQFW
<b>Material</b>	Nylon, Plastic
<b>Color</b>	Black
<b>Product Dimensions</b>	4.53 x 1.77 x 1.57 inches (approx. 11.5 x 4.5 x 4 cm)
<b>Item Weight</b>	2.4 ounces (approx. 0.15 lbs)

*Note: Dimensions and weight are approximate and may vary slightly.*