

ELC 43Z1

ELC 43Z1 43 Inch FHD Smart LED TV User Manual

Model: 43Z1

[Safety Instructions](#) [Package Contents](#) [Product Overview](#) [Setup](#) [Operating](#)
[Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all safety and operating instructions carefully before using this television. Keep these instructions for future reference.

- **Power Source:** Connect the TV only to the power supply indicated on the label.
- **Ventilation:** Ensure proper ventilation. Do not block ventilation openings.
- **Water and Moisture:** Do not expose the TV to rain or moisture. Do not place objects filled with liquids, such as vases, on the TV.
- **Heat:** Keep the TV away from heat sources such as radiators, heat registers, stoves, or other heat-producing appliances.
- **Cleaning:** Unplug the TV from the wall outlet before cleaning. Use a soft, dry cloth. Do not use liquid cleaners or aerosol cleaners.
- **Lightning:** Unplug the TV during lightning storms or when unused for long periods.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.
- **Placement:** Place the TV on a stable, flat surface. Avoid placing it in direct sunlight or near strong magnetic fields.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package. If any items are missing or damaged, contact your retailer.

- ELC 43Z1 43 Inch FHD Smart LED TV
- Remote Control
- TV Stand (2 pieces)
- Power Cord
- User Manual (this document)
- Screws for stand assembly

3. PRODUCT OVERVIEW

The ELC 43Z1 is a 43-inch Full HD (1920x1080) Smart LED TV, offering a clear picture and a 60 Hz refresh rate. It features integrated Wi-Fi, runs on Android 12.0, and supports popular internet services like Netflix, YouTube, Watchit, and Jawwwy TV. The TV is equipped with multiple connectivity options for various devices.

Front View



This image shows the front of the ELC 43Z1 Smart LED TV, powered on and displaying its main user interface. The screen shows various applications such as Netflix, YouTube, and an app store, along with input options like HDMI and AV. The frameless design is visible, providing an immersive viewing experience.

Rear View and Connectivity Ports



This image displays the rear panel of the ELC 43Z1 TV, highlighting the available connectivity ports. From left to right, you can see the antenna input, multiple HDMI ports (3 total), USB ports (2 total), AV input, coaxial audio output, and a VGA port. These ports allow connection to various external devices such as gaming consoles, Blu-ray players, sound systems, and computers.

4. SETUP

4.1 Attaching the TV Stand

To attach the included stand to your ELC 43Z1 TV:

1. Carefully place the TV screen-down on a soft, clean surface to prevent scratches.

2. Align each stand piece with the corresponding slots on the bottom rear of the TV.
3. Secure each stand piece using the provided screws. Ensure they are tightened firmly.
4. Gently lift the TV and place it on a stable, level surface.



This image shows the back of the ELC 43Z1 TV, illustrating the designated areas for attaching the stand legs or a VESA-compatible wall mount. The screw holes for the stand are clearly visible at the bottom corners, and the central square pattern indicates the VESA mounting points.

4.2 Wall Mounting (Optional)

If you prefer to wall mount your TV, ensure you use a VESA-compatible wall mount kit (not included) that supports the 100 x 200 mm standard. Follow the instructions provided with your wall mount kit. Always ensure the wall can support the weight of the TV and the mount.

4.3 Connecting External Devices

Refer to the 'Rear View and Connectivity Ports' image in Section 3 for port locations.

- **HDMI:** Connect Blu-ray players, gaming consoles, or set-top boxes to the HDMI ports (HDMI 1, HDMI 2, HDMI 3) for high-definition video and audio.
- **USB:** Insert USB flash drives or external hard drives into the USB ports (2 total) to play media files or update firmware.
- **AV Input:** Use the AV input for older devices like VCRs or DVD players that use composite video and stereo audio cables.
- **VGA:** Connect a computer to the VGA port for use as a monitor.
- **Coaxial:** Connect an antenna or cable TV source to the coaxial input for broadcast channels.
- **Power:** Connect the power cord to the TV's power input and then to a wall outlet.

5. OPERATING INSTRUCTIONS

5.1 Remote Control Overview

The remote control allows you to operate all functions of your ELC 43Z1 TV.



This image shows the remote control for the ELC 43Z1 TV. Key buttons include Power (red, top left), Number buttons (0-9), Volume Up/Down, Channel Up/Down, Navigation (arrow keys and OK button), Home, Source, and dedicated buttons for various smart TV functions and media playback controls.

5.2 Initial Setup

1. **Power On:** Press the **Power** button on the remote control or the TV.
2. **Language Selection:** Follow the on-screen prompts to select your preferred language.
3. **Network Connection:** Connect the TV to your home Wi-Fi network. Select your network from the list and enter the password.
4. **Channel Scan:** If connecting an antenna or cable, perform an automatic channel scan to find available channels.
5. **Time Zone:** Set the correct time zone and date.

5.3 Smart TV Features

- **Accessing Apps:** From the home screen, navigate to and select desired applications such as Netflix, YouTube, Watchit, or Jawwy TV.
- **Internet Browsing:** Use the built-in web browser to access websites.
- **Media Playback:** Connect a USB device to play photos, videos, or music directly on the TV.

5.4 Input Source Selection

Press the **Source** button on the remote control to cycle through available input sources (HDMI 1, HDMI 2, HDMI 3, AV, VGA, TV).

6. MAINTENANCE

6.1 Cleaning the TV

- **Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, lightly dampen the cloth with water or a specialized screen cleaner (ensure it's safe for LED screens). Do not spray liquid directly onto the screen.
- **Body:** Wipe the TV's body with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- **Before Cleaning:** Always unplug the TV from the power outlet before cleaning.

6.2 Storage

If you need to store the TV for an extended period, ensure it is unplugged, clean, and stored in a dry, dust-free environment. Use the

original packaging if available to protect it from damage.

7. TROUBLESHOOTING

Before contacting customer support, try the following solutions for common issues:

Problem	Possible Cause	Solution
No power	Power cord disconnected; Power outlet not working	Ensure power cord is securely connected. Test the outlet with another device.
No picture, but sound is present	Incorrect input source; Loose HDMI/AV cable	Press the 'Source' button to select the correct input. Check cable connections.
No sound, but picture is present	Volume too low or muted; External audio system issue	Increase volume or unmute. Check connections to external audio devices.
Remote control not working	Dead batteries; Obstruction between remote and TV	Replace batteries. Remove any obstructions. Ensure remote is pointed at the TV's IR sensor.
Cannot connect to Wi-Fi	Incorrect password; Router issue; TV too far from router	Verify Wi-Fi password. Restart your router. Move TV closer to router or use a Wi-Fi extender.

8. TECHNICAL SPECIFICATIONS

Feature	Detail
Brand	ELC
Model Name / Number	43Z1
Screen Size	43 Inch
Display Technology	LED
Resolution	Full HD (1920x1080)
Refresh Rate	60 Hz
Operating System	Android 12.0
Smart Connectivity	Wi-Fi (1+8GB)
Supported Internet Services	Netflix, YouTube, Watchit, Jawwwy TV
Total HDMI Ports	3
Total USB Ports	2
Other Connectivity	AV Input, VGA, Coaxial Audio Output
Aspect Ratio	16:9
Image Contrast Ratio	1200:1
Max Screen Brightness	220 cd/m²
Response Time	8 ms
Product Dimensions (DxWxH)	7.2 x 95.7 x 55.4 cm

Feature	Detail
Item Weight	7.4 kg
Color	Black
Mounting Type	Tabletop
VESA Mounting Standard	100 x 200 mm
Included Components	Remote control, Stand
Manufacturing Year	2024

9. WARRANTY AND SUPPORT

9.1 Product Warranty

This ELC 43Z1 Smart LED TV is eligible for a **two-year warranty** provided by the manufacturer/brand from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. For specific details regarding warranty claims, coverage, and service procedures, please contact the manufacturer or the seller directly. Keep your proof of purchase (receipt or invoice) as it will be required for any warranty service.

9.2 Customer Support

If you encounter any issues that cannot be resolved using the troubleshooting guide in this manual, or if you require further assistance, please contact ELC customer support or your authorized retailer. Have your TV model number (43Z1) and serial number ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question