



Manuals.plus /

› Kinhank /

› Kinhank Super Console X4 Plus Retro Gaming Console User Manual

## Kinhank Super Console X4 Plus

# Kinhank Super Console X4 Plus Retro Gaming Console User Manual

Model: Super Console X4 Plus

## INTRODUCTION

---

The Kinhank Super Console X4 Plus is a versatile retro gaming console designed to provide a comprehensive entertainment experience. It integrates three operating systems: EmuELEC 4.6 for retro gaming, Android 11.0 for smart TV functionalities, and CoreELEC for media playback. Powered by an S905X4 chip, it supports 4K HD video output and features a built-in cooling fan for optimal performance.



**S905X**

**S905X2**

**S905X3**

**S905X4**

**UPGRADE AMLOGIC S905X4 CHIP**

Quad core ARM Cortex-A55 CPU, up to 2.0Hz

Image: The S905X4 chip, the core processor of the Super Console X4 Plus, is shown with its architecture. This chip provides the processing power for gaming and multimedia functions.

## PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- Super Console X4 Plus Game Console
- Wireless Gamepad (x2)
- Remote Control
- TF Card (pre-installed with games and systems)
- HD Cable
- Power Adapter
- User Manual (this document)



Image: All components included in the Super Console X4 Plus package are displayed. This includes the console unit, two wireless gamepads, a remote control, an HD cable, a power adapter, a TF card, and the user manual.

## SETUP

---

1. **Connect to TV:** Connect the console to your television or monitor using the provided HD cable. Ensure the HD cable is securely plugged into the console's HD output port and an available HD input port on your display.
2. **Power Connection:** Connect the power adapter to the console's power input port and then plug the adapter into a power outlet.
3. **Insert TF Card:** Ensure the TF card is properly inserted into the console's TF card slot. The operating systems and games are stored on this card.
4. **Power On:** Press the power button on the console or use the remote control to turn on the device.
5. **Select Input:** Switch your television's input source to the corresponding HD input where the console is connected.
6. **Controller Pairing:** The wireless controllers are typically pre-paired. If not, follow the instructions in the "Operating Instructions" section for controller setup.

# SUPPORT 4K HD OUTPUT

You can enjoy games/watch tv on a big screen.



Image: The Super Console X4 Plus is shown connected to a large screen television, demonstrating its 4K HD output capability. This setup allows users to enjoy games and media on a larger display.

## OPERATING INSTRUCTIONS

---

The Super Console X4 Plus features three integrated operating systems. You can switch between them as needed.

### System Switching

The console supports EmuELEC 4.6 for gaming, Android 11.0 for smart TV functions, and CoreELEC for media. Specific instructions for switching between these systems are typically provided on-screen during initial setup or via a dedicated button on the remote control. Refer to the on-screen prompts for detailed guidance.

# THREE SYSTEMS IN 1

EmuELEC4.6 + Android 11 + CoreELEC



Image: This image illustrates the three distinct operating system interfaces available on the console: EmuELEC 4.6 for gaming, Android 11.0 for applications, and CoreELEC for media playback. Users can switch between these environments.

## EmuELEC 4.6 (Gaming System)

- **Navigating Games:** Use the gamepad's directional pad or analog stick to browse through the game library.
- **Starting a Game:** Select a game and press the 'A' button (or equivalent) on the gamepad to launch it.
- **Saving Game Progress:** Most emulators within EmuELEC support save states. Refer to the in-game menu (often accessed by pressing a combination of buttons like SELECT + START) for options to save or load game progress.
- **Adding Games:** The console supports adding additional games. This typically involves connecting the TF card to a computer, transferring ROM files to the appropriate emulator folders, and then reinserting the card into the console. Ensure ROMs are in compatible formats.

## Android 11.0 (Smart TV System)

- **Navigation:** Use the remote control or a connected mouse/keyboard for navigation within the Android interface.
- **Applications:** Access pre-installed applications or download new ones from the app store.

- **Internet Connectivity:** Connect to Wi-Fi via the Android settings menu to access online content and services. The console supports 2.4/5GHz dual-band Wi-Fi.

## CoreELEC (Media System)

- **Media Playback:** CoreELEC is optimized for playing various media files from local storage or network sources.
- **Configuration:** Configure network shares or external storage devices within CoreELEC settings to access your media library.

## Wireless Controllers

- **Power On/Off:** Press the central button on the gamepad to power it on. It will automatically connect to the console if previously paired.
- **Pairing:** If a controller does not connect, ensure it is charged. On the console, navigate to the Bluetooth settings (usually within Android or EmuELEC system settings) and initiate a search for new devices. Press and hold the pairing button on the controller (refer to controller specific instructions if available) until it appears in the list, then select it to pair.
- **Charging:** Connect the controllers to a USB power source using a compatible cable (not always included, check package contents).



Image: The Super Console X4 Plus is shown alongside its two wireless gamepads and remote control. This illustrates the primary input devices for interacting with the console's various systems and games.

## MAINTENANCE

---

- **Cleaning:** Use a soft, dry cloth to clean the console and controllers. Avoid liquid cleaners or abrasive materials.
- **Cooling Fan:** The console includes an automatic cooling fan to maintain optimal operating temperature (around 50°C). Ensure the fan vents are not obstructed to allow for proper airflow.
- **Software Updates:** Periodically check for system updates within the Android or EmuELEC settings to ensure optimal performance and access to the latest features.
- **Storage:** Store the console in a cool, dry place away from direct sunlight and extreme temperatures.

# UPGRADE COOLING FAN

Super Heat Dissipation function, keep the chip temperature at about 50°C

FAN ON



FAN OFF



Image: A diagram illustrates the internal cooling fan of the Super Console X4 Plus, showing how it dissipates heat to maintain a stable operating temperature. This feature is crucial for sustained performance during gameplay.

## TROUBLESHOOTING

---

Problem	Possible Solution
Console does not power on.	<ul style="list-style-type: none"> <li>◦ Ensure the power adapter is securely connected to both the console and a working power outlet.</li> <li>◦ Try a different power outlet.</li> </ul>
No display on TV.	<ul style="list-style-type: none"> <li>◦ Verify the HD cable is firmly connected to both the console and the TV.</li> <li>◦ Ensure your TV is set to the correct HD input source.</li> <li>◦ Try a different HD cable or TV port.</li> </ul>
Wireless controller not responding.	<ul style="list-style-type: none"> <li>◦ Check if the controller batteries are charged.</li> <li>◦ Attempt to re-pair the controller with the console via Bluetooth settings.</li> <li>◦ Ensure no strong interference sources are nearby.</li> </ul>
Games are slow or laggy.	<ul style="list-style-type: none"> <li>◦ Ensure the console's cooling fan vents are clear.</li> <li>◦ Close any unnecessary background applications if in Android mode.</li> <li>◦ Some demanding games or emulators may require specific settings adjustments within EmuELEC.</li> </ul>
Cannot add new games.	<ul style="list-style-type: none"> <li>◦ Verify that the game files are in the correct format for the emulator.</li> <li>◦ Ensure the files are placed in the appropriate emulator folder on the TF card.</li> <li>◦ Check for sufficient storage space on the TF card.</li> </ul>

## SPECIFICATIONS

---

- **Model:** Super Console X4 Plus
- **Processor:** Amlogic S905X4 Quad-core ARM Cortex A55 (up to 2.0GHz)
- **GPU:** Mali-G31 MP2
- **RAM:** 4GB
- **Operating Systems:** EmuELEC 4.6, Android 11.0, CoreELEC
- **Video Output:** 4K HD
- **Wireless Connectivity:** 2.4/5GHz Dual-band Wi-Fi
- **Emulators Supported:** Compatible with 60+ classic emulators (e.g., PS1, PSP, DC, MAME, Arcade)
- **Pre-installed Games:** 60,000+
- **Languages:** Supports 26+ languages
- **Cooling:** Built-in cooling fan with colored lights
- **Package Dimensions:** 8.66 x 7.09 x 4.61 inches
- **Item Weight:** 1.81 pounds
- **Manufacturer:** Kinhank
- **Release Date:** October 10, 2024

## WARRANTY AND SUPPORT

---

For warranty information, technical support, or assistance with product issues, please contact Kinhank customer service through the retailer where the product was purchased. Keep your purchase receipt as proof of purchase for warranty claims.

For additional resources and frequently asked questions, visit the official Kinhank store or support page, if available, through the link provided by your retailer.