

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [POCKETALK](#) /

› **POCKETALK S2 Voice Translator Instruction Manual (White, PTS2-W)**

POCKETALK S2

POCKETALK S2 Voice Translator Instruction Manual

Model: PTS2-W

1. INTRODUCTION AND OVERVIEW

The POCKETALK S2 is a portable voice translator designed to facilitate communication across language barriers. This device offers real-time two-way voice translation, camera translation for text, and language learning features. It comes with 2 years of global communication included, allowing immediate use in over 170 countries and regions without complex setup.



Image: Front and back view of the POCKETALK S2 device, displaying language selection on its screen.



Image: Promotional banner for the POCKETALK S2 series, emphasizing enhanced usability, broader regional support, two-way automatic translation, and improved battery performance.

2. SETUP

2.1 Initial Charging

Before first use, fully charge the POCKETALK S2 device using the provided USB cable and a compatible

power adapter. A full charge ensures optimal performance and battery life.

2.2 Powering On/Off

- To power on: Press and hold the power button (usually located on the side) until the screen illuminates.
- To power off: Press and hold the power button, then select "Power Off" on the screen.

2.3 Network Connection

The POCKETALK S2 includes a built-in eSIM with 2 years of global communication, allowing immediate use in over 170 countries and regions. No additional setup or contract is required for this feature.

- Global Communication (eSIM):** The device automatically connects to the best available network in supported regions.
- Wi-Fi Connection:** For areas without cellular coverage or to conserve data, you can connect the device to a Wi-Fi network. Navigate to the settings menu, select Wi-Fi, and choose your desired network.

本体購入だけで、世界中[※] ですぐに使える。

本体価格に2年分の通信費が含まれています。
回線契約や難しい設定を行う必要なく、
電源を入れてすぐに世界中[※] でご利用いただけます。

※世界 170以上の国と地域に対応



Image: The POCKETALK S2 displaying its global communication capabilities with eSIM, supporting over 170 countries and regions.

2.4 Initial Language Selection

Upon first power-on or after a factory reset, you will be prompted to select your primary languages for

translation. Choose the two languages you wish to translate between.



NEW ポケトークS2 シリーズ

- 使える国や地域が170以上に
- 双方向に自動翻訳できるように※
- バッテリーがさらに長持ちに

※デフォルト設定ではOFFです。自動翻訳設定をONにした際に、利用できます。

Image: Two POCKETALK S2 devices demonstrating the language selection interface, set to English (US) and Japanese.

3. OPERATING INSTRUCTIONS

3.1 Voice Translation

The POCKETALK S2 provides seamless two-way voice translation. Ensure the correct source and target languages are selected on the screen.

1. **Speak:** Press and hold the large button corresponding to the language you will speak. Speak clearly into the device's microphone.
2. **Release:** Release the button once you have finished speaking. The device will process your speech and translate it into the target language, then play the translation aloud and display it on the screen.
3. **Two-Way Automatic Translation:** The device can be set to automatically translate both ways. This feature can be enabled in the settings menu.

ボタンを押しながら話すだけ
文字と音声で、瞬時に翻訳します。



Image: User interacting with the POCKETALK S2 for voice translation, showing the "please talk" prompt on the screen.

3.2 Camera Translation

The camera translation feature allows you to translate text from signs, menus, or documents. This function supports 56 languages.

- Activate Camera:** From the main screen, select the camera icon to activate the camera translation mode.
- Capture Text:** Point the device's camera at the text you wish to translate. Ensure the text is well-lit and within the frame.
- Translate:** The device will automatically detect and translate the text, displaying the translation on the screen.

カメラ翻訳で、文字も翻訳

お店のメニュー や看板など、カメラで撮影するだけで翻訳できます。何語か分からぬ文字でも言語を自動判別します。（56言語対応）



Image: Demonstrations of the camera translation feature, translating text from a menu and a sign.

3.3 Language Learning Features

The POCKETALK S2 includes tools to assist with language acquisition.

- Pronunciation Practice:** Access this mode to practice speaking and receive feedback on your pronunciation.
- AI Conversation Lessons:** Engage in AI-powered conversation lessons, currently available for English and Chinese, to improve your conversational skills.

3.4 Unit Conversion

The device can perform various unit conversions. Access this feature from the main menu and input the values for conversion.

3.5 Favorite Word Registration

You can register frequently used words or phrases as favorites for quick access. This feature helps personalize your translation experience.

4. KEY FEATURES

- Extensive Language Support:** Translates over 90 languages (74 via voice and text, 11 via text only).
- Global Coverage:** Operates in over 170 countries and regions with included 2-year global communication.
- Two-Way Automatic Translation:** Facilitates natural conversations by automatically translating both directions (when enabled).
- Camera Translation:** Translates text from images in 56 languages, useful for signs and menus.
- Enhanced Audio:** Features a noise-canceling microphone and a large speaker for clear communication even in noisy environments.
- Language Learning Tools:** Includes pronunciation practice and AI conversation lessons for English and Chinese.
- Long Battery Life:** Improved battery performance for extended use.
- Unit Conversion:** Convenient tool for converting various units.
- Favorite Phrases:** Ability to save frequently used words and phrases.

—さらに使いやすくなりました。



Image: Visual representation of POCKETALK S2's key improvements: expanded country support, two-way translation, and extended battery life.

—AI通訳機 ポケトークの多彩な機能



Image: Overview of the POCKETALK S2's diverse functionalities, including mutual translation, language switching, camera translation, and language learning.

ポケトークの翻訳精度が高い理由

言語ごとに最適なエンジンを採用し、常にクラウド上の最新のエンジンを利用して翻訳します。



Image: Charts demonstrating the POCKETALK S2's translation accuracy and its application in language study.

5. MAINTENANCE

- Cleaning:** Use a soft, dry cloth to clean the device. Avoid using harsh chemicals or abrasive materials.
- Software Updates:** Periodically check for and install software updates to ensure optimal performance and access to new features. Updates can usually be found in the device's settings menu.
- Battery Care:** To prolong battery life, avoid fully discharging the device frequently. Store the device in a cool, dry place when not in use for extended periods.

6. TROUBLESHOOTING

Issue	Possible Cause	Solution

Issue	Possible Cause	Solution
No translation / Slow translation	Poor network connection (eSIM or Wi-Fi). Speaking too quickly or unclearly.	Check network signal strength. Move to an area with better reception or connect to a stable Wi-Fi network. Speak clearly and at a moderate pace.
Translation accuracy varies	Contextual nuances or complex sentences.	Translation results may vary depending on the context and complexity of the speech. Try rephrasing your sentence.
Camera translation not working	Insufficient lighting. Text is blurry or too small.	Ensure adequate lighting. Hold the device steady and close enough for clear focus.
Device not powering on	Battery is depleted.	Connect the device to a charger and allow it to charge for at least 30 minutes before attempting to power on again.

Important Note: Operation with SIM cards other than the dedicated communication SIM is not supported. Always refer to the included instruction manual for detailed warnings and usage guidelines.

7. SPECIFICATIONS

Feature	Detail
Brand	POCKETALK
Model Number	PTS2-W
Color	White
Size	POCKETALK S2
Package Dimensions	14.2 x 14 x 3.9 cm
Item Weight	240 g
ASIN	B0DJSFLDGV
First Available Date	2024/10/16

8. WARRANTY AND SUPPORT

The POCKETALK S2 comes with a **1-year manufacturer's warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.

For technical support, troubleshooting assistance, or warranty inquiries, please refer to the official POCKETALK support website or contact their customer service. Contact information can typically be found on the manufacturer's packaging or official website.

