

[Manuals.plus](#) /

› [LEDIARY](#) /

› LEDIARY 19.7-inch Flush Mount Ceiling Fan with Lights and Remote - Instruction Manual

LEDIARY f548bbbc-fce0-4c13-b662-fd1cfae14431

LEDIARY 19.7-inch Flush Mount Ceiling Fan with Lights and Remote - Instruction Manual

Model: f548bbbc-fce0-4c13-b662-fd1cfae14431

INTRODUCTION

Thank you for choosing the LEDIARY 19.7-inch Flush Mount Ceiling Fan with Lights and Remote. This manual provides detailed instructions for the safe and efficient installation, operation, and maintenance of your new ceiling fan. Please read this manual thoroughly before installation and keep it for future reference.



Image: The LEDIARY 19.7-inch Flush Mount Ceiling Fan with Lights and Remote, showcasing its modern design and flush-mount installation in a bedroom setting.

SETUP AND INSTALLATION

The LEDIARY Flush Mount Ceiling Fan is designed for easy installation. Follow the steps below carefully. It is recommended to have a qualified electrician perform the installation if you are unsure about any wiring procedures.

1. Unboxing and Parts Inspection

Carefully open the packaging and remove all components. Inspect all parts for any damage. Ensure all listed components are present before proceeding with installation. Handle the product carefully and avoid pulling wires forcefully.



Image: All components of the LEDIARY Ceiling Fan, including the motor, fan blades, light rings, remote control, and mounting hardware, are laid out on a white surface for inspection.

2. Assembly of the Lamp Body

1. Loosen the four canopy screws on the main motor body (do not remove them completely).
2. Rotate clockwise to detach the mounting plate from the motor body.
3. Thread the screw arms and the wires from the connected ports through the fan motor host together.
4. Secure the two lamp bodies together using the provided screws.
5. Insert the three decorative pieces into the screw holes of the lamp body and press them in by hand.
6. Screw in the fan blade cap counterclockwise to secure it.

3. Electrical Connection and Mounting

Ensure power is turned off at the circuit breaker before beginning any electrical work.

1. Install the ceiling bracket to your junction box using appropriate screws.
2. Connect the electrical wires: Match the live, neutral, and ground wires from your ceiling to the corresponding wires on the fan. Use wire nuts to secure connections.
3. Hang the fan onto the installed ceiling bracket.
4. Secure the fan to the ceiling bracket using the canopy screws.

Your browser does not support the video tag.

Video: A detailed installation guide for the LEDIARY 19.7-inch Ceiling Fan with Lights, demonstrating each step of the assembly and mounting process.

OPERATING INSTRUCTIONS

Your LEDIARY ceiling fan can be controlled via the included remote control or a dedicated smartphone application (Bluetooth connection required).

Remote Control Functions

3000K-6000K Stepless Adjustable

**3000K****4000K****6000K**

10%-100% Brightness Adjustable

**10%****100%**

Image: The remote control for the LEDIARY Ceiling Fan, showing buttons for light ON/OFF, CCT change, brightness adjustment, fan speed settings (1-6), forward/reverse function, night light, and 2-hour timer.

- **Light ON/OFF:** Turns the LED light on or off.
- **CCT Change:** Cycles through 3 color temperatures (3000K warm, 4000K neutral, 6000K white).

- **Brightness +/-:** Adjusts light brightness from 10% to 100%.
- **Fan Speed (1-6):** Selects one of six wind speeds.
- **F/R (Forward/Reverse):** Changes the fan's rotation direction for summer (downdraft) or winter (updraft) modes.
- **2H Timer:** Sets the fan to turn off automatically after 2 hours.
- **Night Light:** Activates a low-brightness light mode.
- **Memory Function:** The light will remember the last brightness and color temperature setting when turned off and on again.

App Control

The fan can also be controlled via a smartphone application. Ensure Bluetooth is enabled on your device and follow the app's pairing instructions.

APP & Remote Control

⌘ Tips: APP control needs Bluetooth



6 Fan Speeds



Timer Setting



Night Light



Smooth Dimming



Reversible DC Motor



3000K-6000K CCT Adjustable



Image: A smartphone displaying the LEDIARY app interface, showing controls for fan speed, light brightness, color temperature, and other functions, mirroring the remote control capabilities.

Regular maintenance ensures optimal performance and longevity of your LEDIARY ceiling fan.

- **Cleaning:** Dust the fan blades and light fixture regularly with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth with mild soap, then wipe dry. Do not use abrasive cleaners or solvents.
- **Inspection:** Periodically check all connections and screws to ensure they are secure.
- **Light Source:** The LED light source is integrated and designed for long-term use. It is not user-replaceable.

TROUBLESHOOTING

If you encounter any issues with your LEDIARY ceiling fan, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Fan does not operate	No power supply; Loose wiring; Remote control battery low.	Check circuit breaker; Verify wiring connections; Replace remote control batteries.
Light does not turn on	No power to light; Loose light wiring; LED driver issue.	Check power supply; Verify light connections; Contact customer support if LED driver is suspected.
Fan makes excessive noise	Loose screws; Unbalanced blades; Motor issue.	Tighten all mounting screws; Ensure blades are properly installed; Contact customer support if motor noise persists.
Remote control not working	Batteries dead; Remote not paired.	Replace batteries; Refer to pairing instructions in the full manual.

SPECIFICATIONS

- **Brand:** LEDIARY
- **Model:** f548bbbc-fce0-4c13-b662-fd1cfae14431
- **Color:** White
- **Electric Fan Design:** Ceiling Fan
- **Power Source:** DC Motor
- **Style:** Modern
- **Product Dimensions:** 19.7"D x 19.7"W x 5.3"H
- **Room Type:** Bedroom, Home Office, Kitchen, Living Room, Study Room
- **Special Features:** 2H Timer, 6 wind speeds, Dimmable, Remote Control, Reversible DC Motor
- **Recommended Uses:** Indoor
- **Mounting Type:** Flush Mount
- **Controller Type:** Remote Control
- **Number of Speeds:** 6
- **Wattage:** 32 watts
- **Number of Blades:** 7
- **Voltage:** 120 Volts
- **Material:** Plastic
- **Included Components:** LED lights, Remote
- **Unit Count:** 1.0 Count

WARRANTY AND SUPPORT

LEDIARY provides a 2-year after-sales service for this product. If you encounter any problems with installation, operation, or product damage, please contact us. We are committed to replying within 24 hours to assist you.



FRIENDLY CUSTOMER SERVICE
Provide 24-hour online technical support and worry-free warranty



FUNCTIONAL UPGRADES
Available in all seasons and improved product utility



MULTI-STYLE DESIGN
Complementing a variety of interior design styles

Image: An illustration representing LEDIARY's customer service, highlighting 24-hour online technical support and a worry-free warranty.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DJSLZ4ZQ>

More documents and user manuals: <https://manuals.plus/>