

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Holiday](#) /

> [Holiday Bluetooth Headphones ALG02 User Manual](#)

Holiday ALG02

Holiday Bluetooth Headphones User Manual

Model: ALG02

INTRODUCTION

Thank you for purchasing the Holiday Bluetooth Headphones. This manual provides detailed instructions on how to set up, operate, and maintain your new wireless earbuds. Please read this manual carefully before use to ensure optimal performance and longevity of your device.

SAFETY INFORMATION

To prevent damage to your device or injury to yourself or others, please read all safety information before using the device. Keep this manual for future reference.

- Do not disassemble, repair, or modify the device.
- Do not expose the device to extreme temperatures (above 45°C or below 0°C).
- Avoid exposing the device to water or liquids, except for the IPX5 water resistance as specified.
- Keep the device away from children and pets.
- Use only manufacturer-approved chargers and cables.
- Do not use the device at high volume for extended periods to prevent hearing damage.

PACKAGE CONTENTS

Ensure all items are present in the package:

- Holiday Bluetooth Headphones (Left and Right Earbuds)
- Charging Case
- USB Type-C Charging Cable
- User Manual (This document)
- *Note: The product description mentions "Cassette" as an included component, which is likely an error. Assuming standard earbud accessories.*

PRODUCT OVERVIEW



Figure 1: Holiday Bluetooth Headphones and Charging Case. The image shows the white earbuds placed inside their matching white charging case, with the lid open, revealing the earbuds' design and charging contacts.

BLUETOOTH V5.1 TECHNOLOGY

Built with A8 bluetooth chip, compatible with Bluetooth v5.1 mode and others bluetooth devices



Figure 2: Bluetooth 5.2 Technology. This diagram illustrates the internal components of an earbud, highlighting the Bluetooth 5.2 chip for stable and efficient wireless connection.

Full-automatic Pairing

Accoppiamento intelligente con una chiave



Connessione rapida



latenza zero



Segnale forte




Figure 3: Automatic Pairing. The image shows the earbuds next to a smartphone screen displaying Bluetooth settings, indicating quick connection, zero latency, and strong signal.

SUPER LIGHTWEIGHT DESIGN

Wire Free, Noise Free, Stress Free(4g/each earbud)



Lightweight



Sweat Proof



Ergonomic Design



Built- in Mic



Wide compatibility



Smart Touch Control



Type-C Charge

Figure 4: Lightweight and Ergonomic Design. This image highlights key features such as lightweight (4g/earbud), sweatproof, ergonomic design, built-in mic, wide compatibility, smart touch control, and Type-C charging.

ONE-TOUCH OPERATION



Play/Pause

Touch left/right earphone twice



Previous Song

Press the right earphone for 2 seconds



Next Song

Press the left earphone for 2 seconds



Voice Assistant

Tap left/right earbuds 3 times



Reject call

Press left/right earbuds 2 seconds



Answer call/Hang up

Tap left/right earbuds twice

Figure 5: One-Touch Operation. This graphic details the touch controls for various functions: Play/Pause (touch L/R earphone twice), Previous Song (press R earphone 2s), Next Song (press L earphone 2s), Voice Assistant (tap L/R earbuds 3 times), Reject Call (press L/R earbuds 2s), Answer Call/Hang Up (tap L/R earbuds twice).

STEREO SOUND QUALIT

Allows you to enjoy high-fidelity sound quality with balanced bass and clear treble anytime, anywhere.



Figure 6: Stereo Sound Quality. This image shows two people enjoying music with the earbuds, illustrating the high-fidelity sound experience with balanced bass and clear treble.

SETUP

Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case, ensuring they are correctly seated.
2. Connect the USB Type-C charging cable to the charging port on the case and the other end to a USB power source (e.g., computer, wall adapter).
3. The charging indicator light on the case will show charging status. The red light will turn white when fully charged.
4. A full charge takes approximately 1.5 hours for the case. The earbuds provide 4-5 hours of playtime on a single charge, and the charging case extends total playtime to 30 hours.

Pairing with Your Device

The earbuds feature automatic pairing for convenience.

1. First-time Pairing:

- Open the charging case and take out both earbuds. They will automatically enter pairing mode.
- On your smartphone or Bluetooth-enabled device, go to Bluetooth settings and enable Bluetooth.
- Search for available devices and select "ViMi" from the list.
- Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.

2. Subsequent Pairing:

- After the initial pairing, the earbuds will automatically connect to the last paired device when taken out of the charging case, provided Bluetooth is enabled on your device.

OPERATING INSTRUCTIONS

Touch Controls

The Holiday Bluetooth Headphones feature intuitive touch controls on each earbud.

Function	Action
Play/Pause Music	Touch left/right earphone twice
Previous Song	Press right earphone for 2 seconds
Next Song	Press left earphone for 2 seconds
Activate Voice Assistant (Siri, Google Assistant, etc.)	Tap left/right earbuds 3 times
Answer/End Call	Tap left/right earbuds twice
Reject Call	Press left/right earbuds for 2 seconds

Wearing the Earbuds

The earbuds are designed for an ergonomic fit. Insert them gently into your ear canal and rotate slightly to ensure a secure and comfortable seal. This helps optimize sound quality and noise isolation.

MAINTENANCE

Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use harsh chemicals, cleaning solvents, or strong detergents.
- Gently clean the charging contacts on both the earbuds and the case to ensure proper charging.

Storage

When not in use, store the earbuds in their charging case to protect them and keep them charged.

Water Resistance

The earbuds are IPX5 water and sweat resistant, making them suitable for workouts and light rain. They are not designed for submersion in water. Do not expose them to strong jets of water or wear them while swimming or showering.

TROUBLESHOOTING

If you encounter issues with your Holiday Bluetooth Headphones, refer to the following common problems and solutions:

- **Earbuds not pairing or only one earbud working:**

- Ensure both earbuds are fully charged.
- Place both earbuds back into the charging case, close the lid, wait a few seconds, then open the lid and take them out again.
- On your device, forget or delete "ViMi" from your Bluetooth paired devices list.
- Restart your device's Bluetooth and attempt to pair again from scratch.

- **No sound or low volume:**

- Check the volume level on both your earbuds and your connected device.
- Ensure the earbuds are properly connected to your device.
- Clean any debris from the earbud speaker mesh.

- **Charging issues:**

- Ensure the charging cable is securely connected to both the case and the power source.
- Verify the power source is active.
- Clean the charging contacts on the earbuds and inside the case.
- Try a different USB Type-C cable or power adapter.

- **Bluetooth connection unstable:**

- Ensure your device is within the 10-meter Bluetooth range.
- Avoid obstacles between the earbuds and your device that might interfere with the signal.
- Minimize interference from other wireless devices.

SPECIFICATIONS

Feature	Detail
Model Name	ALG02
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.2
Bluetooth Range	Up to 10 meters (33 feet)
Battery Life (Earbuds)	4-5 hours (single charge)
Total Playtime (with Charging Case)	Up to 30 hours
Charging Time (Case)	Approx. 1.5 hours (Type-C fast charge)
Water Resistance Rating	IPX5 (Water and Sweat Resistant)
Control Method	Touch
Material	Plastic

Feature	Detail
Weight (per earbud)	Approx. 4g
Frequency Range	20 Hz - 20,000 Hz
Ear Placement	In Ear

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or contact the manufacturer directly. Keep your proof of purchase for warranty claims.

Manufacturer: Holiday

