

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [FUNYET](#) /

› [FUNYET Touchscreen Laptop Computer User Manual](#)

FUNYET FUNYO-01

FUNYET Touchscreen Laptop Computer User Manual

Model: FUNYO-01

[Instructions](#) [Introduction](#) [Setup](#) [Operating](#)
[Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

Welcome to the user manual for your new FUNYET Touchscreen Laptop Computer, Model FUNYO-01. This 14-inch 2-in-1 device is designed for versatility and performance, featuring an Intel N100 processor, 16GB RAM, 512GB SSD, and a vibrant 1920x1080 display. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your laptop to ensure you get the most out of its capabilities.



Figure 1: FUNYET Touchscreen Laptop Computer Overview.

2. SETUP

2.1 Unpacking and Initial Inspection

Carefully remove your laptop from its packaging. Ensure all components are present:

- FUNYET Laptop (Model FUNYO-01)
- Power Adapter
- User Manual (this document)

Inspect the laptop for any signs of physical damage. If any damage is found, contact customer support immediately.

2.2 Powering On and Initial Configuration

1. Connect the power adapter to the laptop's power interface and then to a wall outlet.
2. Press the Power Button (refer to Figure 3 for location) to turn on the laptop.
3. Follow the on-screen instructions to complete the initial Windows 11 Pro setup, including language selection, network connection, and user account creation.
4. Ensure your device is connected to Wi-Fi 6 for optimal internet performance.

Bluetooth 5.2

Wi-Fi 6



Figure 2: Laptop Ports and Connectivity.

3. OPERATING INSTRUCTIONS

3.1 2-in-1 Convertible Design

Your FUNYET laptop features a 360-degree reversible screen, allowing it to transform into multiple modes:

- **Laptop Mode:** Traditional laptop use for typing and productivity.
- **Tablet Mode:** Fold the screen back completely for a tablet experience, ideal for touch-based applications.
- **Stand Mode:** Position the screen to stand upright, perfect for watching videos or presentations.
- **Tent Mode:** Form an inverted 'V' shape, suitable for small spaces or touch interaction.



Figure 3: 360-Degree Convertible Modes.

3.2 Touchscreen Functionality

The 14.1-inch Full HD (1920x1080) IPS display supports multi-touch gestures for intuitive navigation. Utilize the touchscreen for browsing, drawing, and note-taking. The display boasts a 0.2-inch bezel and a 91% screen-to-body ratio for an immersive visual experience.

See more, See clearer

Enjoy clearer, brighter and more vivid colors with 14-inch IPS display



14 Inch



1920*1080 FHD



IPS



91% Screen-to-body ratio



Eye Protection



Clear and vivid display



Figure 4: High-Quality Display Features.

3.3 Backlit Keyboard and Fingerprint Reader

The ergonomic backlit keyboard provides comfortable typing, even in low-light conditions. Press **Fn + F9** to toggle the keyboard backlight. For enhanced security and quick access, the integrated fingerprint reader allows for fast and secure device unlocking.

Fearless of the Night

FN+F9 to turn on the keyboard backlight, allowing you to work and play games even in the dark.



Figure 5: Backlit Keyboard and Fingerprint Reader.

3.4 Storage Expansion

Your laptop comes with 16GB RAM and a 512GB high-speed SSD. For additional storage, you can expand it up to 2TB using a TF (microSD) card inserted into the dedicated TF card slot.

4. MAINTENANCE

4.1 Cleaning Your Laptop

- Screen:** Use a soft, lint-free cloth specifically designed for electronics. Dampen it slightly with water or a screen cleaner. Avoid harsh chemicals.
- Keyboard and Chassis:** Use a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, ensuring no liquid enters the device.
- Ports:** Use compressed air to gently clear dust from ports. Avoid inserting any objects.

4.2 Battery Care

The laptop is equipped with a 5000mAh battery, providing up to 8 hours of use. To prolong battery life:

- Avoid extreme temperatures.
- Do not fully discharge the battery frequently.
- For long-term storage, charge the battery to about 50%.
- Unplug the charger once the battery is fully charged to prevent overcharging.



Figure 6: Advanced Cooling System.

The laptop features an improved thermal system with a smart silent fan and copper tubing, ensuring efficient cooling and preventing overheating during extended use.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Touchscreen not responding.	Driver issue, software glitch, or hardware malfunction.	<ol style="list-style-type: none"> 1. Restart the laptop. 2. Check Device Manager for touchscreen drivers and update them. 3. Ensure Windows 11 Pro is up to date. 4. If the issue persists, contact customer support.
Limited USB ports / No HDMI port.	Product design limitation.	<ol style="list-style-type: none"> 1. Utilize the single USB 3.0 port and Type-C port for connectivity. 2. Consider purchasing a USB hub or a USB-C to HDMI adapter if additional ports or external display connectivity is required.
Short battery life.	High brightness, background apps, or battery degradation.	<ol style="list-style-type: none"> 1. Adjust screen brightness. 2. Close unnecessary background applications. 3. Enable Windows Battery Saver mode. 4. Ensure proper battery care as outlined in Section 4.2.
Stiff touchpad.	Manufacturing variation or preference.	<ol style="list-style-type: none"> 1. Ensure the touchpad is clean and free of debris. 2. Adjust touchpad sensitivity in Windows settings. 3. Consider using an external mouse for a smoother experience.

6. SPECIFICATIONS

Feature	Detail
Brand	FUNYET
Model Name	YO-01 (FUNYO-01)
Operating System	Windows 11 Pro
Screen Size	14.1 Inches
Screen Resolution	1920 x 1080 pixels (Full HD)
Processor	Intel N100 (up to 3.4 GHz, 4 Cores, 4 Threads)
RAM	16GB DDR5
Hard Drive	512GB SSD (PCIE x 2)
Graphics Coprocessor	Intel UHD Graphics (Integrated)
Wireless Type	Wi-Fi 6 (2.4 GHz Radio Frequency)
Bluetooth	Bluetooth 5.2
USB Ports	1 x USB 3.0, 1 x Type-C
Other Ports	Audio Port, TF Card Interface, Power Interface
Item Weight	4.1 pounds
Product Dimensions	12.7 x 0.6 x 8.6 inches

Feature	Detail
Color	Silver
Battery	5000mAh (Up to 8 hours)
Special Feature	Anti Glare Coating, Fingerprint Unlock, Backlit Keyboard, 360-degree Convertible

7. WARRANTY AND SUPPORT

Your FUNYET laptop comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures your product functions as intended under normal use.

For any technical assistance, troubleshooting, or warranty claims, please contact our customer service team. We offer **24/7 customer service** to assist you with any inquiries.

Please refer to your purchase documentation for specific contact details or visit the official FUNYET website for support information.

© 2025 FUNYET. All rights reserved.

This manual is subject to change without notice.