

ZIOVO Z168

ZIOVO Z168 Android 14 Tablet User Manual

Model: Z168

1. INTRODUCTION

This manual provides detailed instructions for the safe and efficient use of your ZIOVO Z168 Android 14 Tablet. Please read this manual thoroughly before using the device and retain it for future reference.

1.1 Safety Information

- Do not expose the tablet to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the tablet to strong impacts.
- Use only approved chargers and accessories.
- Do not attempt to disassemble or repair the tablet yourself.
- Keep the tablet away from children and pets.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- ZIOVO Z168 Tablet
- Tablet Case
- Screen Protector (pre-applied or replacement)
- Bluetooth Keyboard
- Wireless Mouse
- Type-C to USB Adapter
- Type-C Data Cable
- EU Standard Charger
- User Manual (this document)



Image: ZIOVO Z168 Tablet with its accessories, including a keyboard, mouse, charger, and cables.

3. DEVICE OVERVIEW

Familiarize yourself with the physical components of your ZIOVO Z168 Tablet.

3.1 Physical Features


- **Display:** 10.1-inch screen (1280x800 pixels)
- **Front Camera:** 5MP
- **Rear Camera:** 8MP
- **Ports:** Type-C port, 3.5mm headphone jack, Micro SD card slot
- **Speakers:** Dual Smart Speakers

ZIOVO Z168 Octa-Core Android 14 Tablette

Android 14.OS



Octa-Core T606



10.1 Pouces



Widevine L1 Support



22GB RAM+128GB ROM



8000mAh



2.4G+5.0G WiFi



8MP+5MP
Double Caméra



Double Enceinte
Intelligente



Image: Diagram illustrating key features of the ZIOVO Z168 Tablet, including screen size, cameras, and connectivity.

4. SETUP

4.1 Initial Power On

1. Press and hold the Power button until the screen turns on.
2. Follow the on-screen prompts to select your language and region.
3. **Important:** Do not connect to Wi-Fi immediately after powering on. Wait until the tablet reaches the home screen before connecting to a network. This helps ensure proper system initialization.

4.2 Wi-Fi Connection

1. From the home screen, swipe down from the top to open the Quick Settings panel.
2. Tap the Wi-Fi icon to enable it.
3. Go to **Settings > Network & internet > Internet**.
4. Select your desired Wi-Fi network from the list.
5. Enter the password if prompted and tap **Connect**.

5.0G/2.4G WIFI Support

Connexion réseau stable et rapide, pour une bonne expérience en ligne



Image: The tablet screen displaying 5G WiFi connectivity, indicating support for both 2.4GHz and 5GHz bands.

4.3 Google Account Setup

To access the Google Play Store and other Google services, you will need to sign in with your Google account. Follow the on-screen instructions during initial setup or go to **Settings > Accounts > Add account > Google**.

5. OPERATING THE TABLET

5.1 Android 14 Operating System

Your ZIOVO Z168 Tablet runs on the Android 14 operating system, offering enhanced privacy controls, improved security, and a personalized user experience.

Android 14 Système d'exploitation

Android 14 a été optimisé pour un démarrage plus rapide, un défilement plus fluide et des performances améliorées.



Confidentialité
Sécurité & Contrôle des Appareils



Personnalisation
Interface Personnalisée



Prise en compte
Accessibilité Améliorée



Play Store
Diverses Applications Populaires

Image: A visual representation of the Android 14 operating system, highlighting features like privacy, personalization, accessibility, and Play Store access.

5.2 Basic Navigation

- **Swipe:** Move your finger across the screen to scroll through content or switch between screens.
- **Tap:** Touch the screen briefly to select an item or open an application.
- **Long Press:** Press and hold an item to reveal additional options.
- **Pinch-to-Zoom:** Use two fingers to zoom in or out on images and web pages.

5.3 Storage Management

The tablet comes with 128GB of internal storage. You can expand this by up to 1TB using a Micro SD/TF card.

1. Insert the Micro SD card into the designated slot.
2. Go to **Settings > Storage** to manage internal and external storage.

22GB RAM+128GB ROM Massif Stockage

Exécutez des jeux de petite ou moyenne taille en toute fluidité et stockez davantage de contenus, tels que des films, des documents de travail, des photos, des livres électroniques, etc.



Image: A graphic illustrating the tablet's storage capabilities, including 22GB RAM, 128GB ROM, and 1TB expandable storage via TF card.

5.4 Widevine L1 Support

The ZIOVO Z168 Tablet supports Widevine L1, enabling high-definition (HD) and ultra-high-definition (UHD) streaming content from platforms like Netflix, Amazon Prime Video, Hulu, and HBO Max.

Widevine L1 Support

Grâce à la prise en charge de Widevine L1, les tablettes ZIOVO peuvent être utilisées avec Netflix, des streamers vidéo premium comme Amazon Prime Video et bien plus encore. Du contenu en haute définition (HD) et en ultra-haute définition (UHD) au contenu en haute définition (UHD), vous pouvez y accéder en toute sécurité.



Image: A visual demonstrating Widevine L1 support, showing the tablet displaying high-quality video content from various streaming platforms.

5.5 Facial Recognition

The tablet supports facial recognition for quick and secure unlocking. To set up facial recognition, go to **Settings > Security & privacy > Face unlock** and follow the on-screen instructions.

Fonction de l'écran de Projection

Partagez plus de bonheur avec votre famille et vos amis grâce à un écran plus grand.



Brillance à Chaque Clic


8MP Caméra Arrière  10 Pouces Écran

5MP Caméra Frontale  LED Flash



Écran Partagé Intelligent, Tâches Multiples

Les deux fenêtres simultanées facilitent la manipulation et améliorent l'efficacité du travail.



Déverrouillage Facial



Image: A depiction of the facial recognition feature in action, showing a user unlocking the tablet with their face.

5.6 Split Screen Functionality

Utilize the split-screen feature to run two applications simultaneously, enhancing multitasking and productivity. To activate, open an app, then swipe up from the bottom of the screen and hold to access recent apps. Drag one app to the top or bottom of the screen, then select another app for the remaining space.

Fonction de l'écran de Projection

Partagez plus de bonheur avec votre famille et vos amis grâce à un écran plus grand.



Brillance à Chaque Clic

8MP
Caméra Arrière

10 Pouces Écran


5MP
Caméra Frontale

LED Flash



Écran Partagé Intelligent, Tâches Multiples

Les deux fenêtres simultanées facilitent la manipulation et améliorent l'efficacité du travail.



Déverrouillage Facial



Image: The tablet screen displaying two applications running side-by-side in split-screen mode, demonstrating multitasking capabilities.

6. USING ACCESSORIES

6.1 Bluetooth Keyboard and Wireless Mouse

The included Bluetooth keyboard and wireless mouse enhance the tablet's functionality for productivity tasks.

6.1.1 Connecting the Bluetooth Keyboard

1. Ensure the keyboard is charged and powered on.
2. On your tablet, go to **Settings > Connected devices > Bluetooth**.
3. Turn on Bluetooth and tap **Pair new device**.
4. Select the keyboard from the list of available devices and follow any on-screen pairing instructions.

6.1.2 Connecting the Wireless Mouse

1. Insert the USB dongle for the wireless mouse into the Type-C to USB adapter.
2. Connect the Type-C to USB adapter to the tablet's Type-C port.
3. Ensure the mouse has batteries and is powered on. The tablet should automatically detect the mouse.

7. MAINTENANCE

7.1 Battery Management

The tablet is equipped with an 8000mAh battery. To prolong battery life:

- Avoid fully discharging the battery frequently.
- Charge the tablet using the provided Type-C charger.
- Avoid exposing the tablet to extreme heat or cold during charging.

Batterie de 8000 mAh avec chargement de type-C

Tablet Z168 è dotato di una robusta batteria ai polimeri di litio da 8000 mAh, Grazie alla ricarica Type-C, è possibile rimanere alimentati e connessi senza dover ricaricare frequentemente il tablet.

 Type-C  5V/2A  3.5mm Prise pour écouteurs



 Jeu  Vidéo en ligne  Surf sur le web

 Musique  Appel  Livres électroniques

Image: A visual representation of the tablet's 8000mAh battery and its Type-C charging port, along with a 3.5mm headphone jack.

7.2 Cleaning

Use a soft, lint-free cloth to clean the tablet screen and body. Do not use abrasive cleaners or solvents.

7.3 Software Updates

Periodically check for software updates to ensure optimal performance and security. Go to **Settings > System > System update**.

8. TROUBLESHOOTING

- **Tablet does not turn on:** Ensure the battery is charged. Connect the charger and try again.
- **Screen is unresponsive:** Restart the tablet by pressing and holding the Power button.
- **Wi-Fi connection issues:** Check if Wi-Fi is enabled. Restart your router and the tablet. Forget the network and reconnect.
- **Applications crashing:** Clear the cache of the problematic app (**Settings** > **Apps** > select app > **Storage & cache** > **Clear cache**). If the issue persists, reinstall the app.
- **Slow performance:** Close unnecessary background applications. Clear cache and temporary files. Consider a factory reset as a last resort (back up your data first).

9. SPECIFICATIONS

Feature	Specification
Model	Z168
Operating System	Android 14
Processor	Octa-Core T606, 2.0GHz
RAM	22GB (6GB Physical + 16GB Virtual)
Internal Storage (ROM)	128GB
Expandable Storage	Up to 1TB via Micro SD/TF card
Battery Capacity	8000mAh
Screen Size	10.1 Inches
Screen Resolution	1280 x 800 pixels
Widevine Support	L1
Front Camera	5MP
Rear Camera	8MP
Connectivity	5G/2.4G WiFi (802.11ax), Bluetooth 5.0, AGPS
Ports	Type-C, 3.5mm Headphone Jack, Micro SD Slot
Dimensions (L x W x H)	24.3 x 16 x 1 cm

Haute Performance Octa-Core Processeur




Image: A detailed view of the Octa-Core T606 processor, highlighting its 2.0GHz speed, A75 high performance, and 12nm process for energy efficiency.

10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or contact ZIOVO customer service through their official channels. Specific warranty details may vary by region and retailer.