

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Bellemave](#) /

› [Bellemave Kids Twin Over Twin Bunk Bed Instruction Manual \(Model GZZ000060TLK2\)](#)

Bellemave GZZ000060TLK2

Bellemave Kids Twin Over Twin Bunk Bed Instruction Manual

Model: GZZ000060TLK2

INTRODUCTION

This manual provides essential information for the safe assembly, operation, and maintenance of your Bellemave Kids Twin Over Twin Bunk Bed. Please read all instructions carefully before assembly and use. Retain this manual for future reference.

SAFETY INFORMATION

Caution: This bed frame is certified by the Children's Product Certificate (CPC). Adhere to the following safety guidelines:

- The maximum weight capacity for the upper bed is **175 pounds**.
- The maximum weight capacity for the bottom bed is **275 pounds**.
- Exceeding these weight recommendations can cause serious injury.
- All four sides of the twin bunk bed are equipped with protective guardrails to prevent accidental falls.
- Be aware of potential pinch points from the built-in ladder.
- Proper assembly is crucial to prevent instability or collapse. Refer to the assembly instructions for detailed guidance.
- The lower bunk's floor-level design minimizes fall height for younger users.



Image: Close-up of the upper bunk's safety guardrail and the lower bunk's floor-level design, highlighting safety features.

PRODUCT OVERVIEW

The Bellemave Twin Over Twin Bunk Bed is designed for children's rooms, offering a space-saving solution with the flexibility to convert into two separate twin beds. It features a sturdy wood construction and integrated slat support, eliminating the need for a box spring.

Key Features:

- **Convertible Design:** Can be separated into two individual twin beds.
- **Integrated Slat Support:** No box spring required; slats support mattresses directly (14 for upper bunk, 7 for lower bunk).
- **Safety Guardrails:** Full-length guardrails on the upper bunk for enhanced safety.
- **Built-in Ladder:** Provides easy access to the upper bunk.
- **Durable Construction:** Made from wood for stability and longevity.



Image: The Bellemave Twin Over Twin Bunk Bed shown in its standard bunk bed configuration.



Image: The Bellemave Twin Over Twin Bunk Bed disassembled into two separate twin beds, demonstrating its convertible feature.

SETUP (ASSEMBLY)

Assembly of the Bellemave Twin Over Twin Bunk Bed requires careful attention to detail. A clear and detailed assembly instruction guide is included with your purchase, along with all necessary tools.

General Assembly Steps:

1. Unpack all components and verify against the parts list provided in the assembly guide.
2. Follow the step-by-step instructions in the included manual for connecting frame pieces, installing slats, and attaching guardrails and the ladder.
3. Ensure all bolts and screws are securely tightened, but do not overtighten to avoid damaging the wood.
4. Periodically check all connections for tightness after assembly and during use.

Note: This item comes in 2 boxes. Ensure both boxes are received before beginning assembly.

OPERATING INSTRUCTIONS

To ensure safe and proper use of your bunk bed:

- Only use mattresses of the appropriate size for twin beds.
- Ensure mattresses are placed securely within the bed frame and do not exceed the height of the

guardrails on the upper bunk.

- Always use the built-in ladder for accessing the upper bunk. Do not climb on the guardrails or frame.
- Do not allow more than one person on the upper bunk at a time.
- Periodically inspect the bed for any loose parts or damage.

MAINTENANCE

Regular maintenance will help prolong the life and safety of your bunk bed:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Tightness Check:** Every 3-6 months, check all bolts, screws, and connections to ensure they are tight. Retighten as necessary.
- **Damage Inspection:** Regularly inspect the wood frame, slats, guardrails, and ladder for any signs of wear, cracks, or damage. Discontinue use if significant damage is found and contact customer support.

TROUBLESHOOTING

If you encounter issues with your bunk bed, consider the following:

- **Squeaking or Wobbling:** This often indicates loose connections. Re-check and tighten all bolts and screws. Ensure the bed is on a level surface.
- **Difficulty Assembling:** Refer to the detailed assembly guide provided. Ensure all parts are correctly oriented and that you are using the correct hardware for each step. Do not force parts together.
- **Missing Parts:** If any parts are missing upon unpacking, contact Bellemave customer support immediately.

SPECIFICATIONS



Image: Product dimensions and weight capacity details for the Bellemave Twin Over Twin Bunk Bed.

Feature	Detail
Model Number	GZZ000060TLK2
Product Dimensions	79.5"L x 41"W x 51.1"H
Size	Twin over Twin
Material	Wood
Finish Type	Painted (White)
Upper Bed Weight Capacity	175 LBS
Bottom Bed Weight Capacity	275 LBS
Compatible Mattress Size	Twin
Assembly Required	Yes
Included Components	Guardrails, Slats

Feature	Detail
Item Weight	48 pounds

RETURNS AND SUPPORT

For questions regarding assembly, missing parts, or product issues, please contact Bellemave customer support. Information regarding returns and replacements is typically handled through your point of purchase. For Amazon purchases, a 90-day free return, refund, or replacement policy is generally available.

For further assistance, please refer to the contact information provided by your retailer or visit the official Bellemave website.