

[Manuals.plus](#) /

› [KinetCam](#) /

› KinetCam Cat Camera Collar User Manual

KinetCam CAM-B

KinetCam Cat Camera Collar User Manual

Model: CAM-B

INTRODUCTION

Thank you for choosing the KinetCam Cat Camera Collar. This device allows you to capture your pet's adventures from their unique perspective. Designed for ease of use, this cordless camera records 1080P video directly to a micro SD card (not included), without the need for Wi-Fi or smartphone applications. This manual provides comprehensive instructions for setup, operation, maintenance, and troubleshooting to ensure you get the most out of your new pet camera.

Pet POV Camera

Record Their Own Story



Image: A cat wearing the KinetCam camera collar, capturing its surroundings.

WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- Wireless Camera

- Collar with Camera Holder
- USB Charging Cable
- User Manual



Image: Overview of included components.

SETUP GUIDE

1. Charging the Camera

Before first use, ensure the camera is fully charged. Connect the camera to a USB power source using the provided USB cable. A full charge typically takes approximately 5 hours. The indicator light will confirm that charging is in progress.

Button Control-Easy to Use



Image: The KinetCam camera, ready for charging.

2. Inserting the Micro SD Card

A micro SD card (NOT included) is required for recording. Insert the micro SD card into the camera with the metal contacts facing upwards. Ensure it clicks into place. The camera supports up to 128GB SD cards.




Image: Instructions for micro SD card insertion.

3. Assembling the Collar and Camera

Place the camera into the silicone holder with the lens facing up and the power button on the same side as the button on the holder. Adjust the holder's position on the collar to ensure the camera lens is clear and not blocked, providing an optimal recording angle for your pet.



Image: Proper camera orientation on the collar for best recording angle.

For a visual guide on installation, please refer to the official product video:

Your browser does not support the video tag.

Video: Official KinetCam demonstration of the Cat Collar Camera, showing its features and how it looks on a pet.

OPERATING INSTRUCTIONS

1. Recording Video

To start recording, simply press the power button on the camera. The indicator light will confirm that recording has begun. The camera records in 5-minute clips and will loop recordings until the battery runs out (approximately 90 minutes of continuous recording).





Image: Simple button control for recording.

2. Viewing Recorded Videos

To view your pet's adventures, connect the camera to your laptop using the provided USB cable. The camera will appear as a removable drive, allowing you to access and transfer the video files. Alternatively, you can remove the micro SD card

and use a card reader to view the videos on your computer.

Meet Your Pet's New Friend



Easy to check recorded videos.
Connect USB cable to play directly or
use microSD card reader.

**NOTE: The camera does NOT support
Wi-Fi or smartphone APP.**

Image: Connecting the camera to a laptop to view recorded videos.

MAINTENANCE AND CARE

- **Cleaning:** Wipe the camera and collar with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Water Resistance:** The silicone holder provides some rain protection, but the camera is not fully waterproof. Avoid submerging the camera in water.
- **Storage:** Store the camera in a cool, dry place when not in use.

- **Battery Care:** For optimal battery life, avoid fully discharging the battery frequently. Charge the camera regularly.


What's in Package



Image: Features of the upgraded silicone material for better protection.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Camera not turning on.	Low battery; not charged.	Charge the camera for at least 5 hours.
No video recording.	No micro SD card; SD card full or corrupted.	Insert a micro SD card; format or replace the SD card.
Poor video quality / blurry footage.	Lens obstructed; low light conditions (night vision active).	Ensure lens is clean and unobstructed; note that night vision records in black and white.
Cannot connect to computer.	Faulty USB cable; driver issue.	Try a different USB port or cable; ensure your computer's USB drivers are up to date.



Catching Pet's Adventure Time



Image: The KinetCam camera capturing pet adventures.

PRODUCT SPECIFICATIONS

Feature	Detail
Model Name	CAM-B
Video Resolution	1080P HD
Battery Life	Approx. 90 minutes (continuous recording)
Storage	Micro SD card (up to 128GB, not included)
Connectivity	USB (for data transfer and charging)
Weight	3.84 ounces
Material	Nylon (collar), Silicone (camera holder)
Dimensions (Camera)	1 x 3 x 1 inches



Image: The compact and lightweight design of the KinetCam camera.

WARRANTY AND SUPPORT

The KinetCam Cat Camera Collar is covered by a standard manufacturer's warranty. For specific warranty details, please refer to the documentation included with your purchase or contact KinetCam customer support.

If you encounter any issues or have questions not covered in this manual, please contact our customer support team:

Email: support@kinetcam.com

Phone: 1-800-XXX-XXXX (Placeholder, please refer to product packaging for actual number)

Website: [KinetCam Official Store](#)

Note: Contact information is illustrative. Please refer to your product packaging or official KinetCam website for the most accurate and up-to-date support details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question