Solac Kalmar 120W (Model ESS9550810L)

Solac Kalmar 120W Electric Blanket Instruction Manual

Model: Kalmar 120W (ESS9550810L)

Brand: Solac

1. Introduction

Thank you for choosing the Solac Kalmar 120W Electric Blanket. This manual provides essential information for the safe and efficient operation, maintenance, and care of your electric blanket. Please read all instructions carefully before first use and retain this manual for future reference.



Image 1.1: Solac Kalmar 120W Electric Blanket with controller.

2. Important Safety Instructions

To prevent fire, electric shock, or injury, always follow basic safety precautions when using electrical appliances. This electric blanket is designed for domestic use only.

- Do not use the blanket if it is wet or damp.
- Do not use the blanket if it is folded, crumpled, or bunched up, as this can cause overheating.
- Do not insert pins or other sharp objects into the blanket.
- Do not use with infants, children, incapacitated persons, or persons insensitive to heat.
- Always disconnect the blanket from the power supply before cleaning or if not in use for an extended period.
- Regularly inspect the blanket and its power cord for any signs of wear or damage. If damaged, do not use and contact qualified service personnel.
- Ensure the power cord is not trapped or pinched.
- This blanket features an **Overheating Protection System** to automatically shut off in case of excessive temperature.
- Do not dry clean. Follow washing instructions carefully.



Image 2.1: The electric blanket includes an overheating protection system for user safety.




Image 2.2: Detail showing the automatic shut-off feature and fabric properties.

3. Product Features

The Solac Kalmar Electric Blanket is designed for comfort and efficiency, incorporating several key features:

- **Instant and Homogeneous Heat:** Equipped with PTC + NTC technology for rapid and evenly distributed warmth.
- **Optimal Size:** Measures 150 x 90 cm, providing ample coverage.
- **Ultra-Soft Fabric:** Made from a combination of Polar Fleece and Sherpa fabric for maximum comfort.
- **Reversible Design:** Features a reversible design in grey and white stripes, offering versatility and aesthetic appeal.
- **Digital Temperature Control:** An illuminated digital controller provides 8 adjustable temperature levels to suit your preference.
- **Programmable Timer:** Includes a timer function for up to 9 hours, allowing you to set the desired operating duration.

- **Automatic Shut-off:** The blanket automatically turns off after the set timer duration or in case of overheating, enhancing safety.
- **Removable Connector:** The power connector is detachable, making the blanket suitable for machine washing.



Image 3.1: PTC + NTC technology ensures instant and homogeneous heat distribution.



Image 3.2: The blanket features ultra-soft, reversible Polar Fleece and Sherpa fabric.

4. Setup

Follow these steps to set up your electric blanket:

1. Unpack the electric blanket and controller from its packaging.
2. Lay the blanket flat on a bed, sofa, or desired surface. Ensure there are no folds or creases.
3. Locate the connector on the blanket and the corresponding plug on the controller cable.
4. Firmly insert the controller plug into the blanket's connector until it clicks into place. Ensure a secure connection.
5. Plug the power cord of the controller into a suitable electrical outlet.



Image 4.1: Connecting the removable controller to the blanket.

5. Operating Instructions

Using your Solac Kalmar Electric Blanket is straightforward:

1. **Turning On/Off:** Press the power button on the digital controller to turn the blanket on or off. The display will illuminate when on.
2. **Adjusting Temperature:** Use the '+' and '-' buttons to cycle through the 8 available temperature levels. The selected level will be shown on the backlit digital display.
3. **Setting the Timer:** Press the timer button to set the desired operating duration. You can set the timer for up to 9 hours. The blanket will automatically shut off once the set time has elapsed.
4. **Pre-heating:** For best results, turn on the blanket at a higher temperature setting approximately 15-30 minutes before use to pre-heat the area.
5. **During Use:** Once the desired warmth is achieved, you may lower the temperature setting for continuous comfort.



Image 5.1: The digital controller allows easy adjustment of temperature and timer settings.

6. Maintenance and Cleaning

Proper care will extend the life of your electric blanket:

- **Before Cleaning:** Always ensure the blanket is unplugged from the power outlet and the controller is detached from the blanket. Allow the blanket to cool completely.
- **Machine Washing:** The Solac Kalmar electric blanket is machine washable at 30°C (86°F). Use a gentle cycle and mild detergent.
- **Drying:** Do not tumble dry. Hang the blanket to air dry completely. Ensure it is thoroughly dry before reconnecting the controller and using it again.
- **Storage:** When not in use, store the blanket in a cool, dry place. Avoid folding it tightly or placing heavy objects on it, which could damage the internal heating elements.
- **Spot Cleaning:** For minor spills, spot clean with a damp cloth and mild detergent.



Image 6.1: The removable connector allows for safe machine washing at 30°C.

7. Troubleshooting

If you encounter issues with your electric blanket, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blanket does not heat up.	Not plugged in, controller not connected, power outage, or safety shut-off activated.	Ensure power cord is securely plugged into outlet and controller is firmly connected to blanket. Check household circuit breaker. If safety shut-off activated (e.g., due to overheating), unplug, let cool for 30 minutes, then try again.
Blanket heats unevenly.	Blanket is folded or bunched.	Lay the blanket flat and smooth out any folds or creases. Ensure it is not covered by heavy objects that could trap heat.

Problem	Possible Cause	Solution
Controller display is off.	Blanket is off, power issue, or controller malfunction.	Press the power button on the controller. Check power connection. If problem persists, contact customer support.
Blanket turns off unexpectedly.	Timer elapsed or overheating protection activated.	Check if the timer has reached its set duration. If not, the overheating protection may have activated. Unplug the blanket, allow it to cool for at least 30 minutes, then inspect for any damage or improper placement before restarting.

If the problem persists after attempting these solutions, please contact Solac customer support.

8. Specifications

Specification	Detail
Model Name	Kalmar 120W
Model Reference	ESS9550810L
Manufacturer	TAURUS ES
Dimensions	150 x 90 x 3 cm
Power	120W
Temperature Levels	8
Timer	Up to 9 hours
Special Functions	Automatic Shut-off, Portable, Overheating Protection, Timer
Material	Polar Plush (Soft Fleece and Sherpa)
Care Instructions	Machine washable at 30°C (removable connector)
Color	Grey (Reversible)
Country of Origin	Spain

9. Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or contact the retailer. You may also visit the official Solac website for further assistance.
Manufacturer: TAURUS ES
Seller: SDA Europe SLU

© 2024 Solac. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question