Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Beautyrest MM10917CK

Beautyrest Supreme Air California King Air Mattress Instruction Manual

Model: MM10917CK

Introduction

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Beautyrest Supreme Air California King Air Mattress. Designed for comfort and convenience, this air mattress features a built-in SureLock Auto Shut-off Pump, durable Dura-Vinyl material, and offset coil construction for a supportive sleep experience. Please read this manual thoroughly before initial use to ensure proper handling and longevity of your product.



Image: The Beautyrest Supreme Air California King Air Mattress, showcasing its raised design and plush top.

Setup Instructions

Unpacking and Preparation

1. Carefully remove the air mattress from its packaging.
2. Unroll the mattress on a clean, flat surface, free from sharp objects or debris. Ensure adequate space for inflation.
3. Locate the built-in pump on the side of the mattress.

Inflation Process

1. Ensure the pump dial is set to the "INFLATE" position.
2. Plug the power cord into a standard electrical outlet. The pump will begin to inflate the mattress.
3. The SureLock Auto Shut-off Pump features pressure-sensing technology and will automatically turn off once the desired firmness is reached. You can also manually turn the dial to "OFF" at any time to stop inflation.
4. Once inflated, unplug the power cord and store it in the integrated power cord storage compartment.



Image: Diagram illustrating the Smart Pump with auto shut-off feature, power cord storage, and inflation/deflation settings.



Image: The Beautyrest air mattress highlighting the SureLock pump, raised edge support, and auto shut-off for safety and convenience.

Operating Instructions

Adjusting Firmness

The built-in pump allows for adjustment of mattress firmness. If the mattress feels too soft, you can add more air by turning the dial to "INFLATE" and allowing the pump to run briefly. If it's too firm, briefly turn the dial to "DEFLATE" to release some air.

Deflation Process

1. Ensure the mattress is clear of any objects.
2. Plug the power cord into an electrical outlet.
3. Turn the pump dial to the "DEFLATE" position. The pump will actively remove air from the mattress.
4. The pump will automatically shut off once the mattress is fully deflated, facilitating easy storage.
5. Once deflated, unplug the power cord and store it.

Your browser does not support the video tag.

Video: An official video demonstrating the features and operation of the Beautyrest Supreme Air mattress, including inflation and deflation.

Maintenance

Cleaning

To clean your Beautyrest Supreme Air mattress, use a damp cloth with mild soap and water.**Hand wash only.** Do not use harsh chemicals or abrasive cleaners, as these can damage the vinyl material. Ensure the mattress is completely dry before storing.

Storage

After deflating and cleaning, fold or roll the mattress neatly. Store it in the provided carry bag in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid placing heavy objects on top of the stored mattress.



Image: The Beautyrest air mattress shown compactly stored in its carry bag, emphasizing portability.

Troubleshooting

- **Mattress not inflating/deflating:**
  - Ensure the power cord is securely plugged into a working electrical outlet.
  - Check that the pump dial is correctly set to "INFLATE" or "DEFLATE".
  - Verify there are no obstructions in the pump's air intake or exhaust.
- **Mattress losing air:**
  - The Beautyrest Supreme Air mattress features a 100% leak-free guarantee. If you suspect a leak, carefully inspect the mattress surface and seams for punctures or tears.
  - Ensure the pump dial is fully turned to the "OFF" position after inflation to seal the air.
  - Small drops in pressure can occur with temperature changes; this is normal. Add air as needed to maintain desired firmness.
- **Pump not turning off automatically:**
  - The auto shut-off feature activates when the mattress reaches optimal firmness or is fully deflated. If it continues to run, manually turn the dial to "OFF".
  - Ensure the pump is not obstructed.

Specifications

Model Name	Beautyrest 17" Supreme Air
Model Number	MM10917CK
Size	California King
Product Dimensions (L x W x Th)	84"L x 72"W x 17"Th
Material	Dura-Vinyl (Puncture-Resistant Vinyl with Poly Blend Fabric)
Weight Capacity	650 pounds
Pump Type	Built-in SureLock Auto Shut-off Pump
Special Features	Offset Coil Construction, Raised Edge Support, No-Tip Stabilizing Base, Compact, Leakproof
Included Components	Carry Bag
UPC	612650648510



Image: Details on the Dura-Vinyl material, highlighting its puncture resistance, durability, waterproofing, and easy cleaning. Also shows the California King dimensions (72"W x 84"L x 17"H).



Image: A visual comparison of different Beautyrest Supreme Air mattress sizes, including California King, Queen, Full, and Twin, with their respective dimensions.

Warranty and Support

Your Beautyrest Supreme Air mattress is backed by a **3-Year Pump Warranty** and a **100% Leak-Free Guarantee**. This provides assurance regarding the quality and durability of your product.

For warranty claims, technical support, or any inquiries, please refer to the contact information provided with your purchase documentation or visit the official Beautyrest website.

© 2023 Beautyrest. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DJV9GRMV

More documents and user manuals: **https://manuals.plus/**