

Nintiue F1378G

Nintiue Dimmable Gold Floor Lamp

Model: F1378G

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your Nintiue Dimmable Gold Floor Lamp, Model F1378G. Please read this manual thoroughly before installation and use to ensure safe and efficient operation.

SAFETY INFORMATION

- Ensure the power is off before installation, cleaning, or replacing bulbs.
- Use only the specified bulb type and wattage (E26 Medium base, max 80 Watts).
- Do not operate the lamp with a damaged cord or plug.
- Keep the lamp away from water and moisture.
- The heavy base is designed for stability; ensure it is placed on a flat, stable surface to prevent tipping.
- This product is for indoor use only.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Lamp Base
- Main Pole Sections
- 3 Arc Arms
- 3 Lamp Shades (Linen)
- 3 E26 LED Bulbs
- Fixing Rings
- Anti-skid Pad (pre-attached to base)

SETUP AND ASSEMBLY

Follow these steps for quick and easy assembly:

1. **Prepare the Lampshades:** Fit the metal rings into the clips on each lampshade to give them their cylindrical shape.
2. **Assemble the Main Pole:** Insert all main pole tubes and screw them securely together.
3. **Attach Pole to Base:** Insert the bottom tube of the main pole into the heavy lamp base and screw it firmly.
4. **Attach Arc Arms:** Insert each small arc arm into its designated slot on the main pole, then tighten the mini screws to secure them.
5. **Install Lampshades:** Unscrew the fixing ring from each bulb socket. Place a lampshade over the socket and then screw the fixing ring back to secure the lampshade.
6. **Install Bulbs:** Screw the provided E26 LED bulbs into each socket.




Image: Visual guide for assembling the Nintue Dimmable Gold Floor Lamp.

OPERATING INSTRUCTIONS

Power On/Off and Dimming


The lamp features a convenient dimmer switch on the main pole. To operate:

- **Turn On/Off:** Twist the knob on the main pole to turn the lamp on or off.
- **Adjust Brightness:** Once on, continue twisting the knob to adjust the brightness from 0% to 100%. This stepless dimming allows for precise light control for any activity, from bright task lighting to soft ambient light.



10%-100%

STEPLESS DIMMING BRIGHTNESS



Stepless Dimmable Brightness

Image: The integrated knob dimmer switch for power and brightness control.



Easy to adjust brightness from 0 to 100%

Image: Illustration of the dimming capability from 0% to 100%.

Adjusting Arc Arms

The three lamp arms can rotate freely 360 degrees. This allows you to direct light precisely where needed, making the lamp versatile for various room layouts and lighting requirements.



Image: The multi-angle adjustable arms can rotate 360 degrees.

Official Product Videos

Video: Demonstration of the Nintue Dimmable Floor Lamp, highlighting its features and use in a living room or bedroom setting.

Video: Overview of the Dimmable Floor Lamp with 3 Arc Lights, showcasing its design and functionality.

Video: Demonstration of the Dimmable Floor Lamp with 3 Black Arc Lights, highlighting its modern design and dimming capabilities.

Video: A brief overview of the tall lamp, showcasing its suitability for various spaces.

MAINTENANCE

- **Cleaning:** Disconnect the power before cleaning. Wipe the lamp with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Bulb Replacement:** Ensure the lamp is unplugged and the bulbs have cooled before attempting to replace them. Use E26 Medium base LED bulbs, not exceeding 80 watts.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on	No power, loose bulb, faulty switch	Check power outlet, ensure plug is fully inserted. Tighten bulbs. Contact customer support if switch is faulty.
Light flickers	Loose bulb, incompatible dimmer, faulty bulb	Tighten bulbs. Ensure bulbs are dimmable. Replace faulty bulb.
Lamp is unstable	Uneven surface, loose pole connection	Place on a flat, stable surface. Ensure all pole sections are securely screwed.

SPECIFICATIONS

- **Model Name:** F1378G

- **Product Dimensions:** 15"D x 46"W x 69"H
- **Item Weight:** 17.7 Pounds
- **Material:** Metal (Base Material: Metal, Finish Type: Metallic)
- **Shade Material:** Linen
- **Shade Color:** Beige
- **Number of Light Sources:** 3
- **Bulb Base:** E26 Medium
- **Light Source Type:** LED
- **Maximum Compatible Wattage:** 80 Watts (per bulb)
- **Wattage (Included Bulbs):** 8 watts (per bulb)
- **Light Output Maximum:** 1000 Lumens (per bulb)
- **Color Temperature:** 2700 Kelvin (Warm White)
- **Switch Type:** Dimmer
- **Power Source:** Corded Electric
- **Voltage:** 120 Volts (AC)
- **Indoor/Outdoor Usage:** Indoor
- **Assembly Required:** Yes

WARRANTY AND SUPPORT

Nintue offers 100% support for all products. If your lamp has any defects or ceases to function within **3 years** of purchase, please contact customer service for troubleshooting assistance or a brand-new product replacement. Customer satisfaction is our priority.

For support, please refer to the contact information provided with your purchase or visit the official Nintue store online.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question