

Optimus MG-BULKH-7232

Optimus Portable 360 Surround Ceramic Heater with Thermostat

Model: MG-BULKH-7232

INTRODUCTION

Thank you for choosing the Optimus Portable 360 Surround Ceramic Heater with Thermostat. This manual provides important information for the safe operation, installation, maintenance, and troubleshooting of your new heater. Please read all instructions carefully before use and retain this manual for future reference.

IMPORTANT SAFETY INSTRUCTIONS

WARNING: To reduce the risk of fire, electric shock, or injury, observe the following safety precautions:

- Read all instructions before using this heater.
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Always unplug the heater when not in use.
- Do not operate any heater with a damaged cord or plug, or after the heater malfunctions or has been dropped or damaged in any manner.
- Do not use outdoors.
- This heater is not intended for use in bathrooms, laundry areas, or similar indoor locations. Never locate heater where it may fall into a bathtub or other water container.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect heater, turn controls to OFF, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.

- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- This heater includes a tip-over safety switch that automatically shuts off the heater if it is accidentally tipped over.
- This heater is equipped with an overheat protection system that will shut off the heater if parts of the heater get excessively hot.

PRODUCT OVERVIEW

The Optimus Portable 360 Surround Ceramic Heater is designed to provide efficient and even heating for your personal space. Its compact design and 360-degree heat distribution make it suitable for various indoor environments.



Image: Optimus Portable 360 Surround Ceramic Heater with Thermostat. This image displays the white ceramic heater with a black 360-degree mesh grille at the top, a white carrying handle, and a control panel on the front featuring two silver-accented rotary knobs and a red indicator light. The base and lower sides have horizontal vents.

Components:

- **Carrying Handle:** For easy portability.

- **360-Degree Grille:** Allows for omnidirectional heat distribution.
- **Thermostat Control Knob:** Adjusts the desired room temperature.
- **Function Control Knob:** Selects operating modes (Off, Fan Only, Low Heat, High Heat).
- **Power Indicator Light:** Illuminates when the heater is operating.
- **Air Intake/Exhaust Vents:** Located around the base and top grille.

SETUP

1. **Unpacking:** Carefully remove the heater from its packaging. Retain packaging for off-season storage.
2. **Placement:** Place the heater on a firm, level surface. Ensure there is at least 3 feet (0.9 meters) of clear space around the heater from walls, furniture, and other objects. Do not place it on soft surfaces like rugs or carpets that could block the air intake.
3. **Power Connection:** Ensure the heater is in the OFF position (Function Control Knob set to 'O'). Plug the power cord directly into a 120V AC, 60Hz wall outlet. Do not use extension cords or power strips.

OPERATING INSTRUCTIONS

1. **Power On:** With the heater plugged in, turn the Function Control Knob to your desired setting:
 - **Fan Only (▲):** Operates the fan without heat.
 - **Low Heat (I):** Provides low heat output.
 - **High Heat (II):** Provides maximum heat output.

The red power indicator light will illuminate when the heater is on.

2. **Set Thermostat:** Turn the Thermostat Control Knob (marked '-' to '+') to the maximum setting ('+') initially. Once the room reaches a comfortable temperature, slowly turn the Thermostat Control Knob counter-clockwise until the heater turns off. The heater will now cycle on and off to maintain this set temperature.
3. **Power Off:** To turn off the heater, turn the Function Control Knob to the 'O' (OFF) position. Unplug the heater from the wall outlet when not in use.

Safety Features:

- **Tip-Over Switch:** The heater will automatically shut off if it is tipped over. Place it upright on a stable surface to resume operation.
- **Overheat Protection:** If the heater overheats due to blocked air vents or other reasons, it will automatically shut off. Unplug the heater, allow it to cool for 10-15 minutes, and clear any obstructions before plugging it back in and resuming use.

MAINTENANCE

Always unplug the heater before cleaning or performing any maintenance.

- **Cleaning:** Use a soft, damp cloth to wipe the exterior surfaces of the heater. Do not use abrasive cleaners or solvents. Ensure no water enters the interior of the heater.
- **Air Vents:** Periodically vacuum the air intake and exhaust vents to remove dust and lint buildup. Do

not use the heater without the grilles in place.

- **Storage:** When not in use, store the heater in its original packaging in a cool, dry place.

TROUBLESHOOTING






Problem	Possible Cause	Solution
Heater does not turn on.	Not plugged in; Function Control Knob is OFF; Thermostat set too low; Overheat protection activated; Tip-over switch activated.	Ensure plug is firmly in outlet; Turn Function Control Knob to a heat setting; Increase Thermostat setting; Unplug, cool, and clear obstructions; Place heater upright on a stable surface.
Heater produces insufficient heat.	Thermostat set too low; Room size too large for heater capacity.	Increase Thermostat setting; Ensure heater is appropriate for the room size.
Heater cycles on and off frequently.	Thermostat setting is close to room temperature; Overheat protection activating.	Adjust thermostat to a slightly higher or lower setting; Check for blocked air vents and clear if necessary.

SPECIFICATIONS

- **Model Number:** MG-BULKH-7232
- **Type:** Portable 360 Surround Ceramic Heater
- **Power Source:** 120V AC, 60Hz
- **Manufacturer:** Optimus
- **Safety Features:** Tip-Over Switch, Overheat Protection

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or contact the retailer where the product was purchased. Keep your purchase receipt as proof of purchase.

 <p>To activate your tracker, please follow these easy steps:</p> <ol style="list-style-type: none"> 1. Go to our website: www.OptimusTracker.com 2. Click on the "Activate Tracker" link. 3. Fill out the form. You will need the IMEI number. It's the 15-digit number that is printed on the tracker's label. 4. After subscribing, wait a minute for the activation email. Make sure to check your spam/junk folder too. 	<p>Optimus GV75 MG Real-Time GPS Tracker Activation and Installation Guide</p> <p>Learn how to activate and install the Optimus GV75 MG real-time GPS tracker for your vehicle. This guide provides step-by-step instructions, LED status indicators, and wiring details.</p>
 <p>OPTIMUS Professional Series</p> <p>Digital Synthesized Audio/Video Surround Receiver STAV-3590</p>	<p>Optimus STAV-3590 Digital Synthesized Audio/Video Surround Receiver Owner's Manual</p> <p>Comprehensive owner's manual for the Optimus STAV-3590 Digital Synthesized Audio/Video Surround Receiver. Covers setup, basic operation, advanced sound options, remote control usage, troubleshooting, safety instructions, and specifications.</p>
 <p>Optimus 2.0 Manual</p> <p>To activate your tracker, please follow these easy steps:</p> <ol style="list-style-type: none"> 1. Go to our website: www.OptimusTracker.com 2. Click on the "Activate Tracker" link. 3. Fill out the form. You will need the IMEI number. It's the 15-digit number that is printed on the tracker's label. 4. After subscribing, wait a minute for the activation email. Make sure to check your spam/junk folder too. <p>About your Tracker</p> <ul style="list-style-type: none"> GPS: Use the top button, press down for 3 seconds until the light starts to flash. The tracker will start automatically when you start the engine. GPS: Use the top button, press down for 3 seconds and you see the indicator and it goes. The tracker may take up to 10 minutes to find your location. BATTERY: Pressing Battery is low or Battery is empty. GPS: Use the top button. CELLULAR: Press 3 times: Searching for cellphone signal. Press 2 times: Connected to cellphone signal. <p>Take the device outside to acquire signal.</p> <p>Installation videos: optimustracker.com/videos</p>	<p>Optimus 2.0 GPS Tracker Manual - Activation and Usage Guide</p> <p>A concise guide for activating and using the Optimus 2.0 GPS Tracker. Learn about its features, status indicators, and contact information for vehicles, assets, and people.</p>
 <p>OPTIMUS NOVA</p>	<p>Optimus Nova Multifuel Camping Stove Gebruikershandleiding en Veiligheidsgids</p> <p>Leer hoe u de Optimus Nova multifuel camping stove veilig en efficiënt gebruikt met deze uitgebreide handleiding. Inclusief bediening, onderhoud en tips voor buitenavonturen.</p>
 <p>Optimus 3.0 Bundle Manual</p> <p>To activate your tracker, please follow these easy steps:</p> <ol style="list-style-type: none"> 1. Go to our website: www.OptimusTracker.com 2. Click on the "Activate Tracker" link. 3. Fill out the form. You will need the IMEI number. It's the 15-digit number that is printed on the tracker's label. 4. After subscribing, wait a minute for the activation email. Make sure to check your spam/junk folder too. <p>About your Tracker</p> <ul style="list-style-type: none"> GPS: Use the top button, press down for 3 seconds until the light starts to flash. The tracker will start automatically when you start the engine. GPS: Use the top button, press down for 3 seconds and you see the indicator and it goes. The tracker may take up to 10 minutes to find your location. BATTERY: Pressing Battery is low or Battery is empty. GPS: Use the top button. CELLULAR: Press 3 times: Searching for cellphone signal. Press 2 times: Connected to cellphone signal. <p>Take the device outside to acquire signal.</p> <p>Installation videos: optimustracker.com/videos</p>	<p>Optimus 3.0 Bundle Manual: GPS Tracker Activation and Installation Guide</p> <p>This manual provides comprehensive instructions for activating, installing, and using the Optimus 3.0 GPS tracker bundle. Learn about device features, status indicators, optimal placement, troubleshooting, and warranty information for reliable tracking of vehicles, assets, and people.</p>

