

Dystler B0DJVMS73N

Dystler Jewelry Cabinet with LED Lights Instruction Manual

Model: B0DJVMS73N

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Dystler Jewelry Cabinet with LED Lights. Please read this manual thoroughly before installation and use to ensure proper function and longevity of the product. This jewelry cabinet features a full-length mirror, integrated LED lighting, and extensive internal storage for various jewelry and cosmetic items.

2. SAFETY INFORMATION

- Ensure all components are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Keep small parts away from children to prevent choking hazards.
- Install the cabinet on a stable and level surface or wall. If hanging over a door, ensure the door is sturdy enough to support the weight.
- Do not overload the cabinet, as this may compromise its stability and structural integrity.
- Handle the mirror with care. It is made of explosion-proof glass, but excessive force can still cause damage.
- For LED lights, use 3 AA batteries (not included). Do not mix old and new batteries, or different types of batteries. Remove batteries if the cabinet will not be used for an extended period.
- Avoid exposing the cabinet to direct sunlight or high humidity, which can damage the material and finish.

3. PACKAGE CONTENTS

Verify that all the following components are included in your package:

- 1 x Dystler Jewelry Cabinet
- 1 x Accessories Kit (includes mounting hardware, keys)

- 1 x Instruction Manual (this document)

4. ASSEMBLY AND SETUP

The Dystler Jewelry Cabinet offers two primary mounting options: wall-mounted or over-the-door hanging.

4.1. Over-the-Door Installation

1. Attach the adjustable door hangers to the top of the cabinet using the provided screws from the accessories kit. Ensure they are securely fastened.
2. Carefully hang the cabinet over the top edge of a sturdy door. Adjust the hangers to achieve the desired height.
3. Verify that the cabinet hangs evenly and does not obstruct the door's movement.



Figure 4.1: Two Mounting Options: Wall-Mounted or Over-the-Door.




Figure 4.2: Adjustable Height Door Hanger.

4.2. Wall-Mounted Installation

1. Choose a suitable wall location. Mark the desired height and position for the cabinet.
2. Using the provided template (if included) or by measuring the mounting holes on the back of the cabinet, mark the drilling points on the wall.
3. Drill pilot holes at the marked points. Insert wall anchors if necessary (for drywall).
4. Align the cabinet's mounting holes with the drilled holes and secure it to the wall using the provided screws. Ensure the cabinet is level and firmly attached.



Figure 4.3: Wall Mounting Option.

5. OPERATING INSTRUCTIONS

5.1. LED Lighting System

1. **Battery Installation:** Locate the battery compartment, typically inside the cabinet. Insert 3 AA batteries (not included), ensuring correct polarity.
2. **Power On/Off:** The LED lights are controlled by a smart touch button located on the mirror surface. Touch the button to turn the lights on or off.
3. **Color Temperature Adjustment:** Short press the touch button to cycle through the three available color temperatures:
 - **6500K Cool White:** Bright, clear light for detailed tasks.
 - **4000K Warm White:** Neutral light, suitable for everyday use.

- **3000K Warm Yellow:** Soft, ambient light.

4. **Brightness Adjustment:** Long press the touch button to dim or brighten the lights. Release when the desired brightness is achieved.



Figure 5.1: 3 Color LED Light Modes.



Figure 5.2: Battery Installation and Light Switch.

5.2. Internal Storage Organization

The cabinet interior is designed for organized storage of various items:

- **Earring Slots:** 72 slots for earrings.
- **Necklace Hooks:** 24 hooks for necklaces and longer chains.
- **Ring Slots:** 52 slots for rings.
- **Cosmetic Pockets:** 2 clear pockets for smaller items.
- **Acrylic Cosmetic Boxes:** 3 boxes for makeup and brushes.
- **Lip Gloss Display Case:** 10 slots for lip gloss or similar items.
- **Blush and Highlighter Caddy:** 2 compartments.
- **Bracelet Rods:** 3 rods for bracelets or watches.
- **Skincare Display Shelves:** 3 shelves for skincare products or perfumes.



Figure 5.3: Interior Storage Layout.

5.3. Locking Mechanism

The cabinet is equipped with a lockable mechanism to secure your valuables. Use the provided keys to lock and unlock the cabinet door. Ensure the door is fully closed before attempting to lock it.




Figure 5.4: Lockable Door Keys.

6. MAINTENANCE

- **Cleaning the Exterior:** Wipe the exterior surfaces, including the mirror, with a soft, damp cloth. For the mirror, use a glass cleaner if necessary, and wipe dry immediately to prevent streaks.
- **Cleaning the Interior:** Use a soft, dry cloth or a lint roller to clean the velvet lining. For cosmetic boxes and shelves, wipe with a damp cloth and dry thoroughly.
- **Hinge Maintenance:** Periodically check the metal hinges for tightness. If they become loose, gently tighten the screws.
- **Battery Replacement:** Replace AA batteries for the LED lights when they dim or stop working.

7. TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|---|---|--|
| LED lights do not turn on. | <ul style="list-style-type: none"> ◦ Batteries are dead or incorrectly installed. ◦ Touch sensor malfunction. | <ul style="list-style-type: none"> ◦ Check battery polarity and replace with fresh AA batteries. ◦ Ensure the touch sensor area is clean and dry. If problem persists, contact customer support. |
| Cabinet door does not close properly. | <ul style="list-style-type: none"> ◦ Hinges are loose or misaligned. ◦ Obstruction inside the cabinet. | <ul style="list-style-type: none"> ◦ Tighten hinge screws. Adjust hinges if necessary. ◦ Remove any items blocking the door's closure. |
| Cabinet feels unstable (over-the-door). | <ul style="list-style-type: none"> ◦ Hangers are not securely attached or adjusted. ◦ Door is too thin or not sturdy. | <ul style="list-style-type: none"> ◦ Ensure hangers are tightened and adjusted for a snug fit. ◦ Consider wall-mounting if the door is unsuitable. |

8. SPECIFICATIONS

| | |
|---------------------------------------|---|
| Brand | Dystler |
| Model | B0DJVMS73N |
| Material | Engineered Wood, Velvet (inner lining) |
| Product Dimensions (D x W x H) | 3.94"D x 15"W x 43.5"H |
| Color | Black |
| Special Features | 3 Color Dimmable LED Lights, Interior Vanity Mirror, Lockable, Over-the-Door/Wall Mount Options |
| Power Source for Lights | 3 x AA Batteries (not included) |
| Storage Capacity | 72 Earring Slots, 24 Necklace Hooks, 52 Ring Slots, Cosmetic Pockets, Acrylic Boxes, Shelves |
| Closure Type | Key Lock |

9. WARRANTY AND SUPPORT

Your Dystler Jewelry Cabinet comes with an 18-month warranty, extendable by an additional 12 months for a total of 30 months, ensuring a hassle-free experience.

For any questions, concerns, or support needs, please contact Dystler Customer Care. Our support team is available 24/7 to assist you.



Figure 9.1: Customer Support and Warranty Information.