

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Panasonic](#) /

› [Panasonic Fully Automatic Washing Machine 7kg NA-F7PB3-W User Manual](#)

Panasonic NA-F7PB3-W

Panasonic NA-F7PB3-W 7kg Fully Automatic Washing Machine User Manual

Model: NA-F7PB3-W

1. INTRODUCTION AND OVERVIEW

Thank you for purchasing the Panasonic NA-F7PB3-W 7kg Fully Automatic Washing Machine. This manual provides essential information for the safe and efficient use of your new appliance. The NA-F7PB3-W features a popular compact design combined with powerful 'Big Wave Washing' technology, ensuring thorough cleaning results.



This image shows the Panasonic NA-F7PB3-W 7kg fully automatic washing machine from a top-down perspective, highlighting its compact design and control panel.

2. SAFETY INFORMATION

Before operating the washing machine, please read all safety instructions carefully to prevent injury or damage. Keep this manual for future reference.

- Always ensure the washing machine is properly grounded.
- Do not operate the machine with a damaged power cord or plug.
- Keep children and pets away from the washing machine during operation.
- Do not wash items that are waterproof or easily flammable.
- Always turn off the power and unplug the machine before cleaning or performing maintenance.

3. SETUP AND INSTALLATION

Proper installation is crucial for the performance and longevity of your washing machine. Ensure adequate space and stable placement.

3.1 Space Requirements

When carrying in and installing the washing machine, ensure sufficient clearance. For product dimensions, an additional 10cm or more width is required for doorways, entrances, and corridors. For the height of the entrance frame, consider the effective width and frame height.

商品寸法+10cm以上の幅が必要です。

《搬入における確認項目》


※段差やコーナー箇所があり、直線ではない場合、+10cm以上の幅が必要となります。
※手すり・照明・装飾物などがある場合、そちらから+10cmの幅が必要となります。

〈商品の寸法〉




〈玄関の高さ〉

商品寸法+10cm




〈玄関の幅〉

商品寸法+10cm




〈廊下の幅〉

商品寸法+10cm




〈エレベータの幅〉

商品寸法+10cm




〈階段の幅〉

商品寸法+10cm




《設置における確認項目》

・必要なスペースは商品によって異なるため、詳細はメーカーページなどでご確認ください。
・洗濯機の設置時にはドアを開閉するため上部のスペース確保が必要となります。



防水パンの有無と内側サイズをチェック



※排水エルボ・足台の有無と排水口位置によって、追加費用がかかることがあります。


This diagram provides crucial measurements and clearances needed for carrying in and installing the washing machine, ensuring it fits through various household entry points and has adequate space for operation.

For installation, ensure at least 1cm clearance from the wall on the left/right sides and behind the unit. When opening the top door, allow an additional 10-15cm of space for full opening. Check for the presence of a waterproof pan and its inner dimensions. Additional costs may be incurred depending on the presence of a drain elbow/foot stand and drain port location.

3.2 Connecting Water and Drain Hoses

Connect the water supply hose to a cold water faucet and the drain hose to a suitable drain. Ensure all connections are secure to prevent leaks. The drain hose connection side requires 9cm or more clearance.

NA-F7PB3



- 本体設置時、本体奥行寸法 (530 mm) と排水ホース寸法 (43 mm) をご確認ください
- 左右の手掛け部を含むと本体幅 524 mm になります

This technical drawing provides exact measurements for the front and side views of the NA-F7PB3 washing machine, including height, width, and depth, crucial for precise installation planning.

4. OPERATING INSTRUCTIONS

Your Panasonic washing machine is designed for ease of use with a clear digital display and intuitive controls.

4.1 Control Panel Overview

デジタル表示と視認性の良い表記で 操作がしやすい

デジタル表示つき操作パネル



バスポンプ機能付き

洗濯終了時間を1時間単位で24時間後まで予約できます

- 「すすぎ1回」「お急ぎ」コースは1～24時間後、「おまかせ」「わたし流」「毛布」「つけおき」コースは2～24時間後です。
- 「手洗い」「槽洗浄(1時間)」「槽洗浄(11時間)」「槽乾燥」「サッと槽すすぎ」コースでは予約設定できません。

This detailed view of the digital control panel illustrates its user-friendly interface, allowing easy selection of wash, rinse, spin, water level, reservation, bath water, and various washing courses. It also features a child lock function.

The digital display and clearly labeled buttons make operation simple. Key functions include: Power (), Wash (), Rinse (), Spin (), Water Level (), Reservation (), Bath Water (), and Course (). A Child Lock () function is also available.

4.2 Washing Cycles and Features

- **Big Wave Washing** (): This feature utilizes a unique pulsator with three large blades and three protrusions to create a powerful three-dimensional water flow, ensuring thorough cleaning even with low water levels.

水位が低いときでもしっかりもみ洗い

ビッグウェーブ洗浄



3枚の大きな羽根と
3個の突起をもつ
ビッグウイング
パルセーターで
立体水流を起こし、
しっかり洗浄。

立体的な水流

ビッグウイング
パルセーター

(イメージ図)

This illustration demonstrates the 'Big Wave Washing' feature, where a unique pulsator with three large blades and three protrusions creates a powerful three-dimensional water flow for thorough cleaning, even with low water levels.

- **Karamihogushi () - Untangling Function:** This function loosens tangled laundry after spin-drying, making it significantly easier to remove clothes from the tub with minimal effort.

洗濯物のからみを緩和し、 軽い力でずるっと取り出しやすい※1

※1 衣類の量や種類により異なります。

からみほぐし

「からみほぐし」前



衣類がからみ、
ドーナツ状に貼り付く

「からみほぐし」後



衣類のからみが
ほぐれている

・写真はNA-F7PB3 脱水終了直後と、脱水終了後「からみほぐし」運転後の比較。洗濯容量1.8 kgの場合
●「からみほぐし」は「おまかせ」コース時に自動運転します。●容量制限：約1.2 kg～4.5 kg (NA-F5B3のみ約1.2 kg～3.5 kg) ●運転時間：容量に応じて約1～4分で変動します。

This image set compares laundry before and after the 'Karamihogushi' (untangling) function. It shows how the feature loosens tangled clothes, making them easier to remove from the tub after washing and spinning.

- **Available Courses:** The machine offers various courses including Auto (), Blanket (), Soak (), Hand Wash (), and My Course ().
- **Reservation Function:** You can reserve the wash completion time in 1-hour increments, up to 24 hours in advance. Note that some courses like 'Rinse 1 time', 'Quick', 'Auto', 'My Course', 'Blanket', 'Soak', 'Hand Wash', 'Tub Clean (1 hour)', 'Tub Clean (11 hours)', and 'Tub Dry' cannot be reserved.

5. MAINTENANCE

Regular maintenance ensures optimal performance and hygiene of your washing machine.

5.1 Tub Cleaning Courses

The washing machine offers a full range of courses to keep the washing tub clean and prevent mold and odors.

洗濯槽を清潔に保つコースが充実

月に1回
(目安)

NEW

槽洗浄(1時間)コース

月1回・わずか1時間で洗濯槽の黒カビ・ニオイを抑制※1。

週に1回
(目安)

槽乾燥コース

約1時間の送風運転で洗濯槽を乾燥させ、黒カビを抑制※2。

本格的な
お手入れ

槽洗浄(11時間)コース

洗濯槽クリーナー(別売)を使って、本格的に洗濯槽の汚れを除去。

※1〈槽洗浄(1時間)コースによる黒カビ抑制〉[試験機関](一財)日本食品分析センター [試験成績書発行年月日] 2024年6月19日 [試験成績書発行番号] 第24042880001-0101号 [試験方法] 菌液の生菌数測定 [黒カビ抑制方法] 塩素系漂白剤による [対象部分] 洗濯・脱水槽 [試験結果] 菌の減少率99%以上(パナソニック換算値)。

※2〈「槽乾燥」コースによる黒カビ抑制〉[試験機関](一財)日本食品分析センター [試験成績書発行年月日] 2021年6月25日 [試験成績書発行番号] 第20125190001-0101号 [試験方法] 洗濯・脱水槽に取り付けた培地付着布の黒カビ抑制確認 [黒カビ抑制方法]「槽乾燥」による [対象部分] 洗濯・脱水槽 [試験結果] 黒カビの発育なし。

This graphic outlines the various maintenance courses available to keep the washing tub clean. It includes a recommended monthly 1-hour tub clean, a weekly tub dry course, and a thorough 11-hour tub clean using a separate cleaner.

- **Tub Clean (1 hour) Course:** Recommended once a month to suppress black mold and odors.
- **Tub Dry Course:** Recommended once a week, this course uses approximately 1 hour of air circulation to dry the tub and suppress black mold.
- **Tub Clean (11 hours) Course:** For thorough cleaning, use this course with a separately sold washing tub cleaner to remove stubborn dirt.

5.2 Lint Filter Cleaning

The 'Rakupoi Filter' is designed for easy disposal of lint without getting your hands dirty.

手を汚さずに 糸くずをポイツと捨てられる

楽ポイフィルター

約160 mLの
大容量
フィルター



水位が低くても
しっかり捕集

(写真はNA-F7PB3)

抗菌※
加工



・糸くずはイメージです。

※ <[抗菌加工樹脂]による抗菌効果について> [試験機関] (一財)カケンテストセンター [試験方法] JIS Z 2801
に基づく [抗菌方法] 樹脂に抗菌剤を含有 [対象部品] 糸くずフィルター [試験結果] 抗菌活性値2.0以上。

This image highlights the 'Rakupoi Filter,' a large-capacity (approx. 160mL) lint filter with antibacterial properties, designed for easy removal and disposal of lint without direct contact.

Regularly clean the lint filter to maintain washing performance. The filter has an antibacterial processing for improved hygiene.

6. TROUBLESHOOTING

If you encounter any issues with your washing machine, please refer to the following common troubleshooting tips. For more detailed solutions, consult the full product manual or contact customer support.

- **Machine does not start:** Check if the power plug is securely inserted and if the circuit breaker has tripped. Ensure the lid is properly closed.
- **No water supply:** Verify that the water faucet is fully open and that the water supply hose is not kinked or blocked.
- **Unusual noise or vibration:** Ensure the machine is level and stable. Check if laundry is unevenly distributed inside the tub. Remove any foreign objects from the tub or pulsator.

- **Water leakage:** Check all hose connections for tightness. Ensure the drain hose is properly positioned and not blocked.
- **Laundry not clean:** Do not overload the machine. Use the appropriate amount of detergent for the load size and water hardness. Select the correct wash course for the type of laundry.

7. SPECIFICATIONS

Key specifications for the Panasonic NA-F7PB3-W 7kg Fully Automatic Washing Machine:

Product Specifications

Feature	Specification
Brand Name	Panasonic
Model Number	NA-F7PB3-W
Color	White
Product Dimensions (Depth x Width x Height)	57.2 x 56.2 x 95.7 cm
Product Weight	35 Kilograms
Wash/Spin Capacity	7 kg
Bath Pump Function	Included
Washing Function	Big Wave Washing
Cleaning Functions	Tub Dry Course, Tub Clean (1 hour) Course, Tub Clean (11 hours) Course
Ease of Use Features	Karamihogushi (Untangling), Rakupoi Filter

7.1 Model Comparison

	NA-F7PB3	NA-F7B3	NA-F6B3	NA-F5B3
				
洗濯・脱水容量	7 kg	7 kg	6 kg	5 kg
バスポンプ	● 風呂水吸水機能			
洗浄機能	ビッグウェーブ 洗浄	ビッグウェーブ 洗浄	ビッグウェーブ 洗浄	ビッグウェーブ 洗浄
清潔機能	槽乾燥コース/ 槽洗浄(1時間)コース/ 槽洗浄(11時間)コース	槽乾燥コース/ 槽洗浄(1時間)コース/ 槽洗浄(11時間)コース	槽乾燥コース/ 槽洗浄(1時間)コース/ 槽洗浄(11時間)コース	槽乾燥コース/ 槽洗浄(1時間)コース/ 槽洗浄(11時間)コース
	サッと槽すすぎ コース			
コース	わたし流コース			
	つけおきコース	つけおきコース	つけおきコース	つけおきコース
使いやすさ	からみほぐし (約1.2～4.5 kg)	からみほぐし (約1.2～4.5 kg)	からみほぐし (約1.2～4.5 kg)	からみほぐし (約1.2～3.5 kg)
	楽ポイフィルター	楽ポイフィルター	楽ポイフィルター	楽ポイフィルター

This table compares the NA-F7PB3 model with other Panasonic washing machines (NA-F7B3, NA-F6B3, NA-F5B3), outlining differences in wash/spin capacity, presence of a bath pump, washing functions (like Big Wave Washing), cleaning functions, and available wash courses.

8. WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included with your product or visit the official Panasonic website. For technical support, spare parts, or service inquiries, please contact Panasonic customer service. Keep your purchase receipt as proof of purchase.

You can find more information and support resources on the official Panasonic website: www.panasonic.com

