

[Manuals.plus](#) /

› [Smiling Shark](#) /

› Smiling Shark G350 Camping Light User Manual

Smiling Shark G350

Smiling Shark G350 Camping Light User Manual

Model: G350

1. PRODUCT OVERVIEW

The Smiling Shark G350 is a versatile 2-in-1 camping light designed for both reliable illumination and ambient lighting. Constructed from high-quality aluminum alloy and transparent materials, it offers durability for various outdoor activities and emergency situations. Its compact and lightweight design makes it highly portable.



Figure 1: Smiling Shark G350 Camping Light

2. PACKAGE CONTENTS

Please verify that all items are present in the package:

- G350 Camping Lamp x1
- Wearable Rope x1
- Charging Cable x1
- User Manual x1




Figure 2: Included components in the package

3. SETUP

3.1 Charging the Device

Before first use, fully charge the G350 Camping Light. The device uses a Type-C charging port.

1. Locate the charging port by unscrewing the top cap of the light.
2. Connect the provided USB-C charging cable to the light and a suitable USB power source (e.g., computer, wall adapter).
3. The indicator light will show charging status (e.g., red for charging, blue for fully charged).



Figure 3: Type-C Charging Port location

3.2 Attaching the Lanyard

The included lanyard allows for convenient carrying or hanging.

1. Attach the carabiner clip of the lanyard to the metal ring at the top of the G350 light.
2. Ensure the connection is secure.

Video 1: Demonstration of attaching the lanyard and basic operation.

4. OPERATING INSTRUCTIONS

The G350 Camping Light features multiple lighting modes for various needs.

4.1 Power On/Off and Mode Switching

1. **Power On:** Press and hold the power button for approximately 2-3 seconds to turn on the light.
2. **Mode Cycle:** Short press the button to cycle through the following modes: High White Light (8000K) → Weak White Light → High Warm Light (2000K) → Weak Warm Light.
3. **Strobe Light:** Double-click the button quickly to activate the white strobe light for emergency signaling.
4. **Power Off:** Press and hold the power button again for approximately 2-3 seconds to turn off the light.



Figure 4: Cool White Light (8000K)



Figure 5: Soft Warm Light (2000K)




Figure 6: White Strobe Light for emergencies

4.2 Usage Scenarios

The G350's compact size and wearable design make it suitable for various applications:

- **Wearable:** Use the lanyard to wear the light around your neck for hands-free illumination during hiking or walking.
- **Hanging:** Hang the light inside a tent, from a backpack, or on a branch for ambient or task lighting.
- **Emergency:** The strobe mode can be used as a distress signal.




Figure 7: Neck-worn and hanging configurations




Figure 8: Various usage scenarios

5. MAINTENANCE

5.1 Water Resistance

The G350 Camping Light has an IPX4 waterproof rating, meaning it is resistant to splashes from any direction. It is

suitable for use in light rain or damp conditions.

Important: IPX4 rating does not mean the device is waterproof for submersion. Do not immerse the light in water.

Video 2: Demonstration of the IPX4 waterproof feature.



Figure 9: IPX4 Waterproof Rating

5.2 Cleaning and Storage

- Wipe the light with a soft, damp cloth to clean. Do not use harsh chemicals.
- Store the light in a cool, dry place when not in use.
- Ensure the charging port cap is securely fastened to maintain water resistance.

6. TROUBLESHOOTING

If you encounter issues with your G350 Camping Light, please refer to the following common solutions:

- **Light not turning on:** Ensure the battery is charged. Connect the light to a power source and check the charging indicator.
- **Light not charging:** Verify that the charging cable is properly connected to both the light and the power source. Try a different USB port or adapter.
- **Inconsistent light modes:** Ensure the button is being pressed correctly (short press for mode cycle, double-click for strobe, long press for on/off).

If problems persist, please contact customer support.

7. SPECIFICATIONS

Feature	Detail
Model Number	G350-DE
Light Source Type	Light Emitting Diode (LED)
Color Temperature (White Light)	8000K
Color Temperature (Warm Light)	2000K

Power Source	Rechargeable Battery (1 LR44 included)
Material	Aluminum
Water Resistance Level	IPX4 (Splash Resistant)
Mounting Type	Hanging
Item Weight	0.22 Pounds (approx. 100g)
Item Dimensions (L x W x H)	1.77"L x 4.72"W x 1.77"H

8. WARRANTY AND SUPPORT

8.1 Warranty Information

The Smiling Shark G350 Camping Light comes with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

The warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or failure to follow the instructions in this manual.

8.2 Customer Support

For technical assistance, warranty claims, or any questions regarding your Smiling Shark G350 Camping Light, please contact the seller, Smiling Shark, through the platform where the product was purchased.

Please have your purchase details and model number (G350) ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DJW75N5K>

More documents and user manuals: <https://manuals.plus/>