Zippo 2006812

Zippo Butane Lighter Insert (Model 2006812) User Manual

Brand: Zippo | Model: 2006812

Introduction

This manual provides essential instructions for the safe and effective use, setup, and maintenance of your Zippo Butane Lighter Insert. This insert is designed to convert any standard Zippo lighter case into a refillable, adjustable yellow flame butane lighter, offering an odorless and clean-burning heat source.

Safety Information

- **WARNING:** Contains extremely flammable gas under pressure. Keep away from children.
- Do not expose to heat or prolonged sunlight.
- Do not puncture or incinerate container.
- Use only Zippo butane fuel for optimal performance and safety.
- Ensure the lighter is extinguished before closing the lid to prevent accidental gas release.

Package Contents

- Zippo Butane Lighter Insert (Yellow Flame)
- Instruction Manual



Image: Zippo Butane Lighter Insert shown in its gift packaging.

Setup

1. Inserting the Butane Insert

1. Open your standard Zippo lighter case.
2. Remove the existing insert (if any) from the case.
3. Align the Zippo Butane Lighter Insert with the opening of the Zippo case.
4. Gently slide the butane insert into the case until it fits snugly. The insert is designed to fit all regular-sized Zippo cases, excluding Slim or 1935 Replica cases.



Image: The Zippo Butane Lighter Insert ready for insertion into a Zippo case.

2. Refilling Butane Fuel

1. Hold the insert upside down.
2. Locate the refill valve on the bottom of the insert.
3. Firmly insert the nozzle of a Zippo butane fuel can into the refill valve.
4. Press down for approximately 5-6 seconds. A slight hiss indicates the fuel is entering the reservoir.
5. Remove the fuel can. Wait a few seconds for the fuel to stabilize before attempting to ignite.

3. Adjusting Flame Height

1. Locate the flame adjustment screw on the bottom of the insert, next to the refill valve.
2. Use a small screwdriver or a similar tool to turn the screw.
3. Turn towards the '+' symbol for a higher flame, or towards the '-' symbol for a lower flame.
4. Test the flame after each adjustment until the desired height is achieved.



Image: The bottom of the insert, highlighting the butane refill valve and flame adjustment screw.

Operating Instructions

1. Open the Zippo lighter case.
2. Press the ignition button/lever to ignite the yellow flame.
3. Release the ignition button/lever to extinguish the flame.
4. Close the Zippo lighter case to protect the insert and prevent accidental ignition.

The Zippo Butane Lighter Insert produces an odorless yellow flame, providing a clean-burning heat source.



Image: A Zippo lighter case fitted with the butane insert, displaying its yellow flame.

Maintenance

- **Refilling:** Regularly refill the insert with Zippo butane fuel as described in the Setup section to ensure consistent performance.
- **Flint Wheel:** The insert features a replaceable flint wheel ignition. If ignition becomes inconsistent, the flint may need replacement. Refer to Zippo's official resources for detailed instructions on flint replacement for butane inserts.
- **Cleaning:** Keep the ignition area free from debris. Use a soft, dry cloth to wipe down the insert as

needed. Do not use abrasive cleaners or solvents.

Troubleshooting

- **Lighter does not ignite:** Check if the insert has sufficient butane fuel. Refill if necessary. Ensure the ignition button/lever is fully depressed.
- **Weak or inconsistent flame:** This may indicate low fuel or an improperly adjusted flame height. Refill the butane or adjust the flame height using the screw on the bottom of the insert.
- **Gas leaks:** Ensure the refill valve is properly sealed after refilling. If leaks persist, discontinue use and contact Zippo customer support.
- **Lid does not close properly:** Check for any obstructions within the Zippo case or on the insert itself. Ensure the insert is fully seated within the case.

Specifications

Brand	Zippo
Model Number	2006812
Color	Silver
Material	Metal
Style	Butane
Fuel Type	Liquefied Petroleum Gas (Butane)
Item Weight	1.76 ounces (50 Grams)
Product Dimensions	5.12"L x 1.18"W x 2.36"Th

Warranty and Support

Zippo offers a comprehensive **2-year limited warranty** on this product. For warranty claims, technical support, or further assistance, please visit the official Zippo website or contact their customer service department.
You can find more information and products at theZippo Store.