

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Pursonic](#) /

› [Pursonic Luxury Towel Warmer Bucket TW600 User Manual](#)

Pursonic TW600

Pursonic Luxury Towel Warmer Bucket

MODEL: TW600 USER MANUAL

IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Do not immerse the appliance, cord, or plug in water or other liquids.
- Keep the appliance away from water sources, such as bathtubs, showers, or sinks.
- Ensure the voltage indicated on the appliance matches your local power supply before connecting.
- Unplug the appliance from the outlet when not in use and before cleaning.
- Do not operate the appliance with a damaged cord or plug, or if it malfunctions or has been damaged in any manner.
- Do not allow the power cord to hang over the edge of a table or counter, or touch hot surfaces.
- This appliance is for household use only. Do not use outdoors.
- Do not place flammable materials inside the warmer.
- Always ensure the lid is properly closed during operation.
- Keep out of reach of children.

PRODUCT OVERVIEW

The Pursonic Luxury Towel Warmer Bucket Model TW600 is designed to provide warm towels for a comfortable experience. It features quick heating technology, a spacious interior, and an intuitive LED display with adjustable timer settings.

Key Features:

- **Quick Heating:** Heats up in 60 seconds, reaching high temperatures in 4 minutes.
- **Large Capacity:** 23-liter interior accommodates multiple towels.
- **LED Display:** Digital interface for clear visibility of settings.
- **Adjustable Timer:** Three preset timer settings (20, 40, 60 minutes) with automatic shut-off.

- **Portable Design:** Lightweight with side handles for easy relocation.

SETUP

1. **Unpack the Towel Warmer:** Carefully remove all packaging materials and inspect the unit for any damage. Retain packaging for future storage or transport.
2. **Choose a Location:** Place the towel warmer on a flat, stable, heat-resistant surface. Ensure it is away from water sources and out of reach of children. Allow adequate space around the unit for ventilation.
3. **Connect Power:** Plug the power cord into a standard electrical outlet. Ensure the outlet meets the voltage requirements specified on the appliance.

OPERATING INSTRUCTIONS

1. **Prepare Towels:** Fold or roll your towels neatly and place them inside the warmer bucket. Do not overfill the bucket, as this may hinder proper heating. The 23-liter capacity can hold up to two large bath towels or several smaller items.
2. **Close the Lid:** Ensure the lid is securely closed before operating the unit.
3. **Power On:** Press the 'ON/OFF' button on the LED display to turn on the towel warmer. The display will illuminate.
4. **Select Timer Setting:** Press the 'Time' button to cycle through the available timer settings: 20 minutes, 40 minutes, or 60 minutes. The selected time will be shown on the LED display. The unit will begin heating immediately after a timer is selected.
5. **Heating Process:** The towel warmer will quickly heat your towels. It reaches initial warmth in 60 seconds and high temperatures in approximately 4 minutes.
6. **Automatic Shut-off:** The unit will automatically turn off once the selected timer duration has elapsed, ensuring safety and energy efficiency.
7. **Retrieve Towels:** Carefully open the lid and remove your warm towels. Be cautious as towels may be hot.



Fast Heating Technology



Heats up in just 60 seconds



Achieves high heat in just 4 minutes



Perfect for quick post-shower or bath luxury

Image: The Pursonic Towel Warmer highlighting its fast heating capabilities, warming in 60 seconds and reaching high heat in 4 minutes.

Spacious Capacity



Holds up to 2 large towels or several small ones



23-liter large capacity ideal for family use



Lightweight, portable design with side handles for easy movement



Image: The Pursonic Towel Warmer with its lid open, illustrating the 23-liter spacious interior designed for multiple towels.

LED Display with Adjustable Timer



Features 3 adjustable timer settings



Auto shut-off to prevent over-heating



Clear LED display and timer visibility



Image: A detailed view of the Pursonic Towel Warmer's LED display and control panel, showing timer settings and power buttons.

Enjoy Cozy, Heated Towels in Minutes



Image: A user placing a folded towel into the Pursonic Towel Warmer, demonstrating the ease of loading.

MAINTENANCE

- **Cleaning:** Before cleaning, always unplug the towel warmer from the power outlet and allow it to cool completely. Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish. Do not immerse the unit in water.
- **Storage:** When not in use, ensure the unit is clean and dry. Store it in a cool, dry place, away from direct sunlight and moisture.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Towel warmer does not turn on.	Not plugged in; power outlet malfunction; unit malfunction.	Ensure the power cord is securely plugged into a working outlet. Test the outlet with another appliance. If the problem persists, contact customer support.
Towels are not getting warm.	Lid not closed properly; unit overfilled; timer not set.	Ensure the lid is fully closed. Do not overfill the bucket. Select a timer setting. Allow sufficient time for heating (up to 4 minutes for high heat).
LED display is not working.	Power issue; internal fault.	Check power connection. If the unit is receiving power but the display is off, unplug and plug back in. If the issue continues, contact customer support.

SPECIFICATIONS

- **Model Number:** TW600
- **Manufacturer:** PURSONIC
- **Capacity:** 23 Liters
- **Package Dimensions:** 21.3 x 15.4 x 14.9 inches
- **Item Weight:** 14.02 pounds
- **Power:** (Voltage/Wattage not specified in input, assume standard household)
- **Timer Settings:** 20, 40, 60 minutes (with auto shut-off)
- **Batteries Required:** No

WARRANTY AND SUPPORT

For warranty information or technical support, please contact Pursonic customer service. Refer to your purchase documentation for specific warranty terms and contact details.

You can typically find support information on the manufacturer's official website or by contacting the retailer where the product was purchased.