Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > SWOFY /
- > SWOFY M503 Pro 80GB MP3/MP4 Player User Manual

SWOFY M503 Pro (P11)

SWOFY M503 Pro 80GB MP3/MP4 Player User Manual

Model: M503 Pro (P11) | Brand: SWOFY


1. Introduction

This manual provides essential instructions for the operation and maintenance of your SWOFY M503 Pro 80GB MP3/MP4 Player. This device is a versatile digital audio and video player equipped with an 8-core processor, 2GB RAM, 16GB internal ROM, and an included 64GB SD card, expandable up to 1TB. It features a 4-inch IPS touch screen, dual-band Wi-Fi (2.4 & 5GHz), and Bluetooth 4.2 for seamless connectivity. The player supports a wide range of audio and video formats and comes with pre-installed applications for an enhanced media experience.

2. PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- SWOFY M503 Pro MP3/MP4 Player
- USB Type-C Charging Cable
- Wired Earphones
- Screen Protector
- Protective Case
- User Manual (this document)
- 64GB Micro SD Card (pre-installed or included separately)



3. DEVICE OVERVIEW

The SWOFY M503 Pro features a compact design with a 4-inch IPS touch screen. Key physical features include:

- **Display:** 4-inch IPS Touch Screen (480*800px resolution)
- Ports: USB Type-C charging port, 3.5mm headphone jack, Micro SD card slot.
- Controls: Power button, volume buttons (located on the side).
- Color: Red (as per current model)






Image: Side view of the SWOFY M503 Pro, highlighting the USB Type-C port, 3.5mm headphone jack, and Micro SD card slot.

4. INITIAL SETUP

- 1. **Power On:** Press and hold the power button located on the side of the device for approximately 2 seconds until the SWOFY logo appears on the screen.
- 2. **Language and Time Settings:** Upon first boot, you will be prompted to select your preferred language (e.g., English (United States)) and adjust the date and time settings. Follow the on-screen instructions.

3. Connect to Wi-Fi:

- Swipe down from the top of the screen to access the quick settings panel.
- · Long-press the Wi-Fi icon to open Wi-Fi settings.
- Toggle Wi-Fi ON if it's off.
- Select your desired Wi-Fi network from the list and enter the password if prompted.
- · Once connected, the device will have internet access for app downloads and streaming.

5. BASIC OPERATION

The SWOFY M503 Pro operates using an intuitive touch screen interface. Navigation is similar to a smartphone.

- **Home Screen:** After setup, you will see the home screen with various app icons. Swipe left or right to view additional app pages.
- Opening Apps: Tap an app icon to launch it.
- Volume Control: Use the physical volume buttons on the side of the device to adjust audio output.
- Music Playback: Use the pre-installed music player app or streaming apps like Spotify to play audio files. The device supports creating playlists and scanning for local music files.



Image: The player's screen showing a music playback interface with song title, artist, and playback controls.




Image: The player's home screen displaying icons for various applications including Clock, Calendar, Calculator, Sound Recorder, FM Radio, Apple Music, Spotify, Audible, Amazon Music, Deezer, Chrome, and Play Store.

6. STORAGE MANAGEMENT

The device comes with 16GB of internal ROM and an additional 64GB Micro SD card, providing a total of 80GB of storage. The storage can be expanded further up to 1TB using a compatible Micro SD card.

- **File Transfer:** Connect the player to a computer using the provided USB Type-C cable to transfer music, videos, and other files. The device will appear as a removable storage drive.
- **SD Card:** The included 64GB SD card can store a large number of songs and files. Ensure it is properly inserted into the Micro SD card slot.
- **File Manager:** Use the pre-installed File Manager app to browse, organize, and manage files on both internal and external storage.



Image: Visual representation of the player's storage, indicating the included 64GB SD card and support for expansion up to 512GB (note: product specifications state up to 1TB).

7. CONNECTIVITY

The SWOFY M503 Pro offers robust wireless connectivity options:

- Wi-Fi: Built-in Dual Band 2.4 & 5GHz Wi-Fi ensures a stable and strong wireless signal for streaming and app usage.
- **Bluetooth 4.2:** Features two-way sending and receiving, allowing stable connections to Bluetooth headphones, Bluetooth speakers, and car audio systems.



Image: The player connected via Bluetooth to wireless earbuds, illustrating its stable duplex Bluetooth functionality for headphones, home speakers, and car systems.

8. BATTERY MANAGEMENT

The player is equipped with a 2000mAh lithium battery designed for extended use.

- **Battery Life:** Provides approximately 50 hours of continuous music playback (with wired earphones) or 8 hours of video playback.
- **Charging:** Use the provided USB Type-C cable to charge the device. A full charge typically takes about 2 hours.
- Charging Reminder: It is recommended to charge the device fully before first use and when the battery is low to maintain optimal battery health.



Image: Information graphic showing the 2000mAh battery capacity, 50 hours of music playback, and 8 hours of video playback.

9. MEDIA PLAYBACK

The SWOFY M503 Pro supports a wide array of media formats for both audio and video content.

- Audio Formats: MP3, WAV, FLAC, AAC, APE, OGG, M4A, WMA, MP2, and more.
- Video Formats: Supports 720p and 1080p videos in formats such as RM, AVI, RMVB, FLV, MP4, DAT, MKV, MPG, MOV, TS.
- High-Definition Playback: The 4-inch IPS screen provides a clear viewing experience for videos.



Image: The player displaying a video on its 4-inch screen, demonstrating its 1080P HD full format video playback capability.

10. APPLICATIONS

The device comes with several pre-installed applications and supports additional app installations.

- **Pre-installed Apps:** Includes popular streaming apps like Spotify, Amazon Music, Audible, Libby, LibriVox, and Kindle. Other utilities such as a voice recorder, FM radio, ebook reader, file transfer, clock, calendar, calculator, gallery, and file manager are also available.
- **App Installation:** You can install additional apps and update existing ones. Note that apps requiring Google Play Services (e.g., YouTube, YouTube Music) are not supported as the device does not include Google Play Services.
- **Parental Control:** A parental control feature allows kids to download apps only with parental authorization. Unnecessary apps can be deleted to free up memory.



Image: The player's screen displaying icons for pre-installed applications, emphasizing its multifunctional capabilities.

11. TROUBLESHOOTING

If you encounter issues with your SWOFY M503 Pro, consider the following:

- **Device Crash/App Issues:** If an installed application causes the device to crash, delete the problematic app. If issues persist, a factory reset may be necessary (ensure to back up important files first).
- **SD Card Not Read:** Ensure the Micro SD card is correctly inserted. If the issue continues, try reinserting or formatting the card (this will erase all data on the card).
- Forgot Password: If you forget your device password, the original default password is1234.
- **Charging Issues:** Ensure the USB Type-C cable is securely connected to both the player and a power source. Use a compatible wall charger.
- **No Sound:** Check the volume levels and ensure headphones or Bluetooth devices are properly connected and functioning.

12. Specifications

Feature	Detail
Model Name	M503 Pro
Item Model Number	P11
Brand	SWOFY
Memory Storage Capacity	80 GB (16GB internal + 64GB SD card)
Expandable Memory	Up to 1 TB (Micro SD)
RAM	2GB
Processor	MTK 8-Core
Operating System	Android 9.0
Screen Size	4 Inches
Screen Resolution	480*800px

Feature	Detail
Special Feature	Touch Screen
Connectivity Technology	Bluetooth 4.2, Wi-Fi (2.4 & 5GHz)
Battery Capacity	2000mAh
Battery Life (Music)	Up to 50 Hours (wired earphones)
Battery Life (Video)	Up to 8 Hours
Charging Port	USB Type-C
Item Weight	8.8 ounces
Color	Red
UPC	765826118758

13. WARRANTY AND SUPPORT

For warranty information, technical support, or any inquiries regarding your SWOFY M503 Pro MP3/MP4 Player, please refer to the contact details provided on the product packaging or visit the official SWOFY website. Keep your purchase receipt for warranty claims.

Related Documents - M503 Pro (P11)

SWOFY USER MANUAL WITH PARTS WITH A MANUAL AND	SWOFY D50 MP3 Player User Manual User manual for the SWOFY D50 MP3 Player. This guide provides detailed instructions on features such as music playback, Bluetooth connectivity, FM radio, recording, e-book reading, and device settings. Learn to maximize your portable digital music experience.
USER MANUAL BOSTIN, MARKE	SWOFY D26 Digital Player User Manual Comprehensive user manual for the SWOFY D26 Digital Player, covering features, operations, settings, specifications, and warnings. Learn how to use your portable media device.
SWOFY USER MANUAL MORE MORE MORE MORE MORE MORE MORE MORE	SWOFY M501 Digital Player User Manual User manual for the SWOFY M501 Digital Player, covering setup, features, specifications, and warnings.
SWOFY User Manual so soon reques From season assessing distance become to wrent on and season assessing distance become to wrent on	SWOFY M4 Music Player User Manual - Features, Specifications & Operation Comprehensive user manual for the SWOFY M4 Music Player. Learn about its features, specifications, music playback, movie support, FM radio, Bluetooth connectivity, and more.

SWOFY USER MANUAL BOOK MASSE AND	SWOFY M503 Pro Digital Player User Manual Comprehensive user manual for the SWOFY M503 Pro digital player, covering buttons, charging, gesture operations, settings, specifications, and important warnings.
SWOFY USER MANUAL DOUBLE AGEN THE STATE OF	SWOFY M503Pro Digital Player User Manual Comprehensive user manual for the SWOFY M503Pro digital player, covering setup, features, settings, specifications, and warnings. Learn how to use your device effectively.