

Karl home KHDR04016

Karl home White 7 Drawer Dresser Instruction Manual

MODEL: KHDR04016

Important Safety Information

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- **Anti-Tipping Device:** An anti-tipping device is included to prevent accidental tipping. It is crucial to install this device securely to a wall stud to ensure the safety of your household, especially for children.
- **Weight Capacity:** Do not overload drawers. Distribute weight evenly to maintain stability.
- **Assembly:** Ensure all parts are correctly assembled and fasteners are tightened before use.
- **Placement:** Place the dresser on a flat, level surface.

Official Karl home video demonstrating the stability features of a 5-drawer dresser, including the anti-tipping device.

Package Contents

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Dresser Panels (Top, Bottom, Sides, Back)
- Drawer Fronts, Sides, and Bottoms
- Rose Gold Handles
- Drawer Slides and Runners
- Assembly Hardware (Screws, Dowels, Cam Locks, etc.)
- Anti-Tipping Device Kit
- Instruction Manual

Assembly Instructions (Setup)

Assembly typically requires 1-2 people and takes approximately 60-90 minutes. A detailed step-by-step manual with

labeled parts is included in the package. Follow the instructions precisely for correct assembly.

1. **Unpack and Identify:** Carefully unpack all components and lay them out. Identify each part using the labels and the provided parts list.
2. **Assemble Frame:** Begin by assembling the main frame of the dresser according to the manual's diagrams. Ensure all connections are secure.
3. **Install Drawer Slides:** Attach the drawer slides to the dresser frame and to the drawer sides as indicated in the instructions.
4. **Assemble Drawers:** Construct each of the seven drawers, ensuring the bottoms are firmly in place and the handles are attached.
5. **Insert Drawers:** Carefully slide the assembled drawers into their respective slots on the dresser frame.
6. **Attach Anti-Tipping Device:** Securely attach the anti-tipping device to the back of the dresser and to a wall stud using the provided hardware. This step is critical for safety.



Image showing the overall product dimensions (25.98"L x 12.99"D x 40.55"H) and individual drawer dimensions.

Operating Instructions

The Karl home 7 Drawer Dresser is designed for versatile storage in various rooms.

- **Drawer Usage:** The dresser features 5 large drawers (22.83"L x 10.03"D x 3.54"H) and 2 smaller drawers (11.02"L x 10.03"D x 3.54"H). Use the rose gold handles to smoothly open and close the drawers.
- **Storage Capacity:** The large drawers are suitable for clothing, linens, or bulkier items. The smaller drawers are ideal for organizing smaller items such as accessories, socks, or baby essentials.
- **Versatile Placement:** This dresser can function as a bedroom dresser, a storage cabinet in the living room, a drawer chest for a nursery, or an organizer in a hallway or office.



Rose Gold Handles

Add a touch of elegance to your room

Durable Drawer Slides

The metal slide rail is not only durable but also smooth, convenient for daily use.



Anti-Tipping Device

Safety is our priority, anti-tipping devices add extra protection for your family

Image illustrating the ample storage capacity for various items like clothes, books, and decorative objects.

Ample Storage



Image highlighting the utility of the small drawers for organizing smaller items.

Maintenance and Care

Proper care will extend the life and appearance of your Karl home dresser.

- **Cleaning:** Wipe the surface with a dry, soft cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the matte spray-painted finish.
- **Spills:** Promptly wipe up any spills to prevent staining or damage to the engineered wood.
- **Drawer Slides:** Periodically check drawer slides for smooth operation. If needed, a small amount of silicone lubricant can be applied to the runners.
- **Hardware:** Occasionally check and tighten any loose screws or fasteners to maintain structural integrity.



Image detailing the rose gold handles, durable drawer slides, and the anti-tipping device for safety and longevity.

Troubleshooting

If you encounter any issues with your dresser, refer to the following common solutions:

- **Drawers are Sticking or Not Closing Smoothly:**

- Check if the drawer slides are properly aligned and free of obstructions.
- Ensure the drawer is not overloaded or unevenly weighted.
- Verify that all screws on the drawer slides are tightened.

- **Dresser Feels Unstable:**

- Confirm that the dresser is placed on a level surface.
- Ensure the anti-tipping device is correctly installed and securely anchored to a wall stud.
- Check all assembly fasteners and tighten any that are loose.

- **Missing or Damaged Parts:**

- Refer to the package contents list. If parts are missing or damaged upon arrival, contact Karl home customer support for assistance.

Specifications

Feature	Detail
Brand	Karl home
Model Name	KHDR04016
Material	Engineered Wood
Finish Type	White
Product Dimensions (Overall)	12.99"D x 25.98"W x 40.55"H
Number of Drawers	7 (5 large, 2 small)
Item Weight	67.9 pounds
Mounting Type	Free Standing (with anti-tipping device)
Product Care Instructions	Wipe with Dry Cloth

Warranty and Support

Your Karl home dresser is designed for quality and durability.

- **Returns:** This product is eligible for 30-day easy returns. Please refer to the retailer's return policy for specific details.
- **Customer Support:** For any questions, concerns, or assistance with assembly or parts, please contact Karl home customer support. Contact information can typically be found on the packaging or the retailer's website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question