

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [JZAQ](#) /

> [JZAQ BT40 Motorcycle Helmet Bluetooth Headset User Manual](#)

JZAQ BT40

JZAQ BT40 Motorcycle Helmet Bluetooth Headset User Manual

Model: BT40

INTRODUCTION

Thank you for choosing the JZAQ BT40 Motorcycle Helmet Bluetooth Headset. This manual provides detailed instructions for the proper installation, operation, and maintenance of your device. Please read this manual thoroughly before use to ensure optimal performance and safety.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1 x Helmet Headset (BT40)
- 6 x Headphone VELCRO (Adhesive Pads)
- 1 x USB Charging Cable
- 1 x User Manual
- 2 x Noise Reducing Sponge Heads (Microphone Covers)





Image: The JZAQ BT40 Helmet Bluetooth Headset, including the main unit with speakers and microphone, USB charging cable, and various adhesive pads and microphone covers.

SPECIFICATIONS

Model Name	BT40
-------------------	------

Bluetooth Version	V5.0+EDR
Bluetooth Distance	Up to 10 meters (33 feet)
Battery Type	3.7V/600mA Lithium Battery
Charging Time	Approximately 2 hours
Standby Time	Up to 500 hours
Working Time (Playtime/Talk Time)	Up to 90 hours
Water Resistance	IP67 Deep Waterproof Technology
Headphone Thickness	0.35 inches (approx. 9mm)
Noise Control	DSP Noise Cancelling Technology
Compatible Devices	Smartphones, MP3 Players, GPS Devices



Image: A diagram illustrating the dimensions of the headset's earpieces, speaker, microphone, and control unit, highlighting the 0.35-inch thickness of the earpieces.

SETUP AND INSTALLATION

Follow these steps to properly install the BT40 headset into your helmet:

1. **Prepare Earphones:** Take the helmet headphones from the box. Attach the "Magic Tape" (Velcro adhesive pads) to the back of both earphones.
2. **Position Earphones:** Remove the protective tape paper from the Velcro on the earphones. Carefully position and stick the earphones into the helmet's ear recesses on both sides. Ensure proper alignment before pressing firmly.
3. **Secure Headset:** Once the Velcro is attached to the helmet, secure the headset earphones to these Velcro pads.
4. **Microphone Placement:** Position the microphone arm so that the microphone is close to your mouth for clear communication.
5. **Final Check:** Ensure all components are securely attached and comfortable within the helmet.

Important Note: Before ordering, please check the inner size of your helmet to ensure a comfortable fit for the headset.

The headset's ultra-thin design (0.35 inches) is suitable for most helmets without causing discomfort.

Helmet Bluetooth headset

does not squeeze the ears

Ultra-thin

suitable for all helmets

Image: The BT40 headset featuring its ultra-thin speakers, designed to fit comfortably within helmet ear spaces without squeezing the ears.

Simple operation and automatic answering make riding safer.



Image: A motorcycle helmet with the JZAQ BT40 headset microphone arm visible, demonstrating typical installation.

OPERATING INSTRUCTIONS

Power On/Off and Pairing

- **Power On:** Press and hold the Power button (usually the middle button on the control unit) until the indicator light illuminates.
- **Power Off:** Press and hold the Power button until the indicator light turns off.
- **Pairing:** When powered on for the first time or when entering pairing mode, the headset will automatically search for Bluetooth devices. On your smartphone or other Bluetooth-enabled device, search for "BT40" in the Bluetooth settings and select it to connect.
- **Automatic Connection:** After initial pairing, the headset will automatically connect to the last paired device when powered on, if the device is within range.

Call Management

- **Answer Call:** The headset supports automatic answering of incoming calls.
- **End Call:** Press the Power button once to end an active call.
- **Reject Call:** Press and hold the Power button for approximately 2 seconds to reject an incoming call.

Music Playback

- **Play/Pause:** Press the Power button once to play or pause music.
- **Volume Up:** Press the "+" button to increase volume.
- **Volume Down:** Press the "-" button to decrease volume.
- **Next Song:** Press and hold the "+" button for approximately 2 seconds to skip to the next track.
- **Previous Song:** Press and hold the "-" button for approximately 2 seconds to go to the previous track.

Voice Assistant

- **Activate Voice Assistant:** Double-click the Power button to activate your smartphone's voice assistant (e.g., Siri, Google Assistant).



Ipx6-Ipx7 Waterproof
Don't worry about snow and rain

Image: A detailed view of the headset's control unit, showing the volume up (+), power/play/pause, and volume down (-) buttons, along with the microphone.

Your browser does not support the video tag.

Video: An overview of the JZAQ Motorcycle Helmet Bluetooth Headset BT40, demonstrating its components and basic features.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the headset. Avoid using harsh chemicals or abrasive materials.
- **Water Exposure:** While the headset is IP67 waterproof, prolonged submersion or exposure to high-pressure water jets should be avoided. Ensure the charging port cover is securely closed when not charging.
- **Storage:** Store the headset in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the headset regularly, even if not in use for extended periods.
- **Microphone Sponge:** Replace the noise-reducing sponge head on the microphone if it becomes worn or damaged to maintain optimal voice clarity.



Image: The BT40 headset with water droplets, demonstrating its IP67 deep waterproof capability, suitable for use in rainy or snowy conditions.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Headset does not power on.	Low battery.	Charge the headset for at least 2 hours using the provided USB cable.
Cannot pair with device.	Bluetooth is off on the device; headset is not in pairing mode; too far from device.	Ensure Bluetooth is enabled on your device. Make sure the headset is powered on and in pairing mode. Move the headset closer to the device (within 10 meters). Try restarting both devices.

No sound or low volume.	Volume too low on headset or connected device; improper connection.	Increase volume using the "+" button on the headset and on your connected device. Re-pair the headset with your device.
Microphone not picking up voice clearly.	Microphone not positioned correctly; damaged sponge cover.	Adjust the microphone arm so the microphone is close to your mouth. Replace the noise-reducing sponge head if it is worn.
Intermittent connection.	Interference; device too far; low battery.	Move away from sources of strong electromagnetic interference. Ensure the headset is within 10 meters of the connected device. Charge the headset.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official JZAQ website. If you experience any dissatisfaction or issues, please contact customer service for assistance.


Contact: Please refer to your purchase documentation or the seller's information on the platform where you purchased the product.



© 2025 JZAQ. All rights reserved.

Related Documents - BT40

	<p>GS Tooling ShrinkSMART Machine Operating Manual</p> <p>Comprehensive operating manual for the GS Tooling ShrinkSMART machine, detailing installation, usage, maintenance, safety precautions, and technical specifications for shrink fitting tool holders.</p>
	<p>SpacePak BT Series Hydronic Buffer Tank Installation, Operation & Maintenance Manual</p> <p>This manual provides detailed instructions for the installation, operation, and maintenance of SpacePak BT Series Hydronic Buffer Tanks. It includes specifications, dimensions, electrical connections, piping diagrams, replacement parts, and warranty information for models BT13-H, BT26-H, BT40-H, and BT80-H.</p>

	<p>SNDWAY Bluetooth Laser Distance Meter User Manual</p> <p>Comprehensive user manual for the SNDWAY Bluetooth Laser Distance Meter, covering safety regulations, product functions, battery usage, operation, measurement modes (single, continuous, area, volume, Pythagorean theorem), Bluetooth connectivity, technical specifications, maintenance, and error messages.</p>
	<p>Showa Tool Precision Chucks & Tap Holders: Micron, Hard, Synchro Series</p> <p>Explore Showa Tool's advanced Micron Chuck, Hard Chuck, and Synchro Tap Holder series, offering unparalleled precision, clamping power, and durability for high-performance machining applications. Discover detailed specifications and application examples.</p>
	<p>NT BT Tooling System: Milling Chucks & Collet Holders</p> <p>Discover the NT BT Tooling System catalog, featuring a comprehensive range of high-performance milling chucks, collet holders, shrink fit holders, and accessories. Detailed specifications and model numbers for precision industrial machining applications.</p>
	<p>Terragene BT40 Spore Strip Biological Indicator for EO and Dry Heat Sterilization</p> <p>Product description for Terragene's BT40 Spore Strip Biological Indicator, designed for monitoring ethylene oxide (EO) and dry heat sterilization processes. Includes specifications, usage, applicable regulations, and storage conditions.</p>