Mova K30 Mix

Mova K30 Mix Wet Dry Vacuum Cleaner Instruction Manual

Brand: Mova | **Model:** K30 Mix

Your comprehensive guide to operating and maintaining your Mova K30 Mix for optimal cleaning performance.

1. Introduction

The Mova K30 Mix is a versatile 4-in-1 cordless wet and dry vacuum cleaner designed for multi-surface cleaning. It offers powerful suction, efficient mopping, and smart features to simplify your cleaning routine. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure you get the most out of your device.



Figure 1: Mova K30 Mix Wet Dry Vacuum Cleaner with its various configurations.

2. Setup

Before first use, ensure all components are present and undamaged. Assemble the main body and handle. Charge the device fully using the provided charging base. Fill the clean water tank with appropriate cleaning solution as per instructions.

- **Unpacking:** Carefully remove all components from the packaging.
- **Assembly:** Attach the handle to the main body of the vacuum until it clicks securely into place.
- **Charging:** Place the main unit onto the charging base. Connect the power adapter to the charging base and a power outlet. The battery indicator on the LED screen will show charging status. A full charge typically takes several hours.
- **Filling the Clean Water Tank:** Locate the clean water tank. Open the cap and fill with clean water, adding the recommended amount of Mova cleaning solution. Close the cap securely.



Figure 2: Included components of the Mova K30 Mix, including the main body, handle, charging base, and various tools.

3. Operating Instructions

The Mova K30 Mix offers multiple modes and features for diverse cleaning needs.

3.1. 180° Lie-Flat Reach

The K30 Mix features an advanced 180° lie-flat design, allowing it to reach under low furniture and tight spaces. This design ensures sustained powerful suction through the Liquid Locking System, effectively removing dust, hair, and crumbs from hard-to-reach areas as low as 5.51 inches.



Figure 3: The 180° Lie-Flat design enables cleaning under low furniture.

3.2. Dual Rotation Self Cleaning & 140°F Hot Air Drying

Maintain hygiene and brush longevity with the one-press self-cleaning function. The rotation brush is washed, then

spins at high speed to remove excess water. Following this, a 30-minute 140°F hot air drying cycle ensures the brush is dry and ready for the next use, preventing odors and bacterial growth.



Figure 4: Self-cleaning and hot air drying process for the brush roller.

Your browser does not support the video tag.

Video 1: Official Mova K30 Mix demonstration highlighting key features including self-cleaning and drying.

3.3. Dual Sided Cleaning & Self-Propelled

The exclusive brush roller allows for precise cleaning of baseboards and corners, achieving 0-inch dust removal. The cordless vacuum mop effortlessly moves around your home and stairs with its 8.8lbs lightweight and self-propelled design, reducing user fatigue.



Figure 5: Dual-edge cleaning capability for thorough corner and baseboard cleaning.

3.4. 4-in-1 Versatility for Every Mess

Switch seamlessly between wet-dry vacuum, handheld vacuum, and specialized tools like the Floor Washer, Mini-Brush, and Combination Tool. This versatility allows you to clean every corner with ease, from large floor areas to intricate surfaces.



Figure 6: The 4-in-1 design allows for versatile cleaning applications.

3.5. 18,000Pa Suction for Versatile Cleaning & Smart Messes Detection

Delivering an outstanding 18,000 Pa of suction power, the K30 Mix skillfully manages wet and dry messes through

500 RPM rapid mopping while ensuring quiet operation. The Smart Messes Detection feature automatically adjusts suction and water output based on detected dirt levels (shown on the LED screen), optimizing energy use for thorough cleaning in Auto, Turbo, and Suction modes.




Figure 7: Powerful suction and mopping for effective wet and dry mess cleanup.



Figure 8: Battery performance and coverage area for the Mova K30 Mix.

4. Maintenance

Regular maintenance ensures the longevity and optimal performance of your Mova K30 Mix.

- **Self-Cleaning Cycle:** After each use, place the vacuum on its charging base and initiate the self-cleaning

cycle. This will wash and dry the brush roller.

- **Emptying Dirty Water Tank:** Regularly empty the dirty water tank to prevent odors and maintain suction power. The tank is designed for easy solid/liquid separation.
- **Cleaning Filters:** The HEPA filter should be cleaned regularly. Rinse it with water and allow it to air dry completely before reinserting.
- **Roller Brush Maintenance:** While the self-cleaning feature is effective, occasionally inspect the roller brush for tangled hair or debris and remove manually if necessary. The comb-tooth scraper helps prevent tangles.

5. Troubleshooting

If you encounter any issues with your Mova K30 Mix, refer to the following common troubleshooting tips.

Problem	Possible Cause	Solution
No Power	Battery is low or depleted.	Charge the device fully. Ensure the charging base is properly connected.
Weak Suction	Dirty water tank is full; filter is clogged; brush roller is tangled.	Empty dirty water tank. Clean or replace filter. Remove tangles from brush roller.
Poor Mopping Performance	Clean water tank is empty; wrong cleaning solution; brush roller is dirty.	Refill clean water tank. Use recommended Mova cleaning solution. Run self-cleaning cycle.
Unusual Noise	Obstruction in brush roller or suction path.	Check and remove any foreign objects from the brush roller or suction inlet.

If the problem persists after trying these solutions, please contact Mova customer support for further assistance.

6. Specifications

- **Brand:** Mova
- **Model Name:** K30 Mix
- **Special Feature:** 8.8lbs Lightweight, Dual-Edge Cleaning, 4-in-1 Cordless Vacuum for Multi-Surface, 180° Lie-Flat, 140°F 30min Hot Air Drying
- **Filter Type:** HEPA Filter
- **Is Cordless?:** Yes
- **Capacity:** 0.6 Liters (Clean Water Tank)
- **Runtime:** Up to 30 minutes (Floor Washing), Up to 50 minutes (Vacuuming)
- **Form Factor:** Handheld
- **Color:** White
- **Product Dimensions:** 10.8"L x 9.4"W x 43.4"H
- **Battery Description:** Lithium-Ion (6 batteries included)
- **Manufacturer:** MOVA
- **Item Weight:** 8.8 pounds
- **UPC:** 850067619239

7. Warranty and Support

Mova offers a comprehensive service policy for your K30 Mix. This includes a 30-day money-back service and up to a 36-month warranty. For any product-related inquiries, technical support, or warranty claims, please refer to the contact information provided in your product packaging or visit the official Mova website. A 24/7 rapid responding service team is available to assist you.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question