

[Manuals.plus](#) /

› [Hatteker](#) /

› HATTEKER SK-505 Cordless Women's Epilator User Manual

Hatteker SK-505

HATTEKER SK-505 Cordless Women's Epilator User Manual

Model: SK-505

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your HATTEKER SK-505 Cordless Women's Epilator. Please read all instructions carefully before first use and retain this manual for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

- Do not use the device on irritated skin, open wounds, moles, or varicose veins.
- Consult a doctor before use if you have a skin condition, diabetes, hemophilia, or immune deficiency.
- Keep the device dry when not in use.
- Do not immerse the device in water for extended periods.
- Keep out of reach of children.
- Ensure the charging cable is not damaged before use.
- This appliance contains a built-in rechargeable battery. Do not expose to excessive heat.

3. PRODUCT COMPONENTS

The HATTEKER SK-505 Epilator package includes the following items:

- Epilator Head
- Release Button
- Speed Switch (0-1-2)
- Charging Indicator Light
- USB Charging Cable
- Cleaning Brush
- User Manual (this document)



Image: The Hatteker SK-505 Epilator shown alongside its USB charging cable and cleaning brush, illustrating the complete package contents.

4. CHARGING THE DEVICE

Before first use, fully charge the epilator. The device is equipped with a built-in Lithium battery and is USB rechargeable.

1. Connect the USB charging cable to the epilator's charging port.
2. Plug the other end of the USB cable into a compatible USB power source (e.g., laptop, car charger, power bank, or USB wall adapter).
3. The charging indicator light will illuminate during charging.
4. A full charge takes approximately 8 hours and provides about 40 minutes of cordless operation.



Image: The Hatteker SK-505 Epilator connected to a laptop via its USB charging cable, demonstrating a common charging method.

5. OPERATING THE EPILATOR

5.1. Power On/Off and Speed Settings

The epilator features two speed settings for different hair types and areas.

- To turn on the device, slide the switch to position '1' for the first gear (lower speed). This speed is suitable for areas with sparse hair or difficult-to-reach spots.
- Slide the switch to position '2' for the second gear (higher speed). This speed is recommended for removing most of the hair in larger areas and for dense hair.
- To turn off the device, slide the switch back to position '0'.

TWO SPEED SELECTION

Two Speed Options Designed Specifically for Sensitive Areas

First Gear



Applies to areas with sparse and difficult to reach hair removal.

Second Gear



removes most of the area and dense hair.

2
1
0

Image: A detailed view of the epilator's speed switch, indicating the '0' (off), '1' (low speed), and '2' (high speed) settings.

5.2. Integrated LED Light

The epilator includes an integrated LED light to illuminate the skin, helping to reveal fine hairs for more thorough removal.

- The LED light automatically activates when the epilator is turned on.
- Use the light to ensure no hairs are missed, especially in dimly lit areas or for very fine hair.

INTEGRATED DETAIL LIGHT

High Brightness Lighting for Cleaner Shaving



Image: The Hatteker SK-505 Epilator being used on a leg, with its integrated LED light clearly illuminating the skin surface for enhanced visibility of hairs.

5.3. Epilation Technique

For optimal results and comfort, follow these guidelines:

- Ensure your skin is clean and dry. For wet use, the device is suitable for use in the shower or bath.
- Hold the epilator at a 90-degree angle to your skin.
- Stretch your skin taut with your free hand.
- Move the epilator slowly against the direction of hair growth.
- Do not press too hard; let the epilator do the work.
- The epilator is designed to remove hairs as short as 0.5mm.

EFFICIENT & FAST & PAINLESS

Removes Hair to Leave Skin
Soft and Smooth for Weeks



Image: A diagram illustrating the recommended epilation technique, showing the device held perpendicular to the skin and the mechanism of hair removal from the root.

5.4. Applicable Body Areas

The HATTEKER SK-505 Epilator is suitable for hair removal on various body parts:

- Face (e.g., upper lip)
- Legs
- Arms
- Underarms
- Bikini Area
- Back



Image: A visual guide indicating the various body areas where the Hattaker SK-505 Epilator can be effectively used for hair removal.

6. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and hygiene of your epilator.

1. Always turn off the device and disconnect it from the power source before cleaning.
2. Use the provided cleaning brush to remove any trapped hairs from the epilator head.
3. The epilator head can be rinsed under running water. Ensure it is completely dry before reattaching or storing.
4. Wipe the body of the epilator with a damp cloth. Do not use abrasive cleaners or solvents.
5. Store the device in a cool, dry place.

7. TROUBLESHOOTING

If you encounter issues with your epilator, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device for 8 hours.
Reduced hair removal efficiency.	Epilator head is clogged with hair.	Clean the epilator head with the brush.
Device stops during use.	Battery is low.	Recharge the device.
Skin irritation after use.	Incorrect technique or sensitive skin.	Ensure proper technique (90-degree angle, against hair growth). Apply a soothing lotion after epilation. If irritation persists, discontinue use.

8. TECHNICAL SPECIFICATIONS

- **Model Name:** SK-505
- **Item Model Number:** HT-505
- **Brand:** Hatteker
- **Power Source:** Battery Powered
- **Battery Type:** 1 Lithium Ion battery (included)
- **Charging Time:** 8 Hours
- **Working Time:** Approximately 40 minutes
- **Product Dimensions:** 17.2L x 14.5W Centimeters
- **Item Weight:** 330 Grams
- **Country of Origin:** China
- **Features:** Wet & Dry use, LED Light, 2 Speed settings

9. WARRANTY AND CUSTOMER SUPPORT

HATTEKER products are designed for professional-grade performance. Your HATTEKER SK-505 Epilator comes with a **12-month quality warranty** from the date of purchase.

If you experience any issues or are not satisfied with your product, please contact our customer service team. We are committed to providing a satisfactory resolution within 24 hours.

Contact Information: Refer to the product packaging or the official Hatteker website for specific customer support details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DJYG8TTF>

More documents and user manuals: **<https://manuals.plus/>**